Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

S-Link IP-G10N

S-Link IP-G10N 10000 mAh Portable Power Bank

User Manual

Introduction

Thank you for choosing the S-Link IP-G10N 10000 mAh Portable Power Bank. This device is designed to provide reliable and convenient power for your mobile devices on the go. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

Product Overview

The S-Link IP-G10N is a compact and efficient portable charger with a 10000 mAh capacity. It features multiple ports for versatile charging and recharging.



The S-Link IP-G10N power bank features a compact design with multiple charging ports. On one end, it includes two standard USB-A output ports for charging devices, a Micro USB input port for recharging the power bank, and a USB Type-C port that functions as both an input and an output. The top surface displays the S-Link logo and four small LED indicator lights, which show the remaining battery capacity.

Key Features:

- 10000 mAh Lithium-ion battery capacity
- Dual USB-A output ports
- Micro USB input port
- USB Type-C input/output port
- LED battery level indicator
- Compatible with most smartphones and USB-powered devices

Setup

Initial Charging of the Power Bank:

1. Before first use, fully charge your S-Link IP-G10N power bank.
2. Connect the power bank to a USB wall charger (not included) using either a Micro USB cable or a USB Type-C cable.
3. The LED indicators will light up to show the charging progress. All four LEDs will be solid when the power bank is fully charged.

Connecting Devices:

Ensure your device's charging cable is compatible with the power bank's output ports (USB-A or USB Type-C).

Operating Instructions

Charging the Power Bank:

- Use a Micro USB cable or a USB Type-C cable to connect the power bank's input port to a USB power source (e.g., wall adapter, computer USB port).
- The LED indicators will flash during charging and remain solid when fully charged.

Charging External Devices:

- Connect your device's charging cable to one of the power bank's USB-A output ports or the USB Type-C output port.
- Connect the other end of the cable to your mobile device.
- The power bank should automatically begin charging your device. If not, press the power button (if available, though not explicitly mentioned for this model, it's a common feature) to initiate charging.
- The LED indicators will show the remaining battery level of the power bank during discharge.

LED Indicator Status:

- **4 LEDs:** 75-100% battery remaining
- **3 LEDs:** 50-75% battery remaining

- **2 LEDs:** 25-50% battery remaining
- **1 LED:** 0-25% battery remaining (recharge soon)

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the power bank. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. For long-term storage, it is recommended to charge the power bank to about 50-75% every 3-6 months to maintain battery health.
- **Battery Care:** Avoid fully discharging the power bank frequently. Recharge it before it completely runs out of power to prolong battery life.

Troubleshooting

- **Power bank not charging:**
  - Ensure the charging cable is securely connected to both the power bank and the power source.
  - Try a different charging cable or wall adapter.
  - Verify the power source is active.
- **Device not charging from power bank:**
  - Check if the power bank has sufficient charge (refer to LED indicators).
  - Ensure the charging cable connecting your device to the power bank is functional and securely connected.
  - Try a different output port on the power bank.
  - Test with a different device to rule out a device-specific issue.
- **Slow charging:**
  - Ensure you are using a high-quality charging cable.
  - Some devices may charge slower due to their input current limitations.

Specifications

Feature	Detail
Model Name	IP-G10N
Model Number	35661
Battery Capacity	10000 mAh
Battery Type	Lithium-ion
Input Ports	1x Micro USB, 1x USB Type-C
Output Ports	2x USB-A, 1x USB Type-C
Output Current	Up to 5 A (total, shared across ports)
Special Feature	LED Indicator

Dimensions (L x W x H)	19.7 x 10.4 x 3.5 cm
Weight	230 grams
Compatibility	Universal (compatible with most mobile phones)

Safety Information

- Do not expose the power bank to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Avoid dropping, hitting, or disassembling the device.
- Keep away from water and other liquids.
- Do not use if the power bank is damaged or swollen.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations for lithium-ion batteries.

Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BT837MBC

More documents and user manuals: **https://manuals.plus/**