

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iZEEKER](#) /

› [iZEEKER Projector 4K with WiFi Bluetooth User Manual](#)

iZEEKER iPL610

iZEEKER Projector 4K with WiFi Bluetooth User Manual

Model: iPL610

INTRODUCTION

Thank you for choosing the iZEEKER Projector 4K with WiFi Bluetooth. This projector is designed to provide a high-quality home entertainment experience with its native 1080P resolution, 4K support, 600 ANSI Lumens brightness, and integrated streaming capabilities. It features built-in Netflix, Prime Video, and YouTube applications, Dolby Audio support, 5GHz WiFi, and Bluetooth 5.2 connectivity. This manual will guide you through the setup, operation, and maintenance of your new projector to ensure optimal performance and longevity.



The iZEEKER Projector 4K with WiFi Bluetooth, showcasing its compact design and powerful projection capabilities.

SAFETY INFORMATION

Please read all safety instructions carefully before using the projector. Keep this manual for future reference.

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation around the projector to prevent overheating.
- Use only the power adapter provided with the projector.
- Do not expose the projector to rain or moisture.
- Avoid placing the projector on unstable surfaces.
- Keep the projector away from direct sunlight and heat sources.
- Do not attempt to disassemble or modify the projector. Refer all servicing to qualified personnel.

PACKAGE CONTENTS

Verify that all items are present in the package:

- iZEEKER Projector
- Remote Control
- Power Adapter
- User Manual (this document)
- HDMI Cable (short)



Image showing the iZEEKER Projector, remote control, power adapter, and user manual included in the package.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your iZEEKER Projector.

Front View

- **Projection Lens:** Emits the image.

- **Infrared Receiver:** Receives signals from the remote control.
- **Ventilation Grille:** Ensures proper airflow for cooling.

Rear View

- **Power Port:** Connects to the power adapter.
- **HDMI Port:** Connects to external devices like laptops, gaming consoles, or Blu-ray players.
- **USB Port:** Connects to USB drives for media playback.
- **Audio Out (3.5mm):** Connects to external speakers or headphones.

Top View

- **Control Panel:** Basic navigation and power buttons (if present).

SETUP

1. Initial Power On

1. Connect the power adapter to the projector's power port and then plug it into a power outlet.
2. Press the power button on the projector or the remote control to turn it on.
3. The projector will display the home screen.

2. Focus and Keystone Correction

The projector features electronic focus and automatic keystone correction (vertical only) for a clear, rectangular image.

- **Electronic Focus:** Use the dedicated focus buttons on the remote control to adjust the image sharpness until it is clear.
- **Auto Keystone Correction:** The projector automatically adjusts vertical distortion.
- **Manual 4P/4D Keystone Correction:** For more precise adjustments or horizontal correction, navigate to the settings menu to manually adjust the four corners or four dimensions of the image.

Simply Get a Sharp Picture



Electronic Focus

The electronic focus feature allows for quick and precise image sharpness adjustment using the remote control.

Enjoy Big Screen Anywhere



Illustration of 4D and 4P keystone correction, demonstrating how the projector can adjust the image shape from various angles.

3. Network Connection (WiFi & Bluetooth)

Connect your projector to a wireless network and Bluetooth devices for enhanced functionality.

WiFi Connection (2.4G + 5G)

1. From the home screen, navigate to **Settings**.
2. Select **Network** or **WiFi Settings**.
3. Turn on WiFi and select your desired network from the list.
4. Enter the WiFi password using the on-screen keyboard and confirm.
5. Once connected, the network status will show as connected.

Bluetooth Connection (5.2)

1. From the home screen, navigate to **Settings**.
2. Select **Bluetooth Settings**.
3. Turn on Bluetooth. The projector will search for nearby Bluetooth devices.
4. Select your Bluetooth speaker or headphones from the list of available devices to pair.
5. Once paired, audio will be routed through the connected Bluetooth device.

Fast Audio/Video Experience



5G WiFi Bluetooth

The projector supports 5G WiFi and Bluetooth connectivity, allowing for seamless streaming and audio output to external speakers.

4. Connecting External Devices

The projector supports HDMI and USB inputs.

- HDMI:** Connect your laptop, gaming console, or other HDMI-enabled device to the projector's HDMI port using an HDMI cable. Select the HDMI input source from the projector's input menu.
- USB:** Insert a USB flash drive into the projector's USB port. The projector will typically prompt you to access the media files on the drive.

OPERATING

1. Navigating the Interface

Use the remote control to navigate the projector's user interface. The directional buttons (Up, Down, Left, Right) are used to move between options, and the OK button confirms selections. The Back button returns to the previous screen, and the Home button returns to the main menu.

2. Using Built-in Streaming Apps

The iZEEKER Projector comes with pre-installed Netflix, Prime Video, and YouTube applications, allowing direct streaming without external devices.

1. Ensure the projector is connected to a stable WiFi network.
2. From the home screen, select the desired streaming application (Netflix, Prime Video, or YouTube).
3. Log in with your account credentials if prompted.
4. Browse and enjoy content directly on the projector.



The projector displays the Netflix interface, demonstrating its built-in streaming capabilities.



A couple enjoying a movie projected onto a large screen, highlighting the Netflix Licensed feature of the iZEEKER projector.



This image illustrates the convenience of streaming movies and shows directly from the projector using built-in apps like YouTube, Prime Video, and Netflix, eliminating the need for external devices.

3. Screen Mirroring (Android/PC)

Mirror content from your Android smartphone or Windows PC to the projector. **Note: Wireless connection does not work on iOS devices.**

1. On the projector's home screen, select the **Screen Cast** or **Wireless Projection** application.
2. On your Android device or Windows PC, enable the screen mirroring/wireless display feature (e.g., "Smart View," "Cast," "Wireless Display," or "Project to a wireless display").
3. Select "iZEEKER" from the list of available devices.
4. Wait for the connection to establish. Your device's screen will now be mirrored on the projector.

Android Screen Mirroring

*Screen Mirroring for iOS system is not supported



A step-by-step guide illustrating how to connect an Android device to the iZEEKER projector for screen mirroring.

4. Audio Output (Dolby Audio)

The projector supports Dolby Audio for an immersive sound experience. You can use the built-in speakers or connect external audio devices.

- Built-in Speakers:** The projector's integrated speakers provide clear audio.
- Bluetooth Speakers/Headphones:** For enhanced audio, connect external Bluetooth speakers or headphones as described in the "Network Connection" section.
- 3.5mm Audio Out:** Connect wired speakers or headphones to the 3.5mm audio output port.

Enjoy Immersive Sound



Dolby Audio

People enjoying an immersive sound experience, highlighting the Dolby Audio support of the iZEEKER projector.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your projector.

- **Dust Prevention:** The projector features a full-sealed design to effectively prevent dust from entering the optical engine, minimizing black spots on the projection screen.
- **Cleaning the Lens:** Gently wipe the projector lens with a soft, lint-free cloth specifically designed for optical surfaces. Do not use abrasive cleaners or excessive force.
- **Cleaning the Casing:** Wipe the exterior casing with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by a dry wipe.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, ideally in its original packaging or a protective case.

TROUBLESHOOTING

Refer to this section for solutions to common issues.

Problem	Possible Cause	Solution
No image on screen.	Power not connected, incorrect input source, lens cap on.	Check power connection. Select correct input source (HDMI, USB). Ensure lens is clear.
Image is blurry.	Focus not adjusted, projector too close/far, keystone not corrected.	Adjust electronic focus using the remote. Reposition projector. Adjust keystone correction.
No sound.	Volume too low, external audio device not connected/paired, audio settings.	Increase volume. Check Bluetooth connection or 3.5mm cable. Verify audio output settings.
WiFi connection unstable.	Weak signal, interference, incorrect password.	Move projector closer to router. Check for interference. Re-enter WiFi password. Try 5GHz network if available.
Screen mirroring not working (iOS).	iOS devices not supported for wireless mirroring.	Wireless screen mirroring is not supported for iOS devices. Use an HDMI cable for wired connection.

SPECIFICATIONS

Feature	Detail
Brand	iZEEKER
Model	iPL610
Native Resolution	1920 x 1080 (1080P Full HD)
Supported Resolution	Up to 4K video decoding
Brightness	Real 600 ANSI Lumens
Connectivity Technology	Wireless (5GHz WiFi, Bluetooth 5.2)
Special Features	Built-in Streaming Apps (Netflix, Prime Video, YouTube), Dolby Audio Support, Electric Focus, Auto/4P Keystone, Full-Sealed Optical Engine
Recommended Projection Size	40" to 120" (1.15m to 3.3m distance)
Product Dimensions	7.24 x 5.12 x 8.27 inches
Item Weight	7.41 pounds
Recommended Uses	Indoor

Enjoy Vivid Detail

Native 1080P
4K supported

Other 1080P
supported

8000 Lumens

7000 Lumens

6000 Lumens

600 ANSI

iZEEKER

VS

Others

Visual comparison highlighting the brightness of 600 ANSI Lumens compared to other projectors, ensuring vivid detail.

WARRANTY AND SUPPORT

iZEEKER provides a 2-year after-sales guarantee and lifetime professional technical support for this product.

- Warranty Period:** 2 years from the date of purchase.
- Technical Support:** Lifetime professional technical support is available.
- Contact:** If you have any questions or require assistance, please contact iZEEKER customer service through the platform where you purchased the product or visit the official iZEEKER website for contact information.

