

- › **Qaba** /
- › **Qaba 3-in-1 Toddler Trike Instruction Manual (Model 370-258V00BU)**

Qaba 370-258V00BU

Qaba 3-in-1 Toddler Trike Instruction Manual

Model: 370-258V00BU

INTRODUCTION

Thank you for choosing the Qaba 3-in-1 Toddler Trike. This versatile product is designed to grow with your child, transforming from a push tricycle for younger toddlers to a traditional tricycle and then to a balance bike. This manual provides essential information for safe assembly, operation, and maintenance of your trike. Please read it thoroughly before use and retain it for future reference.



Image description: The Qaba 3-in-1 Toddler Trike in its push tricycle configuration, featuring a blue and black frame, a canopy, and a parent push handle.

SAFETY INFORMATION

Your child's safety is paramount. Please adhere to the following safety guidelines:

- Always supervise children when using the trike.
- Ensure all parts are securely fastened before each use.

- The trike is suitable for children aged 18 to 48 months, with a maximum weight capacity of 55 lbs (25 kg).
- Do not use on public roads, near motor vehicles, steep inclines, or stairs.
- Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads.
- Keep hands and feet away from moving parts.
- This product meets ASTM F963 and CPSIA safety standards.

PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Main Trike Frame
- Front Wheel Assembly with Pedals
- Rear Wheel Assemblies (2)
- Seat with Backrest and 3-point Harness
- Parent Push Handle
- Removable Canopy
- Safety Bar (removable)
- User Manual

ASSEMBLY INSTRUCTIONS

Assembly of the Qaba 3-in-1 Toddler Trike is designed to be straightforward, often utilizing click-and-lock mechanisms without the need for additional tools. Refer to the diagrams for visual guidance.

1. **Attach Rear Wheels:** Insert each rear wheel assembly into the designated slots on the main frame until they click securely into place.
2. **Install Front Wheel:** Connect the front wheel assembly, including the handlebars and pedals, to the main frame. Ensure it is firmly attached and the steering mechanism operates smoothly.
3. **Mount Seat:** Slide the seat onto the frame's seat post. Adjust its position and angle as desired (refer to 'Adjustable Features' section) and lock it in place.
4. **Attach Parent Push Handle:** Insert the parent push handle into the rear receiver on the frame. Adjust its height and secure it.
5. **Install Safety Bar:** If using the push tricycle mode, attach the safety bar around the seat. Ensure it latches securely.
6. **Attach Canopy:** Mount the canopy onto the designated points above the seat. Ensure it is stable and can be adjusted or removed as needed.

3-IN-1 DESIGN



Image description: A visual diagram illustrating the three configurations of the Qaba trike: Push Tricycle Mode, Balance Bike Mode, and Kids Tricycle Mode.

OPERATING MODES

1. Push Tricycle Mode (Ages 18-36 Months)

This mode is ideal for younger toddlers who require assistance. The parent push handle allows an adult to steer and control the trike, while the child is secured by the 3-point harness and safety bar. The canopy provides shade.

- Ensure the parent push handle is securely attached and adjusted to a comfortable height.
- Fasten the 3-point harness and engage the safety bar around the child.
- The child's feet can rest on the footrests if they cannot reach the pedals.



Image description: A woman pushing a child in the Qaba trike, configured as a push tricycle, along a paved path in a park.

2. Kids Tricycle Mode (Ages 24-48 Months)

Once your child is ready to pedal independently, the parent push handle and safety bar can be removed. This mode allows the child to learn steering and pedaling skills.

- Remove the parent push handle and safety bar.
- Ensure the child can comfortably reach the pedals and handlebars. Adjust the seat position if necessary.
- Supervise closely as the child learns to balance and steer.

3. Balance Bike Mode (Ages 30-48 Months)

To transition to a balance bike, the pedals and parent push handle are removed. This mode helps children develop balance and coordination, preparing them for a two-wheeled bicycle.

- Remove the pedals from the front wheel.
- Remove the parent push handle and safety bar.
- Lower the seat to allow the child to place their feet flat on the ground for pushing off and balancing.

EVA WHEELS

Fully-closed for kids' safety



Image description: A young child riding the Qaba trike in balance bike mode on a paved surface, highlighting the durable EVA foam wheels.

ADJUSTABLE FEATURES

Adjustable Parent Push Handle: The detachable parent push handle can be adjusted in height from 20.75 inches to 32.25 inches (53-82 cm) to accommodate parents of different heights. Locate the adjustment mechanism on the handle and secure it at the desired height.

ADJUSTABLE HANDLE

The detachable parent push handle is adjustable from

53-82 cm/20.75" -32.25"





Image description: A diagram illustrating the adjustable range of the parent push handle, from 20.75 inches to 32.25 inches.

Adjustable Seat: The seat can be repositioned to allow your child to face forward or backward, promoting interaction or observation. The backrest angle is also adjustable by up to 140 degrees for enhanced comfort. Locate the seat adjustment levers or buttons to change position and recline angle.

COMFORTABLE SEAT



Angle Adjustable 140°



Position Adjustable

Image description: A diagram demonstrating how the trike's seat can be adjusted in position (forward/backward) and reclined up to 140 degrees for child comfort.

Removable Canopy: The cloth canopy provides shade and protection from light rain. It can be easily removed or folded for storage or when not needed.

ADJUSTABLE CANOPY

For easy storage,
you could remove and fold it



Image description: A diagram illustrating the canopy's ability to be removed and folded for convenience.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your trike:

- **Cleaning:** Wipe down the frame and plastic parts with a damp cloth and mild soap. Avoid abrasive cleaners. The canopy can be spot cleaned.
- **Inspection:** Periodically check all bolts, screws, and fasteners to ensure they are tight. Inspect wheels and tires for wear or damage.
- **Storage:** Store the trike in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Lubrication:** Apply a small amount of silicone-based lubricant to moving parts like wheel axles or steering joints if they become stiff.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Wheels do not turn smoothly.	Debris in axle, loose connection, worn wheel.	Clean axles, check for secure attachment, contact support if worn.
Parent handle feels wobbly.	Handle not fully inserted or locked, adjustment mechanism loose.	Ensure handle is fully engaged and adjustment lock is secure.
Seat is not stable.	Seat not properly locked into position.	Re-engage seat locking mechanism. Ensure it clicks into place.
Pedals do not engage.	Pedals not fully attached or damaged.	Check pedal attachment. If damaged, contact support for replacement parts.

SPECIFICATIONS

Feature	Detail
Model Number	370-258V00BU
Overall Dimensions	38" L x 19.25" W x 39.75" H
Recommended Age	18 months - 4 years
Weight Capacity	55 lbs (25 kg)
Item Weight	13.2 lbs (6 kg)
Parent Handle Height Range	20.75" - 32.25" (53-82 cm)
Backrest Angle Adjustment	Up to 140 degrees
Materials	Aluminum alloy, nylon, EVA foam wheels
Certifications	ASTM F963, CPSIA



Image description: A diagram detailing the overall dimensions of the trike, including length, width, and height, along with seat and handlebar measurements.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or any product-related inquiries, please contact Qaba customer service. Keep your purchase receipt as proof of purchase.

For further assistance and to explore other Qaba products, please visit the official [Qaba Store](#).






[Qaba 370-198 Children's Tricycle: Assembly, Safety, and Usage Guide](#)

Comprehensive guide for the Qaba 370-198 children's tricycle, detailing safety warnings, maintenance procedures, spare parts identification, step-by-step assembly instructions, and usage directions.



[Qaba Children's Tricycle 370-026V00 User Manual and Installation Guide](#)

Comprehensive user manual and installation guide for the Qaba 370-026V00 children's tricycle. Includes safety warnings, maintenance tips, parts list, and step-by-step assembly instructions.



[Qaba 370-061V00 Children's Tricycle User Manual and Safety Guide](#)

Comprehensive user manual and safety guide for the Qaba 370-061V00 children's tricycle. Includes assembly instructions, maintenance tips, parts list, and important safety warnings. Imported by Aosom.



[Qaba Child Tricycle 370-258V00 User Manual and Installation Guide](#)

User and installation guide for the Qaba Child Tricycle (Model 370-258V00). Covers safety, maintenance, spare parts, and assembly instructions for various modes including tricycle and balance bike.



Qaba 370-370V80 Ride-On UTV Owner's Manual

Comprehensive owner's manual for the Qaba 370-370V80 ride-on UTV, covering safety warnings, specifications, assembly instructions, dashboard and remote control operation, charging, maintenance, and troubleshooting.



[Qaba 370-348V80 Owner's Manual: Assembly & Operation Guide](#)

Comprehensive owner's manual for the Qaba 370-348V80 ride-on electric car. Includes detailed assembly instructions, operating guidelines, safety warnings, and troubleshooting tips for children's use.