

[Manuals.plus](#) /

› [MeetLeisure](#) /

› MeetLeisure Outdoor Swivel Rocker Patio Chairs with Side Table User Manual

## MeetLeisure Meetleisure

# MeetLeisure Outdoor Swivel Rocker Patio Chairs with Side Table User Manual

Model: Meetleisure

Brand: MeetLeisure

## SAFETY INFORMATION

---

**WARNING:** This product requires assembly. Always follow the assembly instructions carefully to ensure stability and safety.

Maximum weight capacity is **300 lbs** per chair. Exceeding this limit may cause the chair to tip or break, leading to injury.

Regularly inspect all bolts and connections to ensure they remain tight.

Do not stand on the chairs or side table.

Keep children and pets away from the assembly area.

## PACKAGE CONTENTS

---

Before assembly, ensure all parts listed below are present. If any parts are missing or damaged, contact customer support.

- 2 x Swivel Rocker Chairs
- 1 x Side Table
- Cushions (seat and back)
- Assembly Hardware (screws, washers, wrench)

**Note:** Specific part labels (e.g., Part A, Part B) are referenced in the assembly video.

## ASSEMBLY INSTRUCTIONS

---

Assembly is required for the MeetLeisure Outdoor Swivel Rocker Patio Chairs and Side Table. It is recommended to have two people for assembly.

**Tools Required:** Included Allen wrench.

**Important:** Do not fully tighten screws until all parts are loosely assembled. This allows for proper alignment.

## Chair Assembly

Follow the steps outlined in the assembly video for detailed visual guidance.

Your browser does not support the video tag.

**Video:** M50 Swivel Rocker Patio Chair Set Assembly Instruction. This video provides a step-by-step guide on how to assemble the swivel rocker patio chairs, detailing the connection points and hardware usage.

1. Begin by identifying the main frame components of the chair.
2. Attach the backrest to the seat frame using the provided screws and washers. Ensure the arms are horizontally placed and parts A & B incline to the demonstrated angle as shown in the video.
3. Secure the armrests to the seat and backrest. Use short screws and washers (8, 13) for the top connections and short screws and washers (11, 13) for the lower connections.
4. Connect the swivel base to the chair frame. Four washers and bolts (12, 13, 14, 15) are needed for this step.
5. Once all components are loosely connected, gradually tighten all screws evenly to ensure stability.

## Side Table Assembly

The side table assembly is straightforward.

1. Attach the legs to the tabletop.
2. Secure the lower shelf between the legs.
3. Tighten all screws.

## OPERATING INSTRUCTIONS

---

### Swivel Function

The chairs feature a 360-degree swivel base. To rotate, simply shift your weight or gently push off the ground with your feet in the desired direction.

### Rocking Function

The chairs are designed with a gentle rocking motion. Lean back and forth to engage the rocking mechanism.

### Side Table Usage

The side table provides a convenient surface for drinks, books, or other small items. The lower shelf offers additional storage.

## COMFORTABLE AND DURABLE

| Thoughtful Designs for Excellent Experience



| **5"**-thick cushion with high elasticity



| **4"**-wide Ergonomic Armrest



| Top-notched PE Rattan Anti Deforming, Cracking and Fading



**Image:** This image illustrates the side table's storage capacity and a person enjoying the rocking motion of the chair.

Your browser does not support the video tag.

**Video:** Meetleisure Outdoor Swivel Rocker Chair with Side Table. This video demonstrates the chairs' swivel and rocking functions, as well as the utility of the side table in an outdoor setting.

## CARE AND MAINTENANCE

### Cleaning the Wicker Frame

Wipe the resin wicker frame with a soft cloth dampened with mild soap and water. Rinse thoroughly and dry completely to prevent water spots.

### Cushion Care

The cushions are made from premium Olefin fabric. Spot clean with a mild detergent and water. For deeper cleaning, remove covers if possible and follow care instructions on the label. Allow cushions to air dry completely before use or storage.

Store cushions indoors during inclement weather or prolonged periods of non-use to extend their lifespan and prevent fading.

# Applied to Multi-Spaces



**Image:** Detail of the durable, all-weather resin wicker.



**Image:** Detail of the premium beige Olefin fabric used for the cushions.

## General Care

Cover the furniture set when not in use for extended periods to protect it from environmental elements.

Periodically check and tighten all bolts and screws to ensure the furniture remains stable and safe.

## TROUBLESHOOTING

---

### **Chairs are wobbly after assembly.**

**Solution:** Ensure all bolts are tightened evenly. If you tightened them fully during initial assembly, loosen them slightly, adjust the chair to sit flat, then re-tighten all bolts.

### **Swivel/rocking motion is not smooth.**

**Solution:** Check for any obstructions under the base. Apply a silicone-based lubricant to the moving parts of the swivel/rocker mechanism if needed.

### **Cushions appear faded.**

**Solution:** While Olefin fabric is fade-resistant, prolonged direct sun exposure can cause some fading over time. Store cushions indoors or cover the furniture when not in use to minimize exposure.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	MeetLeisure
Model Name	Meetleisure
Model Number	Meetleisure
Color	Beige
Material	Resin Wicker, Aluminum Frame, Olefin Fabric
Product Dimensions (Chair)	30"D x 31"W x 32"H
Product Dimensions (Table)	20"D x 20"W x 22"H
Item Weight	133.3 Pounds (Total for 3 PCS)
Maximum Weight Recommendation	300 Pounds per chair
Indoor/Outdoor Usage	Outdoor
Required Assembly	Yes
Special Features	360° Swivel, Rocking Function, Ergonomic Design, Extra Side Table



**Image:** Detailed product dimensions for the chair (31"W x 30"D x 32"H) and side table (20"W x 20"D x 22"H).

# PRODUCT DIMENSION



**Image:** Highlights comfort and durability features such as 5-inch thick cushions, 4-inch wide ergonomic armrests, and top-notched PE rattan.

## WARRANTY INFORMATION

For specific warranty details, please refer to the warranty card included with your product packaging or contact MeetLeisure customer support directly.

Typically, warranties cover manufacturing defects under normal use. Damage resulting from improper assembly, misuse, or neglect may not be covered.

## CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact MeetLeisure customer support.

**Seller:** Newlancy

**Amazon Store:** [MeetLeisure Store on Amazon](#)

Please have your model number (Meetleisure) and purchase date available when contacting support.

