

BESIGN LSX7

BESIGN LSX7 Laptop Stand User Manual

Model: LSX7 | Brand: BESIGN

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your BESIGN LSX7 Laptop Stand. Designed for ergonomic comfort and versatility, the LSX7 stand helps optimize your workspace by elevating your laptop to an ideal viewing height and angle. Please read this manual thoroughly to ensure proper use and to maximize the benefits of your new laptop stand.



Figure 1: BESIGN LSX7 Laptop Stand

PRODUCT FEATURES

- **Broad Compatibility:** Supports laptops ranging from 10 to 15.6 inches, including models from Air, Pro, Lenovo ThinkPad, Dell, HP, ASUS, and Chromebook.
- **Ergonomic Design:** Adjustable height and angle to minimize neck fatigue and promote better posture. Adjustments are tool-free, requiring only a push or pull.
- **Stable and Protective:** Constructed from premium metal materials, ensuring stability for laptops up to 13 lbs (6kg). Features rubber pads on the holder hands to prevent scratches and secure the laptop in place.
- **Enhanced Heat Dissipation:** An open design facilitates good ventilation and airflow, preventing laptop overheating. This design also allows for storage of peripherals like keyboards and mice underneath.
- **Rotatable and Adjustable:** Equipped with a 360° rotatable axis for flexible viewing angles, allowing users to incline the stand at various angles and adjust height as needed.

SETUP AND ASSEMBLY

The BESIGN LSX7 Laptop Stand comes pre-assembled. To set it up for use:

1. Place the stand on a stable, flat surface.
2. Gently pull the top platform upwards to unfold the stand. The hinges are designed to be firm to maintain stability, so a moderate amount of force may be required.
3. Adjust the height and angle of the laptop platform to your desired ergonomic position. The stand's arms can be moved up or down to achieve the optimal viewing level.
4. Ensure the stand is stable and locked into your chosen position before placing your laptop on it.

LSX7 Adjustable Laptop Riser



Figure 2: Step-by-step adjustment of the LSX7 Laptop Stand

OPERATING INSTRUCTIONS

Once set up, the LSX7 stand offers flexible operation:

- **Height Adjustment:** To change the height, firmly hold the base and gently push or pull the laptop platform to the desired vertical position. The robust hinges will hold the position securely.
- **Angle Adjustment:** The laptop platform can be tilted to various angles. Apply gentle pressure to the top or bottom of the platform to adjust its tilt.
- **360° Rotation:** The base of the stand features a 360° rotatable axis. You can easily swivel your laptop to share your screen or adjust your viewing angle without moving the entire stand.

Rotatable & Ergonomic

360° Rotatable Axis for your flexible viewing angles.



Figure 3: Demonstrating 360-degree rotation

MAINTENANCE

To ensure the longevity and optimal performance of your BESIGN LSX7 Laptop Stand:

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically check all moving parts and rubber pads for wear and tear. Ensure the hinges remain firm.
- **Storage:** When not in use, the stand can be folded flat for compact storage. Store in a dry place away from extreme temperatures.

Foldable Design

Foldable and light weight, easy to store, use it anywhere and any time.



Figure 4: Foldable design for easy storage

TROUBLESHOOTING

If you encounter any issues with your laptop stand, consider the following:

- **Stiffness in Adjustment:** The hinges are designed to be stiff to provide maximum stability. This is a normal characteristic and ensures the stand holds its position. Apply firm, even pressure when adjusting.
- **Laptop Slipping:** Ensure the rubber pads on the holder hands and base are clean and free from debris. These pads provide friction to keep your laptop secure.
- **Wobbling:** Verify that the stand is placed on a completely flat and stable surface. Ensure all adjustable joints are firmly set.

SPECIFICATIONS

Attribute	Detail
Brand	BESIGN





Model Number	LSX7
Compatible Devices	Laptops (10-15.6 inches)
Material	Premium Metal
Color	Black
Item Weight	2.84 pounds
Max Load Capacity	13 lbs (6kg)
Rotation	360° Rotatable Axis

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact BESIGN customer service directly through their official website or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

© 2023 BESIGN. All rights reserved.

Related Documents - LSX7

	BESIGN BE-RCA Pro Wireless Music Receiver User Manual User manual for the BESIGN BE-RCA Pro, a wireless Bluetooth music receiver designed to connect audio systems wirelessly. Includes setup, pairing, and troubleshooting instructions.
	BESIGN BTH01 Wireless Headphones & Transmitter Set: Quick User Guide Comprehensive guide to setting up and using the BESIGN BTH01 wireless headphones and transmitter set for TV and mobile devices. Includes pairing, troubleshooting, and care instructions.
	BESIGN BE-RCA Pro Wireless Music Receiver User Manual User manual for the BESIGN BE-RCA Pro, a wireless Bluetooth music receiver designed to connect audio systems wirelessly. Includes setup, pairing, and troubleshooting instructions.
	BESIGN BTH01 Wireless Headphones & Transmitter Set: Quick User Guide Comprehensive guide to setting up and using the BESIGN BTH01 wireless headphones and transmitter set for TV and mobile devices. Includes pairing, troubleshooting, and care instructions.