



[Manuals.plus](#) /

> [Ninja](#) /

> Ninja BN805A Pro Plus Kitchen System Instruction Manual

## Ninja BN805A

# Ninja BN805A Pro Plus Kitchen System Instruction Manual

Model: BN805A

## INTRODUCTION

The Ninja Pro Plus Kitchen System with Auto-iQ is a versatile 5-in-1 appliance designed for a variety of food preparation tasks. With 1400 peak watts of professional power, it efficiently handles blending, chopping, dough mixing, and nutrient extraction. This system includes a 72 oz. Total Crushing Pitcher, an 8-cup Precision Processor Bowl, and two 32 oz. single-serve cups, offering comprehensive solutions for your kitchen needs.



Figure 1: Overview of the Ninja BN805A Pro Plus Kitchen System components.

## IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons. Read all instructions before using this appliance.

- **Sharp Blades:** Handle blade assemblies with extreme care. The blades are sharp.
- **Hot Liquids:** Do not blend hot liquids.
- **Secure Placement:** Ensure the motor base is placed on a clean, dry, and level surface. The suction cups on the base provide stability during operation.
- **Maximum Fill Line:** Do not exceed the maximum fill line indicated on the pitchers or cups to prevent overflow and potential damage.
- **Proper Assembly:** Always ensure the lid is securely locked in place before operating the appliance.

## WHAT'S INCLUDED

The Ninja BN805A Pro Plus Kitchen System comes with the following components:

- 1400-Peak-Watt Motor Base
- 72 oz. Total Crushing Pitcher with Stacked Blade Assembly

- 8-cup Precision Processor Bowl with Chopping Blade Assembly and Dough Blade Assembly
- Two 32 oz. Single-Serve Cups with Spout Lids and Pro Extractor Blades Assembly
- Recipe Inspiration Guide (30 recipes)



Figure 2: All included components of the Ninja Kitchen System.

## SETUP

Before first use, wash all components (pitcher, bowls, cups, lids, and blade assemblies) in warm, soapy water, then rinse and dry thoroughly. All removable parts are dishwasher safe.

### Assembling the Blender Pitcher:


1. Place the motor base on a clean, dry, level surface.
2. Align the pitcher with the motor base and twist clockwise until it clicks into place.
3. Carefully place the Stacked Blade Assembly onto the drive gear inside the pitcher.
4. Place the pitcher lid on top and press down firmly until the handle clicks into the locked position.

### Assembling the Precision Processor Bowl:

1. Place the motor base on a clean, dry, level surface.
2. Align the processor bowl with the motor base and twist clockwise until it clicks into place.
3. Carefully place the desired blade assembly (Chopping or Dough) onto the drive gear inside the bowl.
4. Place the processor bowl lid on top and press down firmly until the handle clicks into the locked position.

### Assembling the Single-Serve Cups:

1. Fill the single-serve cup with ingredients, ensuring not to exceed the MAX FILL line.
2. Screw the Pro Extractor Blades Assembly onto the cup until tightly sealed.
3. Invert the cup and place it onto the motor base, twisting clockwise until it clicks into place.



**Includes a recipe book with  
30 recipes to inspire you**

Figure 3: Detailed view of component assembly.

### OPERATING INSTRUCTIONS


The Ninja Pro Plus Kitchen System features both manual speed controls and intelligent Auto-iQ programs for optimized

results.

## Control Panel Overview:

- **Manual Speeds:** LOW, MED, HIGH, PULSE. Use these for precise control over blending and processing.
- **Auto-iQ Programs:**
  - **SMOOTHIE:** For smooth, drinkable blends.
  - **ICE CRUSH:** Designed to crush ice into snow in seconds.
  - **EXTRACT:** For nutrient extractions from fruits and vegetables.
  - **CHOP:** For consistent chopping of ingredients.
  - **DOUGH:** For quickly mixing and kneading dough.

# Get to know the Ninja® Professional Plus Kitchen System



\*\*64 oz. max liquid capacity

\*Extract a drink containing vitamins and nutrients from fruits and vegetables.

Figure 4: The intuitive control panel with Auto-iQ programs.

## Usage Tips:

- For best results, follow the recommended fill levels for each container.

- The Auto-iQ programs feature unique timed pulsing, blending, and pausing patterns that automatically handle the processing for you.
- The included Recipe Inspiration Guide provides 30 recipes to help you get started with various functions.

# What's included in your Ninja® Professional Plus Kitchen System

**NINJA**  
PROFESSIONAL PLUS  
KITCHEN SYSTEM



## **INCLUDES**

- 1400-Peak-Watt Motor
- 72 oz.\* Total Crushing® Pitcher
- Two 32 oz. Single Serve Cups
- 8-Cup Precision Processor® Bowl
- 5 Auto-iQ® Programs
- 4 Manual Programs
- 30 Recipe Inspiration Guide

\*64 oz. max liquid capacity

Figure 5: Demonstrating the versatility of the system for blending and processing.



## Professional versatility

Blend smoothies and frozen drinks, chop veggies, puree smooth sauces, and mix doughs all in one system.

Figure 6: Preparing dough with the Precision Processor Bowl.



## Meal prep made easy

Use the Precision Processor® bowl to quickly chop ingredients or the DOUGH program to whip up homemade dough.

Figure 7: The included recipe book offers diverse culinary inspiration.

### MAINTENANCE & CLEANING

Proper maintenance ensures the longevity and optimal performance of your Ninja Kitchen System.

- **Dishwasher Safe:** All removable parts, including the pitcher, single-serve cups, processor bowl, and blade assemblies, are dishwasher safe. Place them on the top rack for best results.
- **Hand Washing:** For hand washing, use warm, soapy water and a non-abrasive cloth or sponge. Exercise extreme caution when cleaning blade assemblies due to their sharp edges.
- **Motor Base Cleaning:** Wipe the motor base clean with a damp cloth. Do not immerse the motor base in water or any other liquid.

### TROUBLESHOOTING

If you encounter any issues with your Ninja Kitchen System, refer to the following common troubleshooting tips:

- **Appliance Not Turning On:** Ensure the unit is properly plugged into a working electrical outlet. Check that the pitcher/bowl/cup is correctly assembled and securely locked onto the motor base. The lid must also be securely locked.
- **Motor Stops During Operation:** This may indicate overheating. Unplug the unit, remove the container, and allow the motor base to cool down for at least 15 minutes before attempting to use it again. Reduce the load or liquid in the container if the issue persists.
- **Ingredients Not Blending/Processing:** Ensure there is enough liquid in the mixture for blending. For thicker mixtures, use the PULSE function or add more liquid. For food processing, ensure ingredients are cut into appropriate sizes.

For further assistance, please contact Ninja customer support.

## SPECIFICATIONS

Feature	Detail
Brand	Ninja
Model Name	BN805A (NJBN805ARB)
Power	1400 Peak Watts
Product Dimensions	9.63"D x 7.38"W x 18"H
Color	Black
Blade Material	Stainless Steel
Dishwasher Safe	Yes (removable parts)
Item Weight	13.89 pounds
UPC	622356584739



Figure 8: Product dimensions for space planning.

## WARRANTY & SUPPORT

For warranty information, product registration, or technical support, please visit the official Ninja website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims. Visit the [Ninja Store](#) for more products and information.