

- Manuals.plus /
- › NAWAZJEE /
- › NAWAZJEE 5-in-1 4D Electric Shaver User Manual

NAWAZJEE LK -1800

NAWAZJEE 5-in-1 4D Electric Shaver User Manual

Model: LK -1800

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use, maintenance, and troubleshooting of your NAWAZJEE 5-in-1 4D Electric Shaver. Please read this manual thoroughly before first use and keep it for future reference.



Image 1.1: The NAWAZJEE 5-in-1 4D Electric Shaver with its various interchangeable heads, including the rotary shaver, facial hair trimmer, nose/ear trimmer, facial cleansing brush, and pre-shave massage brush.

2. SAFETY INFORMATION

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Use only the approved charger for this waterproof electric shaver.
- Do not use near water sources or while charging unattended.
- Be cautious when handling the shaver to avoid cuts.
- Do not use while sleeping.
- Clean and maintain the device regularly to prevent bacterial growth and skin irritation.
- This product is not suitable for trimming pet hair.

3. PACKAGE CONTENTS

Please verify that all items are present in the package:

- Electric Shaver Main Unit
- Rotary Shaver Head (4D/5D)
- Facial Hair Trimmer Head
- Nose and Ear Trimmer Head
- Facial Cleansing Brush Head
- Pre-Shave Massage Brush Head
- USB Charging Cable
- Cleaning Brush
- User Manual



Image 3.1: An illustration showing the main shaver unit and its five distinct interchangeable heads, highlighting the comprehensive grooming kit.

4. PRODUCT FEATURES

- **5-in-1 Versatility:** Includes rotary shaver, facial hair trimmer, nose/ear trimmer, facial cleansing brush, and pre-shave massage brush.

- **Wet & Dry Use:** Designed for comfortable dry shaving or refreshing wet shaving with foam or gel.
- **IPX7 Waterproof:** Fully washable for easy cleaning under running water.
- **Cordless Operation:** Provides freedom of movement during use.
- **Ergonomic Design:** Ensures a comfortable and controlled grip.
- **Long-Lasting Battery:** Equipped with a Lithium Polymer battery for extended use.
- **USB Charging:** Convenient charging via USB cable.



Image 4.1: Visual representation of the shaver's key features, including quick shaving, irritation-free experience, smooth cutting performance, and user-friendly design.

5. SETUP AND CHARGING

5.1 Initial Charge

Before first use, fully charge the shaver. Connect the USB charging cable to the shaver's charging port and plug the other end into a compatible USB power adapter (not included) or a computer USB port. The charging indicator light will show the charging status.

5.2 Attaching/Detaching Heads

To attach a head, align the head with the main unit and gently push until it clicks into place. To detach, firmly pull the head away from the main unit. Ensure the shaver is turned off before changing heads.

NJ

Water Resistant **Shaver!**

**USB
Charging****8500 RPM
Motor**

Image 5.1: The shaver is shown being used in a wet environment, emphasizing its water-resistant design. The image also highlights its USB charging feature and 8500 RPM motor.

6. OPERATING INSTRUCTIONS

Press the power button to turn the shaver on or off.

6.1 Rotary Shaver Head (for Head and Face)

For best results, move the shaver in small, circular motions over the skin. For head shaving, ensure hair is short (stubble length) for optimal performance. Can be used wet or dry.

6.2 Facial Hair Trimmer Head

Use for shaping sideburns, beard lines, or trimming longer facial hair before shaving. Move the trimmer against the direction of hair growth.

6.3 Nose and Ear Trimmer Head

Gently insert the trimmer tip into the nostril or ear canal. Move it slowly to trim unwanted hair. Do not insert too deeply.

6.4 Facial Cleansing Brush Head

Attach the brush head and apply your preferred facial cleanser to your face or directly to the brush. Gently move the brush in circular motions across your face to cleanse and remove impurities.

6.5 Pre-Shave Massage Brush Head

Use this head to gently massage your skin before shaving. This can help lift hairs and prepare the skin for a smoother shave.

MULTI – PERFORMANCE ONE SHAVER MEETS ALL NEEDS

Beard | Nose hair | Head | Facial Cleaning | Facial Massagher | Side Burns



Image 6.1: This image illustrates the multi-performance capabilities of the shaver, showing its application for head shaving, beard trimming, body grooming, and nose hair removal.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene.

7.1 Daily Cleaning

After each use, turn off the shaver. Detach the head and rinse it thoroughly under running water. You can also use the included cleaning brush to remove any trapped hair from the blades and inside the head unit. Allow the head to air dry completely before reattaching or storing.

7.2 Deep Cleaning

Periodically, for a more thorough clean, you may detach the rotary blades from their housing (refer to the head's specific design for removal instructions) and rinse them individually. Ensure all parts are dry before reassembly.

7.3 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the shaver when the battery indicator shows low power. If storing for an extended period, charge the shaver every few months.

EASY TO CLEAN



Image 7.1: The shaver head is shown open and wet, indicating its washable and water-resistant design. A cleaning brush is also visible, illustrating the ease of hair removal and maintenance.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
Poor shaving performance.	Blades are dirty or clogged with hair. Blades are worn. Hair is too long.	Clean the shaver head thoroughly. Consider replacing the shaver head if blades are dull. Trim longer hair with the trimmer head first.

Problem	Possible Cause	Solution
Shaver stops during use.	Battery is low.	Recharge the shaver.
Skin irritation after shaving.	Improper technique. Skin not prepared. Shaver head is dirty.	Use gentle, circular motions. Use the pre-shave massage brush. Ensure shaver head is clean. Consider wet shaving with foam/gel.

9. SPECIFICATIONS

- **Model Name:** NAWAZJEE Rotary 5 in 1
- **Item Model Number:** LK -1800
- **Power Source:** Battery Powered
- **Battery Type:** 1 Lithium Polymer battery (included)
- **Product Dimensions:** 3.9 x 3.2 x 0.4 inches
- **Item Weight:** 12.31 ounces
- **Special Feature:** Ergonomic Design
- **Recommended Uses:** Scalp, Face, Body, Nose, Ear

10. WARRANTY AND SUPPORT

The product is stated to have a lifetime warranty. For warranty claims or technical support, please refer to the contact information provided with your product packaging or visit the official NAWAZJEE website. Keep your purchase receipt as proof of purchase.

11. OFFICIAL PRODUCT VIDEOS

No relevant official product videos from the seller were found to be embedded in this manual.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BTBLMMLH>

More documents and user manuals: <https://manuals.plus/>