Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE ULTV330T21

VASAGLE ULTV330T21 TV Stand with LED Lights

Instruction Manual

Introduction

Thank you for choosing the VASAGLE ULTV330T21 TV Stand. This entertainment center is designed to accommodate TVs up to 70 inches, featuring integrated LED lighting, open glass shelves, and two cabinets with doors for versatile storage. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.



Image: The VASAGLE ULTV330T21 TV Stand, showcasing its design and functionality in a modern living room.

Safety Instructions

- For safety reasons, children are not allowed to climb or play on this TV stand.
- Ensure all parts are securely fastened before use.
- Do not exceed the maximum weight capacity of 200 lb (90.7 kg).
- Place the TV stand on a level and stable surface to prevent tipping.
- Keep electrical components, especially the LED lights, away from water and moisture.
- Avoid exposing the unit to direct sunlight or extreme temperatures.

Package Contents

Before beginning assembly, please verify that all components listed below are present and undamaged:

- 1 x VASAGLE ULTV330T21 TV Stand with LED Lights
- 1 x Accessory Kit (including all necessary hardware and a screwdriver)
- 1 x Instruction Manual

If any parts are missing or damaged, please contact customer support for assistance.

Setup and Assembly

Assembly of the VASAGLE ULTV330T21 TV Stand is designed to be straightforward. Follow the numbered steps in the included instruction manual carefully. It is recommended to have two people for assembly due to the size and weight of the components.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Verify all parts against the parts list in the manual.
2. **Assemble the Main Frame:** Follow the diagrams to connect the side panels, bottom panel, and central support structures using the provided hardware.
3. **Install Glass Shelves:** Carefully insert the glass shelves into the designated slots. Ensure they are seated securely.
4. **Attach Cabinet Doors:** Mount the cabinet doors using the soft-close hinges. Adjust as necessary for proper alignment.
5. **Install LED Lights:** The LED lights are pre-embedded. Ensure the power cable is accessible for connection.
6. **Final Placement:** Move the assembled TV stand to its desired location. Ensure it is stable and level before placing any items on it.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and assembly of the VASAGLE LED TV Stand. This video provides a visual guide to the product's design and functionality.

Operating Instructions (LED Lights)

The integrated LED lights enhance the ambiance of your living space. They are controlled via a remote control.

Remote Control Functions:

- **Power Button:** Turns the LED lights ON or OFF.
- **Color Selection:** Buttons for Blue, Red, Purple, Cyan, White, and RGB (color cycling) allow you to choose your preferred light color.
- **Brightness Adjustment:** Use the '+' and '-' buttons to increase or decrease the light intensity.
- **Mode Selection:** Toggle between constant light mode and breathing light mode (fading in and out).
- **Memory Function:** The lights will remember the last selected color and mode when turned back on.



Image: The remote control for the LED lights, illustrating the various color and function buttons.

Ensure the remote control is pointed towards the receiver on the TV stand for optimal functionality. The remote operates within a range of approximately 16.4 ft (5 meters).

Maintenance

To maintain the appearance and longevity of your VASAGLE TV Stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the particleboard and veneered panels.
- **Glass Care:** Use a glass cleaner for the glass shelves to keep them clear and streak-free.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.



Image: The durable, easy-to-clean veneered panels of the TV stand.

Troubleshooting

If you encounter any issues with your TV stand, refer to the following common solutions:

- **LED Lights Not Working:**
  - Ensure the power adapter is securely plugged into both the TV stand and a working power outlet.
  - Check the remote control battery.
  - Verify that the remote control is pointed directly at the LED receiver.
- **Wobbly Stand:**
  - Check all assembly screws and tighten any loose connections.
  - Ensure the TV stand is placed on a flat, even surface.
- **Cabinet Doors Not Aligning:**
  - Adjust the hinges as per the assembly instructions to correct alignment.

For persistent issues or further assistance, please contact VASAGLE customer support.

Specifications

Attribute	Detail
Brand	VASAGLE
Model Number	ULTV330T21
Color	Black

Material	Particleboard, Tempered Glass
Dimensions (L x W x H)	63"L x 15.7"W x 23.6"H (160 cm x 40 cm x 60 cm)
Item Weight	82 Pounds (37.2 kg)
Max. TV Size Supported	Up to 70 inches
Max. Weight Capacity	200 lb (90.7 kg)
LED Lights	6 colors, adjustable brightness, constant/breathing modes, memory function
Assembly Required	Yes
Product Care	Wipe with Damp Cloth




Image: Dimensional overview of the TV stand, indicating its length, width, height, and TV size compatibility.

Warranty and Support

For warranty information, technical support, or to order replacement parts, please refer to the contact details provided on the VASAGLE official website or the documentation included with your purchase. Please have your model number (ULTV330T21) and purchase date ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTD15BZN

More documents and user manuals: **https://manuals.plus/**