

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Bella Depot](#) /

› Bella Depot Farmhouse Chandelier User Manual

Bella Depot Chandelier1

Bella Depot Farmhouse Chandelier User Manual

Model: Chandelier1

Brand: Bella Depot

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Bella Depot Farmhouse Chandelier. Please read this manual thoroughly before installation and keep it for future reference. This chandelier is designed to add a rustic and elegant touch to various indoor spaces such as dining rooms, kitchens, foyers, hallways, and entryways.



Image: The Bella Depot Farmhouse Chandelier, showcasing its weathered wood finish and six light sockets.

SAFETY INFORMATION

- Always turn off the main power supply at the circuit breaker before beginning any installation or maintenance.
- All electrical connections must be in accordance with local and national electrical codes. If you are unsure about wiring, consult a qualified electrician.
- This fixture is designed for indoor use only.
- Ensure the mounting surface can support the weight of the fixture.
- Use only E12 base bulbs, maximum 40W per bulb. Do not exceed the recommended wattage.
- Do not connect this fixture to an ungrounded electrical system.
- UL approved core components ensure safety and reliability.

PACKAGE CONTENTS

Carefully unpack the box and ensure all parts are present and undamaged. If any parts are missing or broken, contact Bella Depot customer service immediately.

Component	Quantity
Chandelier Fixture	1
Adjustable Metal Chain	1
Canopy	1
Mounting Hardware (screws, wire nuts, etc.)	1 set
Instruction Manual	1

Note: Bulbs are not included and must be purchased separately. Requires 6 x E12 Base max 40W incandescent or LED bulbs.

SPECIFICATIONS

Feature	Detail
Model Number	Chandelier1
Dimensions (Overall)	17.8"L x 17.8"W x 24.4"H
Adjustable Chain Length	Up to 70 inches
Canopy Size	5.1"L x 5.1"W x 1.2"H
Bulb Base	E12
Max Wattage per Bulb	40W
Number of Lights	6
Material	Wood, Metal
Finish	Weathered Wood
Installation Type	Semi Flush Mount
Special Features	Dimmable (with compatible bulbs and dimmer switch)
Safety Certification	UL Approved Core Components




Image: Diagram illustrating the dimensions of the chandelier, including length, width, height, canopy size, and adjustable chain length.

INSTALLATION INSTRUCTIONS

Installation typically takes less than 10 minutes. Follow these steps carefully:

1. Prepare for Installation:

- Turn off power at the circuit breaker.
- Ensure you have all necessary tools (screwdriver, wire strippers, electrical tape, etc.) and the included mounting hardware.

2. Attach Mounting Bracket:

- Secure the mounting bracket to the junction box in your ceiling using the provided screws.

3. Adjust Chain Length:

- Determine the desired hanging height for your chandelier. The chain is adjustable up to 70 inches. Use pliers to open and remove links as needed to achieve the correct length.
- Feed the electrical wires through the chain and canopy.

4. **Make Electrical Connections:**

- Connect the fixture's ground wire (usually bare copper or green) to the ground wire from the junction box.
- Connect the fixture's neutral wire (usually white) to the neutral wire from the junction box.
- Connect the fixture's hot wire (usually black) to the hot wire from the junction box.
- Secure all connections with wire nuts and wrap with electrical tape for added safety.

5. **Secure Canopy:**

- Carefully push the canopy up against the ceiling, covering the junction box and wiring.
- Secure the canopy to the mounting bracket using the provided screws or nuts.

6. **Install Bulbs:**

- Screw 6 E12 base bulbs (not included) into the chandelier sockets. Ensure bulbs do not exceed 40W each.

7. **Restore Power:**

- Turn the power back on at the circuit breaker.
- Test the chandelier to ensure it functions correctly.

Your browser does not support the video tag.

Video: An official product video demonstrating the appearance and features of the Bella Depot Farmhouse Chandelier, including its installation in a living space.



Image: The chandelier installed in a kitchen setting, demonstrating its aesthetic appeal in a typical home environment.

OPERATING INSTRUCTIONS

Once installed, operate the chandelier using your standard wall switch. This fixture is dimmable, allowing you to adjust the light intensity if you use dimmable E12 bulbs and a compatible dimmer switch (sold separately).

- **Turning On/Off:** Use the wall switch connected to the chandelier's circuit.
- **Dimming Function:** If you have installed dimmable E12 bulbs and a compatible dimmer switch, use the dimmer switch to adjust the brightness level.



Image: The chandelier illuminated, showcasing the warm light emitted from its six bulbs.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

- **Cleaning:**

- Always turn off power before cleaning.
- Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents as they may damage the finish.
- For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth.

- **Bulb Replacement:**

- Ensure power is off and bulbs have cooled before replacing.
- Unscrew the old bulb and screw in a new E12 base bulb (max 40W).

- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	No power to fixture, loose wiring, faulty bulb, tripped circuit breaker.	Check circuit breaker. Ensure all wire connections are secure. Replace bulb. Test power at the fixture.
Flickering lights	Loose bulb, incompatible dimmer switch/bulbs, unstable power supply.	Tighten bulbs. Ensure dimmer and bulbs are compatible. Consult electrician if power supply is suspected.
Chandelier is unstable/wobbles	Mounting hardware not secure, junction box not properly reinforced.	Ensure mounting bracket and canopy are tightly secured. Verify junction box is rated for fixture weight.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Bella Depot customer support.

WARRANTY AND SUPPORT

Bella Depot products are manufactured with high-quality materials and craftsmanship. This product comes with a limited warranty covering defects in materials and workmanship. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Bella Depot website.

[Visit the Bella Depot Store on Amazon](#)