Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 643

Ariete 643 Party Time Ice Cream Maker Instruction Manual

Model: 643 | Brand: Ariete

1. Introduction

Welcome to the Ariete 643 Party Time Ice Cream Maker. This appliance is designed to help you prepare delicious homemade ice cream, sorbets, and frozen yogurt quickly and easily. Please read this manual carefully before first use to ensure safe and optimal operation. Keep this manual for future reference.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Do not immerse the motor unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils out of the freezer bowl during use to reduce the risk of injury to persons or to the appliance itself.
- Do not use sharp objects or metal utensils inside the freezer bowl.
- Ensure the voltage indicated on the appliance corresponds to your mains voltage before connecting.
- This appliance is for household use only.

3. Product Overview and Components

Familiarize yourself with the parts of your Ariete 643 Ice Cream Maker:



Image: All components of the Ariete 643 Ice Cream Maker laid out, including the motor unit, transparent lid, mixing paddle, and the main body with the freezer bowl.

1. **Motor Unit:** Contains the motor that drives the mixing paddle.
2. **Transparent Lid:** Allows you to observe the ice cream making process and has an opening for adding ingredients.
3. **Mixing Paddle:** Attaches to the motor unit and churns the ingredients.
4. **Double-Insulated Freezer Bowl:** Contains the coolant and must be pre-frozen.
5. **Main Body:** Houses the freezer bowl during operation.

4. Setup

Before first use, and for each batch of ice cream, follow these steps:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the freezer bowl, transparent lid, and mixing paddle in warm, soapy water. Rinse thoroughly and dry all parts completely. The motor unit should only be wiped with a damp cloth.
3. **Freeze the Bowl:** Place the double-insulated freezer bowl in the freezer for at least 24 hours. Ensure your freezer is set to -18°C (0°F) or colder. The bowl must be completely frozen for proper operation.

5. Operating Instructions

Follow these steps to prepare your homemade ice cream:

1. **Prepare Your Mixture:** Prepare your desired ice cream, sorbet, or frozen yogurt mixture. Ensure the mixture is chilled in the refrigerator before adding it to the machine.

2. **Assemble the Machine:**
    - Place the frozen freezer bowl into the main body of the ice cream maker.
    - Insert the mixing paddle into the motor unit.
    - Place the motor unit with the paddle onto the main body, ensuring the paddle sits correctly inside the freezer bowl.
    - Secure the transparent lid onto the motor unit.
3. **Start Churning:** Plug in the appliance. The mixing paddle will begin to rotate.
4. **Add Ingredients:** Slowly pour your chilled ice cream mixture through the opening in the transparent lid while the machine is churning. Do not overfill; the mixture will expand as it freezes.



Image: A hand pouring a pink liquid mixture into the ice cream maker through the lid opening, with other ingredients like berries and yogurt in the background.

5. **Churning Time:** Allow the machine to churn for approximately 20-30 minutes, or until the mixture reaches your desired consistency. The exact time may vary depending on the recipe and ambient temperature.
6. **Serve:** Once the ice cream is ready, unplug the appliance. Remove the motor unit and mixing paddle. Use a plastic or wooden utensil to scoop the ice cream from the freezer bowl. Avoid metal utensils to prevent scratching the bowl.



Image: The Ariete 643 Ice Cream Maker containing freshly churned pink ice cream, with several glass bowls of different flavored ice cream scoops and fresh fruits like bananas and strawberries arranged around it.

7. **Storage:** For firmer ice cream, transfer it to an airtight container and place it in the freezer for an additional 1-2 hours.

6. Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your ice cream maker:

- **Unplug:** Always unplug the appliance from the power outlet before cleaning.
- **Disassemble:** Disassemble all removable parts: the transparent lid, mixing paddle, and freezer bowl.
- **Wash Removable Parts:** Wash the lid, paddle, and freezer bowl in warm, soapy water. Rinse thoroughly and dry immediately. These parts are not dishwasher safe.
- **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water or any other liquid.
- **Storage:** Ensure all parts are completely dry before reassembling or storing the appliance. Store in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your Ariete 643 Ice Cream Maker, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet malfunction.	Ensure the appliance is securely plugged into a working power outlet.

Problem	Possible Cause	Solution
Ice cream is not freezing or is too soft.	Freezer bowl not frozen long enough; mixture not chilled; too much mixture.	Ensure the freezer bowl was frozen for at least 24 hours. Chill your mixture thoroughly before adding. Do not exceed the maximum capacity of the bowl.
Mixing paddle stops during operation.	Mixture is too thick; too much mixture.	Ensure your mixture is not excessively thick. Reduce the amount of mixture if overfilled.
Loud noise during operation.	Paddle not correctly seated; foreign object in bowl.	Unplug and check that the mixing paddle is correctly assembled. Ensure no foreign objects are in the bowl.

8. Technical Specifications

Brand	Ariete
Model Number	643
Power	12 Watts
Capacity	1.5 Liters
Voltage	230 Volts
Material	Aluminum
Product Dimensions (L x W x H)	22.5 x 22.5 x 25 cm
Item Weight	2.7 Kilograms
Special Feature	Removable double-insulated bowl with coolant
Operating Mode	Automatic

9. Warranty and Support

This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase or contact your retailer for specific warranty terms and conditions. For technical support or service inquiries, please contact Ariete customer service through their official website or the contact information provided in your purchase documentation. For more information, visit the official Ariete website.

© 2023 Ariete. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTHXKZBR

More documents and user manuals: **https://manuals.plus/**