

BANZAI Rapid Falls

Banzai Rapid Falls Water Slide Instruction Manual

MODEL: RAPID FALLS

Brand: BANZAI

Introduction

This instruction manual provides essential information for the safe and proper setup, operation, and maintenance of your Banzai Rapid Falls Water Slide. Please read all instructions carefully before assembly and use to ensure a fun and safe experience.

Safety Information

WARNING: Adult supervision is required at all times. This product is intended for outdoor domestic use only. Not for commercial use.

- Recommended Age: 5 - 12 years
- Maximum Weight Capacity: 150 lbs (combined user weight)
- Ensure the product is placed on a soft, level surface, free from sharp objects or debris.
- Keep children away from the air blower during operation.
- Do not allow users to slide headfirst. Always slide feet first.
- Ensure adequate clear space around the water slide to prevent collisions.
- The heavy-duty Dura-Tech construction is designed for lasting durability, but regular inspection for wear and tear is recommended.

Components

The Banzai Rapid Falls Water Slide comes with the following components:

- Inflatable Water Slide Unit (featuring dual waterslides, climbing wall, splash pool, water cannons, and waterfall splash arch)

- Air Blower with GFCI (Ground Fault Circuit Interrupter)
- Anchor Stakes
- Storage Bag
- Repair Kit



Figure 1: Key components of the Banzai Rapid Falls Water Slide.

Banzai

**INCLUDES
A BLOWER,
STORAGE BAG,
AND REPAIR KIT**



**FOR KIDS AGES
5-12 YEARS OLD;
SUPPORTS
UP TO 150 LBS.
COMBINED USER WEIGHT**

Figure 2: The air blower, storage bag, and repair kit included with the water slide.

Setup

1. **Site Selection:** Choose a flat, level area in your backyard, clear of any sharp objects, rocks, or debris. Ensure there is sufficient space around the inflatable for safe play.
2. **Unfold:** Carefully unroll and unfold the water slide unit on the chosen surface.
3. **Connect Blower:** Attach the air blower to the inflation tube of the water slide. Ensure the connection is secure.
4. **Inflate:** Plug the air blower into a GFCI-protected electrical outlet. The water slide will inflate in approximately 3 minutes. Ensure the blower runs continuously during use to maintain inflation.
5. **Secure:** Use the provided anchor stakes to firmly secure the water slide to the ground at all designated anchor points. This prevents movement during play.
6. **Water Connection:** Connect a standard garden hose to the water spray assembly on the water slide. Turn on the water supply to activate the sprinklers, water cannons, and waterfall arch.
7. **Fill Splash Pool:** Allow the splash pool area to fill with water to the recommended level before use.



Figure 3: Simple 3-step setup process for quick inflation.

Operating Instructions

Once fully inflated and secured, and the splash pool is filled, the Banzai Rapid Falls Water Slide is ready for use.

- **Climbing Wall:** Users can climb the integrated wall to access the top of the slides. Ensure hands and feet are used on the designated climbing holds.
- **Waterslides:** Slide down the dual waterslides feet first. Ensure the landing area (splash pool) is clear before sliding.
- **Splash Pool:** The large splash pool provides a safe landing area and a space for water play.
- **Water Cannons & Sprinklers:** The integrated water cannons and sprinklers provide continuous water flow for sliding and additional water play.

Maintenance

- **Cleaning:** After each use, drain all water from the splash pool. Wipe down all surfaces with a damp cloth and mild soap solution. Rinse thoroughly.
- **Drying:** It is crucial to thoroughly dry the entire water slide unit before storage to prevent mold and mildew growth. Keep the blower running for an extended period after draining water to help dry the internal surfaces. You may also need to air dry the exterior in direct sunlight.
- **Storage:** Once completely dry, deflate the unit. Fold or roll it neatly and place it into the provided storage bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Repairs:** Use the included repair kit for small punctures or tears. For larger damage, professional repair may be necessary.

Troubleshooting

Problem	Possible Cause	Solution
Water slide not fully inflating.	Blower not running, air leak, or inflation tube not securely attached.	Ensure blower is plugged in and running. Check all seams and the inflation tube connection for leaks.

Problem	Possible Cause	Solution
Water features not working.	Hose not connected, water supply off, or clogged nozzles.	Verify hose connection and water supply. Check water nozzles for blockages.
Unit moving during use.	Not properly anchored.	Ensure all anchor stakes are firmly in the ground at all designated points.

Specifications

Feature	Detail
Product Dimensions (L x W x H)	260" x 180" x 100" (21.7' L x 15' W x 8.3' H)
Weight	80 lbs
Recommended Age Range	5 - 12 years
Maximum Weight Recommendation	150 Pounds (combined)
Material	Heavy-duty Dura-Tech construction
UPC	191124038137
ASIN	B0BTJRKVLN



FITS PERFECTLY IN YOUR BACKYARD!

- 8.3' HIGH
- 15' WIDE
- 21.7' LONG

Figure 4: Dimensions of the Banzai Rapid Falls Water Slide.




Figure 5: Information on the durable construction and package contents.

Warranty and Support

For customer support, inquiries, or to address any issues with your Banzai Rapid Falls Water Slide, please refer to the contact information provided with your purchase documentation or visit the official BANZAI website. This product typically includes a 30-day easy return policy from the point of purchase. For additional assistance, you may contact customer support via the details provided by the seller, Spreetail.