

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [MANSCAPED](#) /

> [MANSCAPED The Weed Whacker 2.0 Electric Nose & Ear Hair Trimmer Instruction Manual](#)

MANSCAPED 30-00060

MANSCAPED The Weed Whacker 2.0 Electric Nose & Ear Hair Trimmer Instruction Manual

Model: 30-00060

INTRODUCTION

This manual provides essential information for the safe and effective use of your MANSCAPED The Weed Whacker 2.0 Electric Nose & Ear Hair Trimmer. Please read all instructions carefully before first use and retain for future reference.

IMPORTANT SAFETY INFORMATION

SkinSafe Technology does not guarantee cut protection.

This nose and ear hair trimmer can be used in wet and dry conditions. The rechargeable battery should be fully charged before first use. It is suitable for trimming nose and ear hair.

PRODUCT OVERVIEW



Image: The MANSCAPED The Weed Whacker 2.0 Electric Nose & Ear Hair Trimmer shown alongside its product packaging.

The MANSCAPED The Weed Whacker 2.0 is an electric nose and ear hair trimmer designed for precision grooming. Key features include:

- **Improved Stainless Steel Rotary Blade:** Provides a closer, easier cut, designed to miss fewer hairs.
- **7,000 RPM Motor:** Powers a 360° rotary dual-blade system for a clean and close cut without pulling.
- **USB-C Rechargeable Battery:** Offers up to 45 minutes of runtime for cordless operation.
- **Wet/Dry Use:** Can be used in the shower or rinsed under a faucet. Features a matte, rubberized grip for enhanced precision.
- **Tri-LED Indicator:** LEDs light up individually when the trimmer is on to show the charge level.



Wet or dry cycle

You can use it in the shower
or rinse it off under the faucet.

*IPX7 rated to protect against immersion in up to
one meter of fresh water for up to 30 minutes.

Image: The trimmer is shown being rinsed under running water, highlighting its wet/dry capability.

WHAT'S IN THE BOX

Your MANSAPED The Weed Whacker 2.0 package includes:

- The Weed Whacker 2.0 Trimmer
- USB-C Charging Cable
- Power Adapter
- Travel Pouch



Image: The Weed Whacker 2.0 trimmer, USB-C charging cable, and power adapter are displayed as the package contents.

SETUP

Initial Charge

Before using your Weed Whacker 2.0 for the first time, ensure it is fully charged. Connect the USB-C charging cable to the trimmer and the power adapter, then plug it into a wall outlet. The Tri-LED indicator will show the charging status.




Image: The Weed Whacker 2.0 is shown connected to its USB-C charging cable, illustrating the charging process.

Attaching/Detaching the Blade Head

To attach or detach the blade head for cleaning or replacement, gently twist the head counter-clockwise to remove, and clockwise to secure. Ensure it clicks into place.

Your browser does not support the video tag.

Video: This video demonstrates the process of removing and replacing the blade head on the Manscaped Weed Whacker for maintenance.

OPERATING INSTRUCTIONS

Trimming Nose Hair

1. Ensure the trimmer is charged and the blade head is securely attached.
2. Press the power button to turn on the device. The Tri-LED indicator will illuminate.
3. Gently insert the trimmer tip into your nostril. Move it slowly and carefully to trim unwanted hairs. Avoid inserting too deeply.
4. After trimming, turn off the device and clean the blade head as described in the Maintenance section.



Attract the right attention.

Make trimming your manholes with the Weed Whacker® 2.0 part of your essential grooming routine.



Image: A man is shown using the Weed Whacker 2.0 to carefully trim nose hair.

Trimming Ear Hair

1. Ensure the trimmer is charged and the blade head is securely attached.
2. Press the power button to turn on the device.
3. Carefully guide the trimmer tip around the outer ear and into the ear canal opening to trim visible hairs. Do not insert the trimmer deeply into the ear canal.
4. After trimming, turn off the device and clean the blade head.



Dual blades for hair duels.

A premium 7,000 RPM motor powers
our new 360° rotary dual-blade system.

Image: A man is shown using the Weed Whacker 2.0 to carefully trim ear hair.

Your browser does not support the video tag.

Video: This video provides a quick demonstration of the Manscaped Weed Whacker 2.0 in use for trimming nose hair.

MAINTENANCE

Cleaning the Blade Head

1. Turn off the trimmer.
2. Gently twist the blade head counter-clockwise to remove it from the trimmer body.
3. Rinse the detached blade head under running water to remove any trimmed hairs and debris.
4. Allow the blade head to air dry completely before reattaching it to the trimmer.
5. Wipe the trimmer body with a damp cloth if necessary. Do not submerge the entire trimmer body in water.

Electric Nose & Ear Hair Trimmer



SkinSafe®

Improved stainless steel rotary blade provides a closer cut, missing fewer hairs.



Dual-Blade

360° rotary dual-blade system so you experience no pulling.



USB-C

Up to 45 minutes of runtime.



Tri-LED Indicator

LEDs light up individually when the trimmer is on to show charge level.

*SkinSafe® technology does not assure cut protection.

*IPX7 rated to protect against immersion in up to one meter of fresh water for up to 30 minutes.

Image: A close-up view of the Weed Whacker 2.0's rotary blade head, showing its design for effective trimming.

Replacing the Blade

For optimal performance, it is recommended to replace the blade head every few months, or when you notice a decrease in cutting efficiency. Replacement blade heads are available from MANSCAPED.

TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the battery is fully charged.
- **Poor trimming performance:** Clean the blade head thoroughly. If performance does not improve, consider replacing the blade head.
- **Hair pulling:** Ensure the blade head is clean and not damaged. Use the trimmer slowly and gently.

SPECIFICATIONS

Feature	Detail
Model Number	30-00060

Power Source	Battery Powered (1 AAA battery included)
Motor Speed	7,000 RPM
Blade Type	Improved Stainless Steel Rotary Dual-Blade
Water Resistance	Wet/Dry Use (IPX7 rated)
Runtime	Up to 45 minutes
Color	Black
Item Weight	0.28 Kilograms

WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official MANSAPED website or contact their customer service. Keep your proof of purchase for any warranty claims.