



Manuals.plus /

› **Blaupunkt** /

› Blaupunkt BLP4969N Bluetooth In-Ear Headphones User Manual

Blaupunkt BLP4969-133

Blaupunkt BLP4969N Bluetooth In-Ear Headphones User Manual

Model: BLP4969-133

1. INTRODUCTION

Thank you for purchasing the Blaupunkt BLP4969N Bluetooth In-Ear Headphones. This manual provides essential information for setting up, operating, and maintaining your new headphones. Please read it carefully before use and retain it for future reference.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Blaupunkt BLP4969N Bluetooth In-Ear Headphones (Left and Right earbuds)
- Charging Case
- USB Charging Cable
- Ear Cushions (various sizes)
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Blaupunkt BLP4969N headphones.



Image 3.1: The Blaupunkt BLP4969N Bluetooth In-Ear Headphones shown with their charging case. The earbuds are black, sleek, and designed to fit comfortably in the ear. The charging case is also black, compact, and features a small indicator light on the front.



Image 3.2: This image displays the two black in-ear headphones placed outside their open charging case. The charging case reveals two molded compartments for the earbuds and a small red indicator light in the center, signifying charging status or power. The earbuds themselves have a stem design with silicone ear tips.



Image 3.3: A top-down view of the Blaupunkt BLP4969N earbuds securely seated within their open charging case. The earbuds are positioned vertically within their respective slots, and a red indicator light is visible on the front edge of the charging case, indicating its operational status.

4. SETUP

4.1 Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.

3. The indicator light on the charging case will illuminate to show charging status. A full charge for the case can take approximately 1 day. The earbuds will charge faster when placed in a charged case.
4. Once fully charged, disconnect the charging cable.

4.2 Bluetooth Pairing

To connect your headphones to a device:

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and an indicator light on the earbuds may flash.
3. On your device (e.g., smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices. You should see "Blaupunkt BLP4969N" or a similar name in the list.
5. Select the headphones to connect. Once paired, a confirmation sound may play, and the indicator light on the earbuds will stop flashing.
6. The headphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

5. OPERATING THE HEADPHONES

5.1 Basic Controls

The BLP4969N headphones feature touch controls for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Activate Voice Assistant:** Press and hold either earbud for 2 seconds.

5.2 Phone Calls

The built-in microphone allows for hands-free calling:

- **Answer Call:** Single tap on either earbud when a call comes in.
- **End Call:** Single tap on either earbud during a call.
- **Reject Call:** Press and hold either earbud for 2 seconds when a call comes in.

6. MAINTENANCE

6.1 Cleaning

To ensure optimal performance and hygiene:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

6.2 Storage

When not in use, store the headphones in their charging case to protect them from dust and damage.

7. TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common solutions:

- **No Sound:** Ensure headphones are charged and paired. Check volume levels on both headphones and the connected device.
- **Pairing Failure:** Make sure Bluetooth is enabled on your device. Turn off and on the device's Bluetooth. Try resetting the headphones by placing them in the case, closing it, and then reopening.
- **One Earbud Not Working:** Place both earbuds back into the charging case, close the lid for a few seconds, then open it and try again. Ensure both earbuds are charged.
- **Charging Issues:** Verify the charging cable is securely connected. Try a different USB port or power adapter. Ensure the charging contacts on the earbuds and in the case are clean.
- **Poor Audio Quality:** Ensure you are within the Bluetooth range of your device. Avoid obstacles between the device and headphones.

8. SPECIFICATIONS

Model Number	BLP4969-133
Connectivity	Bluetooth 5.3 (Wireless)
Ear Placement	In Ear
Form Factor	In Ear
Material	Plastic
Colour	Black/White
Battery Type	Lithium Ion (included)
Battery Capacity (Case)	250 mAh
Battery Life (Earbuds)	Approx. 3 hours
Charging Time (Case)	Approx. 1 day
Frequency Range	Approx. 20 Hz - 20,000 Hz
Item Weight	110 g (0.11 Kilograms)
Product Dimensions	9 x 3 x 13 cm
Water Resistance	Not Water Resistant
Compatible Devices	Cell Phone, Tablet, Laptop
Recommended Uses	Music, Calling, Video Games

9. SAFETY INFORMATION

Please observe the following safety guidelines:

- Do not expose the headphones or charging case to extreme temperatures, direct sunlight, or moisture.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the headphones yourself. This will void the warranty.
- Keep out of reach of children and pets.
- Prolonged listening at high volume levels can cause hearing damage. Adjust volume to a safe level.
- Do not use headphones in situations where inability to hear ambient sounds could be dangerous (e.g., driving, cycling, walking in traffic).

10. WARRANTY AND SUPPORT

Blaupunkt products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included in your package or visit the official Blaupunkt website. Please have your model number (BLP4969-133) and proof of purchase ready when contacting support.