

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Deolme](#) /
- › [Deolme 360 Swivel Accent Glider Rocking Chair User Manual](#)

Deolme Glider Chair

Deolme 360 Swivel Accent Glider Rocking Chair User Manual

Model: Glider Chair (B0BTLTTL9J)

INTRODUCTION

Thank you for choosing the Deolme 360 Swivel Accent Glider Rocking Chair. This manual provides essential information for the safe and effective use, assembly, and maintenance of your new chair. Please read it thoroughly before use and retain it for future reference.



Image: The Deolme 360 Swivel Accent Glider Rocking Chair, beige color, positioned in a modern living room with a side table and decor.

Multi-angle Display



Front View

Side View

Side View

Back View

Image: Various views of the chair, including front, side, and back, illustrating its design from multiple perspectives.

IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of **300 pounds**.
- Keep children and pets away from the chair during assembly.
- Avoid standing on the chair or using it as a step stool.
- Place the chair on a flat, stable surface to prevent tipping.

PRODUCT COMPONENTS

Before assembly, verify that all parts are present and undamaged. The chair typically includes:

- Chair Backrest
- Seat Base with Armrests
- Swivel/Glider Mechanism Base
- Cushion (integrated or separate)
- Assembly Hardware (bolts, washers, Allen wrench)



Image: Close-up details highlighting the high backrest for comfort, the squared armrests for pressure relief, and the convenient large side pocket for storage.

SETUP AND ASSEMBLY

Assembly of the Deolme Glider Chair is designed to be straightforward. It is recommended to have a second person assist during certain steps.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Base:** Secure the swivel/glider mechanism base to the bottom of the seat base using the provided hardware. Ensure all bolts are tightened firmly.
3. **Connect Backrest:** Align the backrest with the seat base and attach it using the designated bolts. Do not overtighten initially.
4. **Final Tightening:** Once all parts are loosely assembled, gradually tighten all bolts until secure. Do not force.

5. **Inspect:** Before first use, gently rock and swivel the chair to ensure stability and proper function.

OPERATING INSTRUCTIONS

The Deolme Glider Chair offers several comfort features:

- **360-Degree Swivel:** The chair is equipped with a robust metal base allowing for a full 360-degree rotation. Simply push off the floor with your feet to rotate to your desired position.
- **Gentle Gliding Motion:** The chair provides a smooth, back-and-forth gliding motion. Lean back and gently push with your feet to initiate the glide.
- **Side Pocket:** A convenient side pocket is integrated into the armrest for storing small items such as remote controls, magazines, or personal devices.

Gentle Gliding Motion

It makes you feel more comfortable, so you can be comfortable as you feed or rock your baby to sleep.



Image: Illustration demonstrating the 360-degree swivel capability of the chair, highlighting the strong metal base for support and stability.

Multi-angle display

360 Degree Club Chair, Leisure Arm



Image: Visual representation of the gentle gliding motion, indicating the smooth back-and-forth movement for enhanced comfort.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your chair:

- **Cleaning Fabric:** The linen material is durable and easy to clean. For minor spills, blot immediately with a clean, dry cloth. For tougher stains, use a mild fabric cleaner according to its instructions, testing on an inconspicuous area first.
- **Vacuuming:** Regularly vacuum the chair using an upholstery attachment to remove dust and debris.
- **Frame Care:** Periodically check all bolts and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading. Position the chair away from direct sun exposure.

TROUBLESHOOTING

If you encounter any issues with your Deolme Glider Chair, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not glide smoothly or makes noise.	Loose connections; debris in mechanism; uneven surface.	Check and tighten all assembly bolts. Inspect the gliding mechanism for obstructions and clear if found. Ensure the chair is on a flat, level surface.
Chair feels unstable or wobbly.	Loose hardware; uneven floor.	Re-tighten all assembly bolts. Adjust chair position or use floor levelers if applicable.
Swivel function is stiff.	Mechanism needs lubrication; debris.	Apply a silicone-based lubricant to the swivel mechanism (avoid oil-based lubricants). Check for and remove any debris.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Deolme
Model Name	Glider Chair
Color	Beige
Product Dimensions (D x W x H)	27.95"D x 27.95"W x 39.37"H
Maximum Weight Recommendation	300 Pounds
Item Weight	58.4 pounds
Material	Linen (Upholstery), Foam (Fill), Solid Wood/Polywood (Frame)
Special Feature	360 Swivel, Gliding Motion, Side Pocket, Durable
Room Type	Living Room, Nursery, Bedroom
ASIN	B0BTLTTL9J

360 Degree Swivel

Founded atop a posh 360-degree swivel pedestal base, this swivel chair allows you fast to move or change sitting position without leaving the seat.



Image: Detailed dimensional drawing of the chair, indicating height, width, and depth measurements in inches.

WARRANTY INFORMATION

Specific warranty details for the Deolme 360 Swivel Accent Glider Rocking Chair are not provided in this manual. For information regarding product warranty, please contact Deolme customer support directly or refer to the product packaging and purchase documentation.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Deolme customer service. Contact information can typically be found on the product packaging, the manufacturer's official website, or through your retailer.

For further assistance, you may visit the [Deolme brand page on Amazon](#).



© 2024 Deolme. All rights reserved.