

[Manuals.plus](#) /

› [Jabra](#) /

› Jabra Elite 4 Wireless Earbuds User Manual

Jabra Elite 4

Jabra Elite 4 Wireless Earbuds User Manual

Model: Elite 4 (100-99183700-98)

1. INTRODUCTION

Welcome to the user manual for your Jabra Elite 4 Wireless Earbuds. These earbuds are designed to provide a seamless audio experience for both work and leisure, featuring an ergonomic Danish design for all-day comfort. Key features include 4-microphone technology for clear calls, Active Noise Cancellation (ANC) to reduce background noise, and HearThrough technology to stay aware of your surroundings. Advanced connectivity options like Google Fast Pair, Microsoft Swift Pair, and Bluetooth Multipoint ensure easy pairing and device switching. The Elite 4 earbuds are also water and dust resistant, offering durability for various environments.



Image 1.1: Jabra Elite 4 Wireless Earbuds and Charging Case. The earbuds are dark grey, with the Jabra logo visible on each earbud and on the charging case.



Ganztägiger Tragekomfort. Perfekt für jeden Tag

Image 1.2: All-day wearing comfort. A user demonstrating the comfortable fit of the Jabra Elite 4 earbuds during daily activities.

2. SETUP

2.1. Package Contents

Your Jabra Elite 4 package includes the following items:

- Two Jabra Elite 4 in-ear earbuds
- One charging case
- One USB-C to USB-A charging cable
- Three sets of silicon EarGels (small, medium, large), with one medium set pre-installed on the earbuds



Jabra Elite 4 Earbuds, Ladecase, EarGels in 3 Größen & USB-C-Kabel

Image 2.1: Jabra Elite 4 package contents. This image displays all items included in the product box.

2.2. Charging

Before first use, fully charge your earbuds and charging case. The charging case provides additional battery life for your earbuds.

- Connect the USB-C cable to the charging case and a power source.
- A full charge for the case takes approximately 3.5 hours.
- A 10-minute fast charge provides up to 1 hour of earbud playback.

2.3. Fitting the Earbuds

For optimal sound quality and comfort, select the correct size of EarGels. Experiment with the three provided sizes (small, medium, large) to find the best fit for your ears. A good seal is crucial for effective Active Noise Cancellation.

2.4. Pairing

The Jabra Elite 4 offers multiple pairing options for convenience.

2.4.1. Standard Bluetooth Pairing

1. Remove the earbuds from the charging case. They will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings and select 'Jabra Elite 4' from the list of available devices.

3. Follow any on-screen prompts to complete the pairing.

2.4.2. Google Fast Pair (for Android devices)

For Android devices running OS 6.0 or higher, Fast Pair allows for quick and easy connection.

1. Ensure Bluetooth is enabled on your Android device.
2. Open the charging case with the earbuds inside, near your Android device.
3. A pop-up notification will appear on your device. Tap to connect.

2.4.3. Microsoft Swift Pair (for Windows PCs)

For Windows PCs running Windows 10 or higher, Swift Pair simplifies the connection process.

1. Ensure Bluetooth is enabled on your Windows PC.
2. Open the charging case with the earbuds inside, near your PC.
3. A notification will appear on your PC. Click 'Connect' to pair.



Verbinde dich schnell und einfach mit deinem Smartphone oder PC über **Fast Pair und Swift Pair***

*Fast Pair ist kompatibel mit Android™ 6.0 oder höher
Swift Pair ist kompatibel mit Windows 10 oder höher

Image 2.2: Fast Pair and Swift Pair connectivity. This image demonstrates the quick pairing process with compatible devices.

2.5. Bluetooth Multipoint

The Jabra Elite 4 supports Bluetooth Multipoint, allowing you to connect to two devices simultaneously. This enables seamless switching between, for example, your smartphone and your PC without needing

to re-pair.



Wechsle nahtlos zwischen deinen Endgeräten mit Bluetooth®-Multipoint

Image 2.3: Seamless device switching with Bluetooth Multipoint. The earbuds can maintain connection with two devices simultaneously.

3. OPERATING THE EARBUDS

3.1. Controls


The Jabra Elite 4 earbuds feature physical buttons and touch controls for managing audio, calls, and sound modes. Specific functions can be customized via the Jabra Sound+ app.

- **Music Playback:** Play/pause, skip tracks.
- **Call Management:** Answer/end calls, reject calls.
- **Voice Assistant:** Activate your device's voice assistant.
- **Volume Control:** Adjust volume directly from the earbuds.

3.2. Sound Modes: ANC and HearThrough

Manage your audio environment with Active Noise Cancellation (ANC) and HearThrough technology.

- **Active Noise Cancellation (ANC):** Reduces unwanted background noise, allowing you to focus on your audio or calls.
- **HearThrough:** Allows you to hear your surroundings without removing your earbuds, enhancing situational awareness.



Filtert Hintergrundgeräusche heraus dank **aktiver Geräuschunterdrückung (ANC)**

Image 3.1: Active Noise Cancellation (ANC). The earbuds effectively filter out background noise for an immersive experience.

3.3. Call Functions

The Jabra Elite 4 features 4-microphone technology for clear call quality, even in noisy environments.

- Microphones are strategically placed to pick up your voice while minimizing ambient sound.
- Voice control is also supported for managing calls.



Kannst du mich hören? Klar und deutlich. 4-Mikrofon-Technologie

Image 3.2: 4-Microphone Technology. Ensures clear and distinct voice transmission during calls.

3.4. Battery Management

The earbuds and charging case provide extended listening and talk time.

- Earbuds offer up to 5.5 hours of battery life with ANC activated.
- The charging case extends total battery life to up to 22 hours with ANC activated, or 28 hours with ANC deactivated.
- **Mono Mode:** Use a single earbud while the other charges, allowing for continuous use.



Insgesamt bis zu 22 Stunden Akkulaufzeit bei aktivierter ANC (28 Stunden bei deaktivierter ANC)

Image 3.3: Battery life indication. The charging case provides significant additional power for the earbuds.

4. MAINTENANCE

4.1. Cleaning

Regular cleaning helps maintain optimal performance and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove EarGels and clean them with mild soap and water, then dry thoroughly before reattaching.
- Avoid using harsh chemicals or abrasive materials.

4.2. Water and Dust Resistance

The Jabra Elite 4 earbuds are designed to be water and dust resistant, making them suitable for various conditions, including rain. However, they are not intended for submersion in water.

- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.
- The charging case is not water resistant.

5. TROUBLESHOOTING

If you encounter issues with your Jabra Elite 4 earbuds, try the following troubleshooting steps:

5.1. Connectivity Issues

- **Earbuds not connecting:** Ensure earbuds are charged and within range of your device. Try turning Bluetooth off and on again on your device.
- **Intermittent connection:** Move closer to your device and away from potential interference sources (e.g., Wi-Fi routers, other Bluetooth devices).
- **Unable to pair:** Delete 'Jabra Elite 4' from your device's Bluetooth list and attempt to pair again.

5.2. Sound Quality Issues

- **Low volume or poor sound:** Ensure EarGels are properly fitted to create a good seal. Clean any debris from the earbud speakers.
- **One earbud not working:** Ensure both earbuds are charged. Try resetting the earbuds by placing them in the charging case, closing the lid for a few seconds, then reopening. If the issue persists, a factory reset may be necessary (refer to the Jabra Sound+ app for instructions).

5.3. Battery Issues

- **Earbuds not charging:** Ensure the charging cable is securely connected and the power source is active. Clean the charging contacts on both the earbuds and the case.
- **Earbuds turning off unexpectedly:** Ensure earbuds are fully charged. If they power off after a period of inactivity, this may be a power-saving feature; check settings in the Jabra Sound+ app.

5.4. Call Quality Issues

- **Microphone not picking up voice clearly:** Ensure the microphones are not obstructed. Try adjusting the earbud position.
- **Echo or background noise during calls:** Ensure ANC or HearThrough settings are appropriate for your environment.

6. SPECIFICATIONS

Feature	Specification
Model Name	Elite 4
Model Number	100-99183700-98
Brand	Jabra
Connectivity Technology	Wireless (Bluetooth)

Ear Placement	In-Ear
Form Factor	In-Ear
Soundproofing	Active Noise Cancellation
Frequency Response	100 Hz (Note: Typically a range, this value is as provided)
Sensitivity	101 dB
Headphone Jack	No audio jack
Control Method	Touch, Voice Control
Special Features	Bluetooth Multipoint, 4 Microphones, Active Noise Cancellation, Google Fast Pair, Microsoft Swift Pair, Water Resistant, HearThrough Technology
Compatible Devices	Android Smartphones, PC Windows 10 or later
Battery Type	Lithium-ion (Rechargeable)
Earbud Battery Life	Up to 5.5 hours (with ANC)
Total Battery Life (with case)	Up to 22 hours (with ANC), 28 hours (without ANC)
Charging Time (Case)	Approx. 3.5 hours
Fast Charge	10 minutes for 1 hour playback
Water Resistance Level	Water and Dust Resistant
Material	Plastic
Item Weight	42.6 Grams
Color	Dark Grey

7. WARRANTY AND SUPPORT

7.1. Manufacturer's Warranty

The Jabra Elite 4 earbuds come with a **2-year manufacturer's warranty**. To activate and manage your warranty, product registration is required via the Jabra Sound+ app.

7.2. Jabra Sound+ App

The Jabra Sound+ app is your companion for the Elite 4 earbuds, offering:

- Product registration for warranty.
- Customization of sound profiles and controls.
- Firmware updates.
- Access to detailed user guides and troubleshooting tips.

For further assistance, please refer to the support section within the Jabra Sound+ app or visit the official Jabra support website.