

MASKO 1

MASKO High-Pressure Cleaner User Manual

MODEL: 1

Brand: MASKO

1. INTRODUCTION

Thank you for choosing the MASKO High-Pressure Cleaner. This powerful 2200 Watt unit, with a maximum pressure of 165 bar and a flow rate of 450 liters per hour, is designed for efficient and environmentally friendly cleaning of various surfaces. From facades and driveways to patios and vehicles, this high-pressure cleaner provides excellent results with minimal effort. This manual provides essential information for safe operation, assembly, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

2. IMPORTANT SAFETY INSTRUCTIONS

Always observe the following safety precautions to prevent injury or damage to the device:

- Read the entire manual before operating the high-pressure cleaner.
- Ensure the power supply matches the specifications on the product label.
- Always wear appropriate personal protective equipment, including safety glasses and gloves, when operating the device.
- Do not direct the water jet at people, animals, electrical equipment, or the device itself.
- Keep children and pets away from the operating area. The device is equipped with a child safety lock for added protection.
- Never operate the high-pressure cleaner with damaged cables, hoses, or connections.

- Disconnect the power plug from the socket before performing any cleaning, maintenance, or when the device is not in use.
- Ensure adequate ventilation during operation to prevent overheating.

3. PACKAGE CONTENTS

Please check that all items are present and undamaged:

- MASKO High-Pressure Cleaner Unit
- High-Pressure Gun with Quick Release
- 10-meter High-Pressure Hose
- 5-meter Power Cable
- Adjustable Fan Jet Nozzle
- Point Jet Nozzle
- Soap Dispenser / Foam Sprayer
- Car Wash Brush
- Pipe Cleaning Hose (10 meters)
- Floor Brush
- Protective Gloves



Image: The MASKO High-Pressure Cleaner unit shown with its comprehensive 9-piece accessory set, including the high-pressure gun, various nozzles, brushes, soap dispenser, and protective gloves.

4. SETUP AND ASSEMBLY

4.1 Unpacking

Carefully remove all components from the packaging. Keep the packaging for future storage or transport.

4.2 Connecting Water Supply

1. Connect a garden hose (not included) to the water inlet on the high-pressure cleaner.
2. Ensure the water supply is clean and free of debris. A filter may be required for dirty water sources.
3. Turn on the water supply to allow water to flow through the unit before starting the motor.

4.3 Attaching High-Pressure Hose and Gun

1. Unwind the 10-meter high-pressure hose from the integrated hose reel.
2. Connect one end of the high-pressure hose to the high-pressure outlet on the unit.
3. Connect the other end of the high-pressure hose to the high-pressure gun. Ensure all connections are secure to prevent leaks.
4. Attach the desired nozzle or accessory (e.g., adjustable fan jet nozzle, foam sprayer) to the high-pressure gun using the quick-release mechanism.



Image: A detailed diagram illustrating the high-pressure gun with quick-release, wash brush, soap dispenser, various nozzles, pipe cleaning hose, car wash brush, and child safety lock, showing how they connect.

4.4 Connecting Power

Plug the 5-meter power cable into a suitable grounded electrical outlet. Ensure the outlet meets the power requirements of the device.

5. OPERATING INSTRUCTIONS

5.1 General Operation

1. After connecting water and power, turn on the main power switch on the unit.
2. Press the trigger on the high-pressure gun to start the water flow and motor. The motor will automatically stop when the trigger is released (Auto-Stop function).
3. Always start cleaning from a safe distance and gradually move closer to the surface, adjusting the spray pattern as needed.

5.2 Using Different Nozzles and Attachments

- **Adjustable Fan Jet Nozzle:** This nozzle allows you to vary the spray strength from a wide fan for gentle cleaning to a concentrated stream for stubborn dirt. Simply twist the nozzle to adjust.
- **Point Jet Nozzle:** Provides a powerful, concentrated stream for extremely tough dirt and specific spot cleaning. Use with caution on delicate surfaces.
- **Soap Dispenser / Foam Sprayer:** Fill with appropriate cleaning detergent. Attach to the gun to apply soap foam for car washing or other cleaning tasks.
- **Car Wash Brush:** Ideal for manual car washing in conjunction with the soap dispenser, providing a gentle yet effective clean.
- **Pipe Cleaning Hose:** The 10-meter pipe cleaning hose is designed to effectively clear blockages in pipes without the need for harsh chemicals.
- **Floor Brush:** Perfect for cleaning large flat surfaces like patios and balconies, ensuring a thorough and splash-free result.
- **360° Swivel Angle Nozzle:** Provides access to hard-to-reach areas, offering flexibility for comprehensive cleaning.

KINDERSICHERUNG

Für den Schutz für Ihre Kinder gibt es eine extra Sicherung, damit Ihre Kinder durch den Hochdruck unverletzt bleiben.



VERÄNDERBARE STRAHLDÜSE

Ändern Sie je nach Wunsch zwischen den verschiedenen Stärken der Strahldüse.



VIELE ANSCHLUSSMÖGLICHKEITEN

MASKO macht den vollen Waschgang möglich. Vom Seifenspender bis zum Druckpistolenrohr mit Schnellverschluss.



ZUBEHÖRFACH

Stauen Sie die verschiedenen Zubehöre einfach am Hochdruckreiniger selbst.

Image: This image highlights the child safety lock for secure operation, the adjustable fan jet nozzle with settings for maximum, medium, minimum, and point spray, and the integrated accessory compartment for convenient storage.



MASKO[®]

VIELSEITIG EINSETZBAR

Für ein zielgenaues entfernen des Schmutzes zur Verwendung auf Terrassen, Grills, Rohre, diversen Oberflächen wie Fliesen, Metall, Stein, Holz, Möbeln und Autos mit Seifenspender Schaumprüher.

Image: A collage demonstrating the versatile applications of the high-pressure cleaner, including cleaning fences, house walls, patios, and vehicles with the foam sprayer.

5.3 Optimal Reach

With the 10-meter high-pressure hose and a 5-meter power cable, the MASKO High-Pressure Cleaner offers an impressive total working range of up to 30 meters, allowing you to reach distant areas without constantly moving the unit. The two plastic wheels provide excellent mobility.



Image: This graphic visually represents the extensive 30-meter reach achieved by combining the 10-meter high-pressure hose and the 5-meter power cable.

6. MAINTENANCE AND STORAGE

6.1 Cleaning the Unit

- After each use, disconnect the power and water supply.
- Release any remaining pressure in the system by pressing the trigger on the gun.
- Clean the exterior of the unit with a damp cloth. Do not use abrasive cleaners or solvents.
- Rinse any detergent residue from the soap dispenser and nozzles.

6.2 Hose Management

The integrated hose reel is designed for convenient storage of the high-pressure hose. After use, carefully wind the hose back onto the reel. This helps prevent kinks and extends the life of the hose.

6.3 Winter Storage

If storing the high-pressure cleaner in an area where temperatures may drop below freezing, it is crucial to drain all water from the pump and hoses to prevent damage from freezing. Run an anti-freeze solution through the pump if necessary, following the solution manufacturer's instructions.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No pressure or low pressure	Insufficient water supply; Air in the pump; Clogged nozzle; Kinked hose	Ensure water tap is fully open; Bleed air by running water through the gun without power; Clean or replace nozzle; Straighten hose
Motor not starting	No power supply; Thermal overload activated; Faulty switch	Check power connection and outlet; Allow motor to cool down; Contact customer support
Water leaks	Loose connections; Damaged O-rings or seals; Cracked hose	Tighten all connections; Replace worn O-rings/seals; Replace damaged hose
Pulsating pressure	Air in the pump; Insufficient water supply; Clogged inlet filter	Bleed air from the pump; Ensure adequate water flow; Clean inlet filter

8. TECHNICAL SPECIFICATIONS

Specification	Value
Brand	MASKO
Model Number	1
Maximum Pressure	165 Bar
Maximum Flow Rate	450 Liters per Hour
Power	2200 Watt

Specification	Value
Hose Length	10 Meters
Power Cable Length	5 Meters
Product Dimensions (L x W x H)	37L x 43B x 132H cm
Weight	14.5 Kilograms
Water Temperature Range	5-60°C
Protection Class	IPX5 (against jet water from any angle)
Certifications	CE

MASKO[®]

EIGENSCHAFTEN

- MAX. DRUCK:** 165 BAR
- MAX. FÖRDERMENGE:** 450 L/H
- LEISTUNG:** 2200 WATT
- WASSEITEMPERATUR:** 5 ~ 50°C
- HOCHDRUCKSCHLAUCH:** 10 METER
- KABELLÄNGE:** 5 METER
- GEWICHT:** 10,7 KG
- IPX5** GEGEN STRAHLOWASSER AUS BELIEBIGEM WINKEL
- KINDERSICHERUNG**

INKL. HANDSCHUHE

Image: The MASKO High-Pressure Cleaner unit displayed alongside a list of its key technical specifications, including max pressure, flow rate, power, water temperature, hose length, cable length, weight, and IPX5 rating.



ABMESSUNGEN

Höhe / cm: 132
 Breite / cm: 43,5
 Tiefe / cm: 37

Schlauchlänge / m: 10
 Druck / bar: 165
 Leistung / Watt: 2200



Image: A visual representation of the MASKO High-Pressure Cleaner's dimensions, showing its height (132 cm), width (43.5 cm), and depth (37 cm).

9. WARRANTY AND SUPPORT

MASKO products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.

For technical support, spare parts, or warranty claims, please contact MASKO customer service. Contact information can typically be found on the product packaging, the official MASKO website, or your purchase receipt.

Please have your model number (1) and purchase date ready when contacting support to ensure efficient service.

