Disney TR447GNT

Disney Baby Simple Fold LX Travel System Instruction Manual

Model: TR447GNT

Product Overview

The Disney Baby Simple Fold LX Travel System offers a convenient and secure solution for transporting your child. This system includes a lightweight stroller and a compatible infant car seat, designed for ease of use and child comfort.

The stroller features a one-hand lift-to-fold mechanism, allowing for compact storage and self-standing capability when folded. It is equipped with large wheels for improved maneuverability and flip-flop friendly brakes for secure stopping. The multi-panel sun canopy includes a peekaboo window for easy viewing of your child.

The included infant car seat is designed for rear-facing use, accommodating infants from 4 to 35 pounds and up to 32 inches. It features Side Impact Protection and a 5-point harness system for enhanced safety. The QuickClick® system ensures secure attachment of the car seat to the stroller.



Figure 1: The Disney Baby Simple Fold LX Travel System, featuring the stroller and infant car seat.

Safety Information

Always read and understand all instructions before using the travel system. Failure to follow these instructions could result in serious injury or death.

- **Never leave child unattended:** Always keep your child in view when using the stroller or car seat.
- **Harness Use:** Always secure your child with the 5-point harness in both the stroller and car seat. Ensure straps are snug and not twisted.
- **Weight and Height Limits:** Do not exceed the maximum weight and height limits for the car seat (4-35 lbs, 32 inches) and stroller (up to 50 lbs).
- **Brakes:** Always engage the stroller brakes when stationary.
- **Folding/Unfolding:** Keep children clear of the stroller when folding or unfolding to prevent pinching or injury.
- **Car Seat Installation:** Ensure the car seat is correctly installed in your vehicle according to the car seat manual and vehicle owner's manual.

- **Side Impact Protection:** The car seat is designed with Side Impact Protection for enhanced safety in side-impact collisions.

Assembly and Setup

Stroller Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify all components are present according to the packing list.
2. **Unfold Stroller:** Place the stroller on a flat surface. Release any locking mechanisms and lift the handle until the stroller frame locks into the open position. Ensure all latches are securely engaged.
3. **Attach Wheels:** Insert the front and rear wheels into their respective slots until they click securely into place. Pull on the wheels to ensure they are firmly attached.
4. **Install Parent Tray:** Align the parent tray with the designated attachment points on the stroller handle and press down firmly until it locks.
5. **Install Child Snack Tray:** Attach the child snack tray to the front of the stroller seat by aligning the connectors and pushing until they click.





Figure 2: Front view of the stroller, showing the parent and child trays.



Figure 3: Detailed view of the parent tray, featuring two cup holders and a central storage compartment.

Car Seat Setup

1. **Harness Adjustment:** Adjust the 5-point harness to fit your child snugly. Ensure the shoulder straps are at or below the child's shoulders when rear-facing.
2. **Infant Insert:** For smaller infants, use the provided infant insert for additional padding and support.
3. **Car Seat Base Installation:** Install the car seat base in your vehicle using either the LATCH system or the vehicle's seat belt, following the detailed instructions in the car seat manual. Ensure the base is level and secure.



Figure 4: The infant car seat highlighting its Side Impact Protection features.

Operating Instructions

Using the Stroller

- **Folding the Stroller:** To fold, locate the one-hand lift-to-fold mechanism (typically a strap or handle in the seat). Pull upward firmly. The stroller will fold compactly and stand on its own.
- **Unfolding the Stroller:** Release the storage latch, then lift the handle until the stroller clicks into the open position.
- **Engaging Brakes:** Press down on the rear wheel brakes with your foot until they lock. These brakes are designed to be flip-flop friendly.
- **Reclining the Seat:** Adjust the stroller seat to multiple recline positions using the recline mechanism located behind the seat.
- **Canopy Adjustment:** Extend or retract the multi-panel sun canopy as needed. Use the peekaboo window to check on your child without disturbing them.
- **Storage Basket:** Utilize the large, easy-access storage basket located underneath the seat for carrying essentials.



Figure 5: The stroller being folded compactly with one hand, demonstrating its self-standing feature.



Figure 6: The stroller's canopy, featuring a clear peekaboo window for easy child monitoring.

Using the Car Seat with Stroller (Travel System)

- **Attaching Car Seat:** Ensure the stroller is fully unfolded and locked. Place the infant car seat onto the stroller frame, aligning the QuickClick® connectors. Press down firmly until you hear a click, indicating a secure attachment.
- **Detaching Car Seat:** Locate the car seat release lever (usually at the back of the car seat). Squeeze or lift the lever while lifting the car seat off the stroller frame.

Your browser does not support the video tag.

Video 1: Demonstrates the features of the Disney Baby Simple Fold LX Travel System, including the QuickClick® car seat attachment.

Maintenance

- **Cleaning Fabric:** The car seat pad is machine-washable. Refer to the care label for specific washing instructions. Stroller fabrics can be spot cleaned with mild soap and warm water.
- **Cleaning Frame:** Wipe the stroller and car seat frames with a soft, damp cloth. Avoid abrasive cleaners.

- **Wheel Maintenance:** Periodically check wheels for debris and clean as necessary. Lubricate moving parts with a silicone-based lubricant if needed.
- **Storage:** Store the travel system in a clean, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Stroller will not fold/unfold	Locking mechanism engaged; debris in folding mechanism.	Ensure all locks are disengaged. Check for and remove any obstructions.
Car seat not securely attaching to stroller	Incorrect alignment; QuickClick® connectors not fully engaged.	Re-align car seat with stroller connectors. Press down firmly until a click is heard.
Stroller wheels squeak or are difficult to maneuver	Dirt/debris in wheels; lack of lubrication.	Clean wheels and axles. Apply a silicone-based lubricant to moving parts.
Harness straps are difficult to adjust	Straps are twisted or caught.	Untwist straps and ensure they move freely through the slots.

Specifications

Brand: Disney

Model Number: TR447GNT

UPC: 884392953096

Color: Mickey Blogger

Material: Polyester

Stroller Maximum Weight: 50 Pounds

Car Seat Age/Weight Range: Rear-facing from 4-35 Pounds, up to 32 inches

Harness Type: 5-Point (Stroller and Car Seat)

Item Height: 19 inches (Stroller)

Manufacturer: Dorel Juvenile Group

Warranty and Support

For warranty information, product registration, or customer support, please contact Dorel Juvenile Group directly. Keep your proof of purchase and model number (TR447GNT) readily available when contacting support.

Manufacturer: Dorel Juvenile Group

Please refer to the official Disney Baby website or the Dorel Juvenile Group website for the most up-to-date contact information and warranty details.

© 2025 Disney Baby. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question