



Manuals.plus /

› MYW-Tech /

› MYW-Tech AC DC Adapter User Manual for Sharper Image 1014508 Massager

## MYW-Tech AC DC Adapter for Sharper Image 1014508

# MYW-Tech AC DC Adapter User Manual

Compatible Replacement for Sharper Image 1014508 Deep Tissue Shiatsu Massager

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your MYW-Tech AC DC Adapter. This adapter is specifically designed as a compatible replacement power supply for the Sharper Image 1014508 Deep Tissue Shiatsu Massager. Please read this manual thoroughly before use to ensure proper operation and to prevent damage to the adapter or your device.

## 2. PRODUCT OVERVIEW

---

The MYW-Tech AC DC Adapter is a high-quality power supply designed to provide reliable power to your compatible device. It features a durable construction and incorporates multiple safety protections.




Figure 2.1: Overview of the MYW-Tech AC DC Adapter, showing the main unit, power cord, and output connector.

#### Key Features:

- **Compatibility:** Specifically designed for Sharper Image 1014508 Deep Tissue Shiatsu Massager. *(Note: Not compatible with other models.)*
- **Input Voltage:** Supports 100V - 240V worldwide, making it suitable for international travel with appropriate plug adapters.
- **Safety Protections:** Equipped with Over Voltage Output Protection, Over Current Output Protection, and Short Circuit Output Protection to ensure safe operation.
- **Cable Length:** Features a 7-foot long power cord for flexible placement.
- **LED Indicator:** Includes an LED indicator to show power status.



Figure 2.2: Detailed view of the adapter's label, indicating MYW-Tech branding, input specifications, and safety certifications.



**Figure 2.3:** Visual representation emphasizing the 7-foot cable length and the presence of an LED indicator on the adapter.

### 3. SETUP

---

Follow these steps to set up your MYW-Tech AC DC Adapter:

1. **Verify Compatibility:** Ensure your device is the Sharper Image 1014508 Deep Tissue Shiatsu Massager. This adapter is **NOT** compatible with other models.
2. **Connect to Device:** Insert the output connector of the MYW-Tech adapter firmly into the power input port of your Sharper Image 1014508 massager.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard 100V-240V wall power outlet.
4. **Power On:** Once connected, the LED indicator on the adapter should illuminate, indicating that power is being supplied. You can now operate your massager according to its own instructions.

**Important Safety Note:**

- Do not force the connector into the device's port.
- Ensure the power outlet is easily accessible for quick disconnection if needed.
- Avoid using the adapter in wet or damp conditions.

### 4. OPERATING INSTRUCTIONS

---

The MYW-Tech AC DC Adapter operates automatically once connected to a power source and a compatible device. Its primary function is to convert AC wall power to the DC power required by your Sharper Image 1014508 massager.

- The adapter will provide continuous power as long as it is plugged into a live outlet and connected to the massager.
- The LED indicator will confirm that the adapter is receiving power and is operational.
- To disconnect power, simply unplug the adapter from the wall outlet first, then disconnect from the massager.

### 5. MAINTENANCE

---

Proper care will extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly winding the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires, cracks, or loose connections. If damage is found, discontinue use immediately.

### 6. TROUBLESHOOTING

---

If you encounter issues with your MYW-Tech AC DC Adapter, refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Adapter LED is off, device not powering on.	No power from outlet; loose connection; incompatible device.	Check if the wall outlet is working (test with another device). Ensure adapter is fully plugged into both the outlet and the massager. Confirm your device is the Sharper Image 1014508.
Device powers on intermittently or not stably.	Loose connection; damaged cable/adapter.	Ensure all connections are secure. Inspect the cable and adapter for visible damage. If damaged, discontinue use and replace.
Adapter feels unusually hot.	Overload; poor ventilation; internal fault.	Unplug immediately. Ensure the adapter is not covered and has adequate ventilation. If it continues to overheat, discontinue use.

If the problem persists after trying these solutions, please contact MYW-Tech customer support for further assistance.

## 7. SPECIFICATIONS

Attribute	Detail
Brand	MYW-Tech
Model Compatibility	Sharper Image 1014508 (NOT fit other models)
Input Voltage	100V - 240V AC
Connector Type	Proprietary
Cable Length	7 feet
Color	Black
Special Feature	Short Circuit Protection
Product Dimensions	4 x 2 x 2 inches
Item Weight	5 ounces
Included Components	1 x AC Adapter

## 8. WARRANTY AND SUPPORT

MYW-Tech is committed to providing high-quality products. While specific warranty details are not provided in this manual, please note the following:

- **Return Policy:** This product typically comes with a 30-day return policy from the date of purchase. Please refer to your purchase platform's return guidelines for specific terms and conditions.
- **Customer Support:** For any questions, technical assistance, or issues not covered in this manual, please contact the seller or MYW-Tech customer support through the platform where you purchased

the product.