

[Manuals.plus](#) /

> [eXtremeRate](#) /

> eXtremeRate RISE Remap Kit for PS5 Controller Instruction Manual

eXtremeRate XPFP3042G3

eXtremeRate RISE Remap Kit Instruction Manual

Model: XPFP3042G3

Brand: eXtremeRate

1. INTRODUCTION

The eXtremeRate RISE Remap Kit transforms your standard PS5 controller (BDM-030, BDM-040, BDM-050 models) into a professional eSport elite controller by adding two ergonomic, programmable back buttons. This kit allows you to remap up to 15 different controller buttons to the new back paddles, providing a significant advantage in gameplay. Please note that the PS5 controller itself is not included with this kit.



Image: PS5 controller with the eXtremeRate RISE Remap Kit installed, featuring textured red back paddles.

2. PACKAGE CONTENTS

The eXtremeRate RISE Remap Kit includes all necessary components for installation:

- RISE Remap Board
- Redesigned Back Shell (Textured Red)
- 2 Back Buttons Attachment
- FPC cables (for connection)
- Screws and tools for installation
- Spare parts (e.g., rubber pads)



Image: Contents of the eXtremeRate RISE Remap Kit, showing all parts required for the modification.

3. CONTROLLER COMPATIBILITY

This kit is specifically designed for PS5 controllers with board models BDM-030, BDM-040, and BDM-050. It is NOT compatible with BDM-010 or BDM-020 models. Verifying your controller's BDM model is crucial before installation to ensure proper fit and function.


How to Check Your BDM Model:

You can determine your controller's BDM model by connecting it to a PC using a data cable and visiting the eXtremeRate BDM check tool online. Alternatively, you can visually inspect the internal components of your controller. Refer to the image and video below for guidance.

Compatibility: BDM-030 ✓ BDM-040 ✓ BDM-050 ✓

eXtremeRate-How to Check Your Controller BDM-Model

1  extremeerate check controller bdm



3 **Check Your Controller BDM Model**
JULY 22, 2024
[Share](#)
Connect your controller to your PC with USB cable and press CHECK

CHECK

4 Click [Connect] to check the controller BDM model

Wireless Controller

Connect

Cancel

5 **Check Your Controller BDM Model**
JULY 22, 2024 [Share](#)

Disconnect

Controller info

Your Controller BDM Model **BDM-???**

Image: Visual guide for identifying compatible PS5 controller BDM models.

Your browser does not support the video tag.

Video: A detailed guide on how to check the BDM model of your PS5 controller to ensure compatibility with the kit.

4. SETUP AND INSTALLATION

Installation of the RISE Remap Kit requires high hands-on skills due to the intricate nature of controller disassembly and reassembly. Soldering is optional, depending on whether you wish to remap the L3, R3, or Touchpad buttons. It is highly recommended to watch the official installation video before attempting the process.

For a comprehensive installation guide, search for "eXtremeRate RISE Remap Kit for PS5 BDM-030" or "ifSt9uYggII" on YouTube.



BDM-030&040



Image: Detailed view of the internal components for BDM-030 and BDM-040 models.



Image: Internal view of the controller with the remap board and paddle attachment.

5. OPERATING INSTRUCTIONS (BUTTON REMAPPING)

The RISE Remap Kit allows you to assign up to 15 different controller buttons to the two back paddles. These include X, O, Triangle, Square, Up, Down, Left, Right, L1, L2, R1, R2, L3, R3, and Touchpad Button.

Remapping Process:

1. Enter Programming Mode: Press and hold the Setting Button (located on the back attachment) for 3 seconds until the LED Indicator blinks.
2. Select Button to Remap: Press the button on the controller you wish to remap (e.g., X button).
3. Assign to Paddle: Press the back paddle you want to assign the selected button to.
4. Exit Programming Mode: Press the Setting Button again to save the changes and exit programming mode. The LED Indicator will turn off.

You can clear all remapped settings by holding the Setting Button for 5 seconds until the LED Indicator blinks rapidly, then release. The settings will revert to default.



**15 buttons can be assigned to the back buttons:
X, O, Triangle, Square, Up, Down, Left, Right, L1,
L2, R1, R2, L3, R3 and Touchpad Button**

Image: Overview of remappable buttons for the kit.



Image: Key features on the back attachment: LED Indicator, Setting Button, and Back Buttons.

Your browser does not support the video tag.

Video: Demonstration of the eXtremeRate RISE Remap Kit in use during gameplay, highlighting the functionality of the back paddles.

6. MAINTENANCE

To maintain the cleanliness and longevity of your eXtremeRate RISE Remap Kit's plastic components, follow these guidelines:

- Clean with a wipe dampened with less than 70% alcohol.
- Place in a well-ventilated area to dry thoroughly after cleaning.
- Do not spray water or alcohol directly onto the product surface.
- Avoid using any other organic solvents for cleaning, as they may damage the material.



Image: Recommended cleaning procedure for plastic components.

7. TROUBLESHOOTING

If you encounter issues during or after installation, consider the following common troubleshooting steps:

- **Incorrect BDM Model:** Ensure your PS5 controller is one of the compatible BDM-030, BDM-040, or BDM-050 models. Incompatible models will not work.
- **Loose Connections:** Double-check all FPC cable connections to the remap board and controller. Ensure they are securely seated.
- **Improper Assembly:** Review the installation video carefully to ensure all components are assembled correctly and no wires are pinched.
- **Soldering Issues (if applicable):** If you opted for soldering, ensure all solder points are clean and strong. Cold solder joints can cause intermittent issues.
- **Button Not Responding:** Verify that the remapping process was completed correctly. Try re-programming the button.

For further assistance, please refer to the official eXtremeRate support resources or contact customer service.

8. SPECIFICATIONS

Model Number	XFPF3042G3
Product Dimensions	6.1 x 3.54 x 0.59 inches
Item Weight	1.06 ounces
Manufacturer	Extremerate
Country of Origin	China
Compatible Controller Models	PS5 Controller BDM-030, BDM-040, BDM-050

9. WARRANTY AND SUPPORT

eXtremeRate products are designed for quality and performance. For information regarding product warranty, technical support, or to explore other eXtremeRate accessories, please visit the official eXtremeRate store or contact their customer service directly.

Visit the [eXtremeRate Store](#) for more products and support.