

## NOBLEMOOD LY-2009

# NOBLEMOOD 3-Seat Patio Porch Swing

MODEL: LY-2009 - INSTRUCTION MANUAL

## 1. Introduction

---

Thank you for choosing the NOBLEMOOD 3-Seat Patio Porch Swing. This manual provides essential information for the safe assembly, operation, and maintenance of your product. Please read all instructions carefully before assembly and retain this manual for future reference.

### Safety Guidelines

- Ensure all components are present and undamaged before beginning assembly.
- Assembly should be performed by adults. Two people are recommended for easier and safer assembly.
- Do not exceed the maximum weight capacity of 660 lbs (300 kg).
- Place the swing on a flat, stable surface.
- Regularly inspect all bolts and nuts to ensure they remain tight.
- During strong winds or adverse weather conditions, remove the canopy and cushions, or secure the swing to prevent damage or injury.

## 2. Product Features

---


- **Adjustable Canopy:** The canopy can be adjusted within 45 degrees to provide optimal shade and protection from UV rays and light rain.



Image: The adjustable canopy provides shade, protecting users from sun and light rain.

- **Foldable Storage Tray:** Equipped with side trays for convenient storage of beverages, mobile phones, or other small items. The trays are foldable to save space when not in use.

# Immerse yourself in a sea of knowledge



Thick Cushion



Side Tray



Image: A close-up view of the side tray, designed to hold drinks and small items.

- **2-in-1 Convertible Seat:** The swing can be quickly converted into a flat bed by adjusting the backrest. Includes a round pillow for added comfort when lying down.

# 2 In 1 Convertible Seat

Quick lock and release system  
easily turns swing into swing bed



Adjustable




Easy to convert




Weight capacity

Image: The swing easily converts into a comfortable bed for relaxation.

- **Waterproof Fabric and Removable Cushions:** The canopy and seat cushions are made from high-quality waterproof fabric, resistant to fading from sun exposure. Cushions are removable for cleaning. Avoid prolonged soaking in rain.



**Waterproof Fabric**



**Cylindrical Pillow**

Image: The waterproof fabric ensures durability and easy maintenance.

- **High Strength Spring Hook:** Designed for safe and quiet swinging.

### 3. Setup and Assembly

Please follow the included graphical instructions for detailed step-by-step assembly. Ensure all parts are identified and laid out before starting. Two adults are recommended for assembly.

#### Assembly Tips:

- Organize all hardware and components according to the parts list.
- Do not fully tighten bolts until all components are loosely assembled, then tighten securely.
- Pay close attention to part labels, especially for similar-looking components. For example, ensure correct placement of 'K' and 'K1' rods if applicable, as incorrect placement can lead to imbalance.

#### Assembly Video:

Your browser does not support the video tag.

Video: Official NOBLEMOOD product video demonstrating the assembly process and key features of the patio porch swing.

### 4. Operating Instructions

## Adjusting the Canopy:

To adjust the canopy, locate the adjustment knobs on either side of the canopy frame. Loosen the knobs, position the canopy to your desired angle (up to 45 degrees), and then tighten the knobs to secure it in place.

## Converting to a Swing Bed:

To convert the swing into a bed, locate the locking mechanism on the side of the swing seat. Release the mechanism and gently push the backrest down until it lies flat, forming a bed surface. Ensure it locks securely in the flat position before use. To return to the upright swing position, reverse the process, ensuring the backrest locks into place.

## Using the Foldable Side Trays:

The side trays are located on the outer frame of the swing. To use, simply pull the tray outwards until it clicks into its open position. To fold it back, gently push it inwards until it is flush with the frame.

## 5. Maintenance and Care

---

### Cleaning:

- **Frame:** Clean the metal frame with a mild soap and water solution. Rinse thoroughly and dry completely to prevent rust.
- **Cushions and Canopy:** Spot clean with a mild soap and water solution. For deeper cleaning, the cushions are removable. Allow them to air dry completely before reattaching or storing. Do not machine wash or tumble dry.

### Storage:

- During off-season or prolonged periods of non-use, store cushions and canopy indoors in a dry place.
- Consider using a weather-resistant cover for the entire swing to protect it from the elements.

### Inspection:

- Periodically check all nuts, bolts, and fasteners to ensure they are tight. Tighten as necessary.
- Inspect the frame for any signs of rust or damage. Address any issues promptly to maintain product integrity.

## 6. Troubleshooting

---

- **Swing appears twisted or imbalanced after assembly:** This can occur if similar parts, such as 'K' and 'K1' rods, are incorrectly interchanged during assembly. Review the assembly instructions carefully to ensure all parts are in their designated positions. Disassemble and reassemble the affected sections if necessary.
- **Squeaking during use:** Check all connection points and apply a silicone-based lubricant to moving parts or joints if squeaking persists.
- **Canopy not staying in position:** Ensure the adjustment knobs on the canopy frame are fully tightened after positioning.

## 7. Specifications

Attribute	Detail
Brand	NOBLEMOOD
Model Number	LY-2009
Color	Burgundy
Product Dimensions	78.8"D x 45"W x 65.8"H
Frame Material	Alloy Steel
Finish Type	Painted, Polished
Seat Depth	18.1 inches
Assembly Required	Yes
Set Name	3-Seat Outdoor Porch Swing Set
Item Weight	80 pounds
Material	Aluminum (Frame is Alloy Steel, but general material listed as Aluminum)

# Dimension



Image: Detailed dimensions of the swing and its components.

## 8. Warranty and Support

For warranty information, product support, or to order replacement parts, please contact NOBLEMOOD customer service through the retailer where the product was purchased. Please have your model number (LY-2009) and purchase date available when contacting support.