

[Manuals.plus](#) /

> [Kenmore](#) /

> Kenmore 81714 700 Series Bagged Canister Vacuum Cleaner & Compact Carpet Cleaner User Manual

Kenmore 81714

Kenmore 81714 700 Series Bagged Canister Vacuum Cleaner & Compact Carpet Cleaner User Manual

MODEL: 81714

PRODUCT OVERVIEW

The Kenmore 81714 700 Series Bagged Canister Vacuum Cleaner and Compact Carpet Cleaner is designed for comprehensive home cleaning. This versatile system combines powerful vacuuming capabilities with effective spot cleaning for carpets and upholstery.



Image: Kenmore 700 Series Bagged Canister Vacuum Cleaner and Spotlite Compact Carpet Cleaner, showing both units.

Key features include:

- **Motorized Pet PowerMate Attachment:** Effectively removes stubborn pet hair and dust from carpets and hard-to-reach areas.
- **Ultra Plush Nozzle:** Utilizes airflow for deep cleaning on ultra-plush carpeting.
- **HEPA Media Filter:** Captures 99.97% of dust, including pollen and pet dander, ensuring cleaner air.
- **Performance Indicator:** Alerts you when the bag is full or when to check for clogs.
- **Powerful Suction:** Lifts tough stains from carpets, upholstery, and auto interiors.
- **Lightweight & Portable:** The compact carpet cleaner weighs less than 11 lbs for easy maneuverability.

SETUP AND ASSEMBLY

Vacuum Cleaner Assembly

1. Unpack all components from the packaging.
2. Connect the heavy-duty durable vacuum hose to the main canister unit. Ensure it clicks securely into place.
3. Attach the handle to the extendable vacuum wand. The handle features suction control and carpet/hard floor mode selection.
4. Connect the vacuum wand to the main vacuuming head (power nozzle). Ensure the power cord running down the back of the wand is properly connected to power the brush head.
5. The vacuum wand has multiple locking positions for adjustable length.



Image: The Kenmore 700 Series canister vacuum with its main power nozzle and hose attached.

Compact Carpet Cleaner Setup

The compact carpet cleaner is designed for immediate use. Simply fill the solution tank with appropriate cleaning solution and water as per the cleaner's instructions (refer to the cleaner's specific manual for detailed instructions).

OPERATING INSTRUCTIONS

Vacuum Cleaner Operation

The Kenmore 700 Series vacuum offers versatile cleaning for various surfaces:

- **Power On/Off:** The main power button is located on the canister unit.
- **Surface Selection:** Use the controls on the handle to switch between "Carpet" and "Hard Floor" modes. This adjusts the brush roll speed for optimal cleaning.
- **Suction Control:** Adjust the suction power using the slider on the handle. This allows for customized cleaning based on the surface and debris type.
- **Maneuverability:** The canister unit features heavy-duty wheels, including a 360-degree rolling wheel, for easy movement across floors. The flexible wand attachment allows for cleaning around corners and under furniture.
- **Hard Floor Cleaning:** The hard floor attachment is highly effective at picking up debris, including pet hair, from solid surfaces. It often includes a light to illuminate the cleaning path.

Specialized Attachments

The vacuum includes several attachments for specific cleaning tasks, stored conveniently within the canister unit:

- **Pet PowerMate:** A motorized brush attachment specifically designed for removing pet hair from upholstery, stairs, and other fabric surfaces.
- **Crevice Tool:** For reaching into tight corners and narrow spaces.
- **Dusting Brush:** Ideal for delicate surfaces and dusting.

Compact Carpet Cleaner Operation

The Spotlight Portable Carpet Cleaner is designed for targeted stain removal:

- **Stain Removal:** Apply cleaning solution and use the powerful suction to lift tough stains from carpets, rugs, upholstery, and even car interiors.
- **Portability:** Its lightweight design (under 11 lbs) makes it easy to carry and use wherever needed.



Image: Using the Spotlite cleaner on a carpeted surface.




Image: Cleaning upholstery on a sofa with the Spotlite.



Image: Spot cleaning the interior of a car.

MAINTENANCE

Vacuum Bag Replacement

The Kenmore 700 Series uses anti-bacterial vacuum bags (e.g., 50558). The Performance Indicator on the unit will alert you when the bag is full and needs replacement.

1. Open the vacuum compartment where the bag is located.
2. Slide out the full bag.
3. Slide in a new anti-bacterial bag.
4. Fold the bag slightly and close the compartment securely.

HEPA Filter Maintenance

The vacuum is equipped with a HEPA Media Filtration system, which is excellent for trapping allergens and fine dust. The HEPA filter is located on the bottom of the vacuum. Refer to the specific instructions for cleaning or replacing the HEPA filter to maintain optimal performance.

General Cleaning

Regularly check and clean the brush roll on the power nozzle to remove tangled hair or debris. Wipe down the exterior of both units with a damp cloth as needed.

TROUBLESHOOTING

- **Loss of Suction:** Check the Performance Indicator. If the bag is full, replace it. Inspect the hose and attachments for any clogs.
- **Brush Roll Not Spinning:** Ensure the vacuum is in "Carpet" mode. Check for obstructions in the brush roll.
- **Power Issues:** Ensure the power cord is fully extended and securely plugged into a working outlet. Check the on/off button on the canister.

SPECIFICATIONS

Feature	Detail
Brand	Kenmore
Model Number	81714
Special Feature	Bagged Canister, Compact Carpet Cleaner
Filter Type	HEPA Media Filter
Included Components	Power Nozzle, HEPA Filter, Pet PowerMate, Crevice Tool, Dusting Brush
Form Factor	Canister
Control Method	Push Button, Handle Controls
Portable (Carpet Cleaner)	Yes (less than 11 lbs)

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the official Kenmore website or the warranty card included with your product. Keep your purchase receipt for warranty claims.

For technical support, replacement parts, or additional assistance, please visit the Kenmore customer support portal or contact their service hotline. Contact information can typically be found on the Kenmore website or in the product

packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BTPCDP9Q>

More documents and user manuals: <https://manuals.plus/>