

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [eXtremeRate](#) /

› [eXtremeRate Scarlet Red Real Metal Buttons \(RMB\) Version RISE Remap Kit for PS5 Controller BDM-030 040 050 - Instruction Manual](#)

eXtremeRate XPFJ7004G3

eXtremeRate Scarlet Red Real Metal Buttons (RMB) Version RISE Remap Kit for PS5 Controller - Instruction Manual

Model: XPFJ7004G3

1. INTRODUCTION

This manual provides detailed instructions for installing and using the eXtremeRate Scarlet Red Real Metal Buttons (RMB) Version RISE Remap Kit. This kit is designed to transform your standard PlayStation 5 controller into a professional eSport elite controller by adding two ergonomic, programmable back buttons. The metal back paddles are crafted from high-quality metal for enhanced durability and a tactile feel. The K1 and K2 buttons require a specific pressure to activate, which helps prevent accidental presses during intense gameplay.



Image 1: PS5 Controller with eXtremeRate RISE Remap Kit installed.

2. COMPATIBILITY

This kit is compatible with PlayStation 5 controllers with motherboard models BDM-030, BDM-040, and BDM-050. It is **NOT** compatible with BDM-010 or BDM-020 models.

To ensure compatibility, please verify your controller's BDM model before proceeding with installation. You can check your controller's BDM model using one of the following methods:

1. Method 1: Visual Inspection of R2 Trigger Spring

Carefully inspect the R2 trigger mechanism. The presence and position of the spring can indicate the BDM model. Refer to the image below for visual guidance.

2. Method 2: Software Check via PC

Connect your PS5 controller to a PC using a USB data cable and visit the eXtremeRate BDM check tool online. This tool will identify your controller's BDM model.

Compatibility: BDM-030 ✓ BDM-040 ✓ BDM-050 ✓

eXtremeRate-How to Check Your Controller BDM-Model

1 extremeerate check controller bdm







Image 2: Visual guide for checking PS5 controller BDM models.

Video 1: How to Check Your Controller's BDM Model for PS5. This video demonstrates both visual and software methods to identify your PS5 controller's BDM model, ensuring compatibility with eXtremeRate products.

Video 2: Compatibility & Upgrade Guide V3: How To Check The Model Numbers BDM-030 040 050 for PS5 Controller. This video provides a detailed guide on identifying the correct BDM model for your PS5 controller, crucial for selecting the right upgrade kit.

3. KIT CONTENTS

The eXtremeRate Scarlet Red Real Metal Buttons (RMB) Version RISE Remap Kit includes the following components:

- Scarlet Red redesigned back shell
- Upgrade board
- 2 Real Metal programmable back buttons (K1, K2)
- Various screws and tools for installation



Image 3: Contents of the eXtremeRate RISE Remap Kit.

4. INSTALLATION GUIDE

Installing the RISE Remap Kit requires high hands-on skills. Soldering is optional, depending on which buttons you wish to remap. For a comprehensive step-by-step installation process, please refer to the official video guide.

Key Installation Steps (Overview):

1. Disassemble your PS5 controller.
2. Install the upgrade board and connect the necessary flex cables.
3. Attach the metal back buttons to the redesigned back shell.
4. Reassemble the controller with the new back shell.

Video 3: eXtremeRate RISE (Plastic & Metal buttons version) Remap Kit for PS5 Controller. This video provides a detailed installation guide for the eXtremeRate RISE Remap Kit, demonstrating each step of the modification process.

For specific instructions on soldering (if you choose to remap L3, R3, or Touchpad buttons), please follow the video guide carefully. If you only intend to remap face buttons and shoulder buttons, soldering may not

be required.

5. PROGRAMMING BACK BUTTONS

The RISE Remap Kit allows you to assign up to 15 different controller functions to the two back buttons (K1 and K2). These functions include: X, O, Triangle, Square, Up, Down, Left, Right, L1, L2, R1, R2, L3, R3, and Touchpad Button.

Programming Steps:

1. Press and hold the Setting Button (located on the back attachment) until the LED indicator lights up.
2. Press the back button (K1 or K2) you wish to program.
3. Press the desired function button (e.g., X, O, L1) on the front of the controller.
4. Press the Setting Button again to save the mapping. The LED indicator will turn off.



Image 4: Back of the controller showing the LED indicator, Setting Button, and Back Buttons.



15 buttons can be assigned to the back buttons: X, O, Triangle, Square, Up, Down, Left, Right, L1, L2, R1, R2, L3, R3 and Touchpad Button

Image 5: Illustrates the 15 assignable buttons for the back paddles.

6. USAGE AND BENEFITS

Once installed and programmed, the RISE Remap Kit allows for faster and more efficient gameplay by keeping your thumbs on the analog sticks and fingers on the triggers. This can provide a competitive edge in various games.

Video 4: eXtremeRate Real Metal Buttons Version RISE Remap Kit for PS5 Controller. This video showcases the eXtremeRate Real Metal Buttons Version RISE Remap Kit in action, demonstrating its functionality and ergonomic benefits during gameplay.

7. MAINTENANCE

To maintain the quality and longevity of your eXtremeRate product, follow these cleaning guidelines:

- Clean with a wipe dampened with water.
- If alcohol is used, ensure it is less than 70% concentration.
- Place the product in a well-ventilated area to dry completely.

- Do not spray water or alcohol directly onto the product surface.
- Avoid using any other organic solvents for cleaning.

8. TROUBLESHOOTING

- **Paddles Inconsistent/Unresponsive:** Ensure all flex cables are securely connected and not damaged during installation. Re-check soldering points if applicable.
- **Buttons Not Remapping:** Verify that the programming steps (Section 5) are followed precisely. Ensure the Setting Button is pressed correctly to enter and exit programming mode.
- **Kit Not Fitting:** Double-check your controller's BDM model (Section 2) to confirm it is compatible with this specific kit.

9. SPECIFICATIONS

- **Model Number:** XPFJ7004G3
- **Product Dimensions:** 6.1 x 3.54 x 0.59 inches
- **Item Weight:** 1.06 ounces
- **Compatible Controller Models:** PS5 BDM-030, BDM-040, BDM-050
- **Material:** Real Metal Buttons
- **Programmable Buttons:** Up to 15 functions

10. WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please visit the official eXtremeRate website or contact their customer service directly. You can also find additional resources and guides on the [eXtremeRate Store on Amazon](#).