Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY YT1F

Allimity YT1F Series Remote Control User Manual

Model: YT1F

Introduction

This manual provides detailed instructions for the operation and maintenance of your Allimity YT1F series replacement remote control. This remote is designed to be a direct replacement for various air conditioner models, offering seamless functionality without complex setup.

Compatibility

This remote control is compatible with several air conditioner models, including but not limited to:

- Gree
- Airlux
- Trane
- Electrolux

Specifically, it replaces original remote models such as **YT1F2**, **YT1FF**, **YT1F3**, **YT1F4**, and **YT1F1**.

Setup

Battery Installation

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.



Figure 1: Battery compartment on the back of the remote, showing the correct orientation for AAA battery insertion.

Initial Setup

No programming or complex setup is required for this remote control. Once the batteries are correctly installed, the remote is ready for immediate use with compatible air conditioner models.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the air conditioner.





Figure 2: Front view of the Allimity YT1F remote control.

Button Functions

Button	Function
Power ( )	Turns the air conditioner On or Off.
MODE	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
FAN	Adjusts fan speed (e.g., Low, Medium, High, Auto).
+ / -	Increases or decreases the temperature setting.
I FEEL	Activates the "I Feel" function, which senses the temperature at the remote's location.
CLOCK	Sets the current time on the remote's display.
TIMER ON	Sets a timer for the air conditioner to turn On.
TIMER OFF	Sets a timer for the air conditioner to turn Off.
BLOW	Activates the "Blow" function, which helps dry the indoor unit to prevent mold.
TEMP	Switches the temperature display between Celsius and Fahrenheit.
TURBO	Activates rapid cooling or heating for quick temperature changes.
SLEEP	Adjusts temperature and fan speed for comfortable sleep.
LIGHT	Turns the display light of the indoor unit On or Off.


FAN
I FEEL
MODE
CLOCK
BLOW
TURBO
TIMER ON
TEMP
SLEEP
TIMER OFF
LIGHT



Figure 3 & 4: Various angled views of the remote control, showcasing its design.

Maintenance

Battery Replacement

Replace batteries when the remote control's display becomes dim or its response becomes sluggish. Always replace both batteries at the same time with new AAA alkaline batteries.
Warning: Do not dispose of batteries in fire. Batteries may explode or leak. Dispose of used batteries according to local regulations.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity.
Remote's screen is dim or blank.	Low battery power.	Replace batteries.
Air conditioner not responding to remote.	Obstruction between remote and AC unit; remote not pointed correctly; AC unit's receiver is blocked or faulty.	Ensure clear line of sight. Point remote directly at the AC unit. Check if the AC unit's receiver is clean and unobstructed.
Remote works for some functions but not others.	Compatibility issue with specific AC model or function.	Verify your AC model is listed as compatible. Some advanced functions may vary by AC unit.

Specifications

Model Number: YT1F
Product Dimensions: 6 x 2 x 0.5 inches
Item Weight: 2 ounces
Power Supply: 2 x AAA Batteries (Not Included)
Connectivity Technology: Infrared
Compatible Devices: Air Conditioner
Special Feature: No Programming Required
Manufacturer: YUEDAXINFACTORY
Country of Origin: China

Warranty and Support

This product comes with a**60-day warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as described.
For support or warranty claims, please contact your retailer or the manufacturer directly. Please have your purchase information and product model number (YT1F) ready when contacting support.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTPK2MS7

More documents and user manuals: **https://manuals.plus/**