Cooler Master V1100 SFX Platinum (MPZ-B001-SFAP-BUS)

Cooler Master V1100 SFX Platinum Power Supply User Manual

Model: V1100 SFX Platinum (MPZ-B001-SFAP-BUS)
Brand: Cooler Master

Introduction

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your Cooler Master V1100 SFX Platinum Power Supply. Designed for high-performance ITX and SFF systems, this power supply offers exceptional power density, ATX 3.0 compatibility, and 80 Plus Platinum efficiency. Please read this manual thoroughly before installation and use to ensure optimal performance and safety.

Safety Information

Always observe the following safety precautions to prevent injury or damage to your system:

- Ensure the power supply is disconnected from the AC power outlet before installation or maintenance.
- Do not open the power supply unit. There are no user-serviceable parts inside. Opening the unit will void the warranty.
- Install the power supply in a well-ventilated area, away from heat sources and direct sunlight.
- Use only the modular cables provided with the power supply. Using incompatible cables may cause damage to the PSU or connected components.
- Ensure all cable connections are secure before powering on the system.
- Avoid exposing the power supply to moisture or extreme temperatures.

Product Overview

The Cooler Master V1100 SFX Platinum is a high-performance, fully modular power supply designed for compact systems. It features advanced technology to deliver stable and efficient power.



Figure 1: Front view of the Cooler Master V1100 SFX Platinum Power Supply, showing the modular cable connections.

Video 1: Product Overview of the Cooler Master V1100 SFX Platinum, highlighting its compact size, modularity, and key features.

Key Features:

- **High Power Density:** Achieves one of the highest power densities in the industry, utilizing advanced materials and miniaturization technology.



Figure 2: Illustration demonstrating the high power density of the V1100 SFX Platinum compared to other power supplies.

- **90° Durable Cables:** Features a 90° 12VHPWR PCIe 5.0 connector for improved electrical durability and safety, especially beneficial in tight SFF builds.



Figure 3: Close-up view of the 90-degree 12VHPWR PCIe 5.0 connector, designed for enhanced durability and easier cable management.

- **ATX 3.0 Cables:** The ATX 3.0 standard delivers up to 600W power to your GPU, ensuring compatibility with the latest high-performance graphics cards.




Figure 4: The power supply's modular interface, highlighting the ATX 3.0 and 12VHPWR PCIe 5.0 connectors.

- **80+ Platinum Efficiency:** Achieves Platinum-Level performance with up to 92% efficiency, minimizing energy waste and heat generation.



Figure 5: Graph illustrating the 80 Plus Platinum efficiency curve, showing high efficiency across various load levels.

- **Fully Modular Design:** Modular cables reduce clutter and enhance airflow within your PC case, improving overall system efficiency and aesthetics.



Figure 6: The fully modular design of the power supply, allowing users to connect only the necessary cables for a cleaner build.

- **Japanese Capacitors:** Integrates large, high-quality 100% Japanese capacitors to improve efficiency and reduce ripple noise, ensuring stable power delivery.



Figure 7: Internal view highlighting the high-quality Japanese capacitors used in the power supply for enhanced reliability.

- **92mm Fan:** Equipped with a quiet 92mm fan for effective cooling.
- **Enhanced Dissipation:** Integrated design of the transformer, rectifier, full-bridge LLC, and EMI-inhibited amorphous metal ensures top performance and cooling.



Figure 8: Diagram illustrating the enhanced dissipation design, showing how internal components contribute to efficient heat management.

Setup and Installation

Follow these steps to properly install your Cooler Master V1100 SFX Platinum Power Supply:

1. **Prepare Your Case:** Ensure your PC case is compatible with SFX form factor power supplies.
2. **Install SFX-to-ATX Bracket (if needed):** If your case requires an ATX power supply, use the included SFX-to-ATX bracket to mount the V1100 SFX Platinum.




Figure 9: The SFX-to-ATX bracket, allowing the SFX power supply to be installed in cases designed for ATX power supplies.

3. **Mount the Power Supply:** Secure the power supply into the designated bay in your PC case using the provided screws.
4. **Connect Modular Cables:** Identify the necessary cables for your components (motherboard, CPU, GPU, SATA devices, etc.). Connect them to the corresponding ports on the power supply.



Figure 10: The V1100 SFX Platinum power supply shown with its complete set of modular cables, ready for connection.

5. **Cable Management:** Route the cables neatly to improve airflow and aesthetics. The customized short cables help reduce clutter, but extended cables may be needed for larger cases.




Figure 11: Diagram illustrating the various lengths of the customized modular cables, designed for efficient cable management in compact builds.

6. **Connect to Components:** Plug the other end of each modular cable into your motherboard, graphics card (especially the 12VHPWR PCIe 5.0 connector for compatible GPUs), and storage devices.
7. **Connect AC Power:** Once all internal connections are secure, connect the AC power cord to the power supply and then to a wall outlet.

Operating Instructions

Operating your Cooler Master V1100 SFX Platinum Power Supply is straightforward:

- **Power On:** After completing the installation and ensuring all connections are secure, turn on your computer using the case's power button. The power supply will automatically begin providing power to your components.
- **Power Off:** To shut down your system, use the operating system's shutdown function. The power supply will power down automatically. For complete power disconnection, unplug the AC power cord from the wall outlet.

Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your power supply:

- **Cleaning:** Periodically clean the exterior of the power supply and its fan grille to prevent dust buildup. Use a can of compressed air to gently blow away dust from the fan and vents. Ensure the power supply is turned off and unplugged before cleaning.
- **Cable Inspection:** Occasionally inspect all modular cables for any signs of wear, fraying, or damage. Replace any damaged cables immediately.
- **Environment:** Maintain a clean, dry, and well-ventilated environment for your PC to prevent excessive heat and dust accumulation.

Troubleshooting

If you encounter issues with your Cooler Master V1100 SFX Platinum Power Supply, try the following troubleshooting steps:

- **No Power:**
  - Check if the AC power cord is securely plugged into both the power supply and the wall outlet.
  - Ensure the wall outlet is functional by testing it with another device.
  - Verify that all modular cables are correctly and firmly connected to both the power supply and your components.
- **System Instability/Crashes:**
  - Ensure your system's power requirements do not exceed the power supply's capacity.
  - Check for proper ventilation within your PC case to prevent overheating.
  - Verify that all components are seated correctly in their respective slots.
- **Unusual Noises:**
  - A slight fan noise is normal during operation. If the noise is excessive or unusual (e.g., grinding, rattling), ensure no cables are obstructing the fan.
  - If coil whine is present, it may be due to specific load conditions or system components. While often harmless, if persistent and disruptive, consider contacting support.

If these steps do not resolve the issue, please contact Cooler Master customer support for further assistance.

Specifications

Feature	Specification
Brand	Cooler Master
Model Name	V1100 SFX Platinum
Item Model Number	MPZ-B001-SFAP-BUS
Output Wattage	1100 Watts
Form Factor	SFX
Efficiency Certification	80 Plus Platinum (up to 92%)

Feature	Specification
Modular Design	Full Modular
Cooling Method	Air (92mm fan)
Dimensions (LxWxH)	3.9 x 4.9 x 2.5 inches
Weight	5.1 pounds
Connector Types	ATX, EPS, PCI Express, 12VHPWR PCIe 5.0, SATA
Compatible Devices	Personal Computer

Warranty and Support

Your Cooler Master V1100 SFX Platinum Power Supply comes with a**10-Year Warranty**, ensuring long-term reliability and peace of mind. For technical support, warranty claims, or additional information, please visit the official Cooler Master website or contact their customer service department.
You can find more information and support resources at theCooler Master Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question