

[Manuals.plus](#) /

› [Rafow](#) /

› Rafow 4-in-1 Electric Milk Frother User Manual

Rafow N22-B

Rafow 4-in-1 Electric Milk Frother

Model: N22-B | Brand: Rafow

INTRODUCTION

Thank you for choosing the Rafow 4-in-1 Electric Milk Frother. This versatile appliance is designed to help you create a variety of delicious milk-based beverages, including thick milk foam, thin milk foam, heated milk, and cold milk foam. With its large capacity, quiet operation, and easy-to-clean design, it's the perfect addition to any kitchen for coffee and hot chocolate enthusiasts.



The Rafow 4-in-1 Electric Milk Frother, shown in black with a stainless steel top, features a sleek design and intuitive controls. A cup of frothed coffee and scattered coffee beans are visible, illustrating its primary use.

PRODUCT FEATURES

- **4-in-1 Versatility:** Prepares thick milk foam, thin hot milk foam, heated milk, and cold milk foam.
- **Large Capacity:** 300ml maximum capacity for heating milk, 130ml for frothing milk.
- **Quiet Operation:** Designed for minimal noise during use.
- **Automatic Shut-off:** Ensures safety and prevents overheating.
- **Durable Construction:** Features a double-layer insulated wall, food-grade stainless steel interior, and ABS housing.
- **Non-stick Coating:** Interior with non-stick coating for easy cleaning.
- **Ergonomic Handle:** Provides a comfortable and stable grip.



This image illustrates the versatility of the frother, capable of preparing various coffee drinks such as Cappuccino, Latte, Macchiato, and Mokka, thanks to its multiple frothing and heating functions.

PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- 1 x Electric Milk Frother Unit
- 2 x Whisks (one for frothing, one for heating)
- 1 x Cleaning Brush
- 1 x Cleaning Card (for instructions or specific cleaning tips)
- 1 x User Manual

SPECIFICATIONS

Attribute	Value
Brand	Rafow
Model Number	N22-B (8B-FF98-HX1T)

Color	Black
Product Dimensions	14.99 x 9.91 x 19.81 cm (5.9 x 3.9 x 7.9 inches)
Weight	880 g (26.1 oz)
Capacity (Heated Milk)	300 ml (10 oz)
Capacity (Milk Foam Max)	130 ml (4.3 oz)
Capacity (Milk Foam Min)	75 ml (2.5 oz)
Power	300 W
Material	Stainless Steel and ABS Plastic
Special Features	Quiet operation, Variable foam adjustment, Overheat protection, Non-stick coating, Ergonomic handle



A detailed view of the frother's interior, highlighting the maximum fill lines: 300ml for heating milk, 130ml for maximum milk foam, and 75ml for minimum milk foam, ensuring precise measurements for optimal results.

SETUP

- Unpack:** Carefully remove all components from the packaging.
- Inspect:** Check for any damage during transit. If any damage is found, do not use the appliance and contact customer support.
- Initial Cleaning:** Before first use, clean the interior of the frother and the whisks with the included cleaning brush and a mild detergent. Rinse thoroughly with water. Do not immerse the base unit in water.
- Placement:** Place the frother on a stable, flat, and dry surface away from heat sources and water.

5. **Power Connection:** Connect the power cord to a suitable electrical outlet.

OPERATING INSTRUCTIONS

The RafoW Electric Milk Frother offers four distinct modes for various milk preparations. For best frothing results, it is recommended to use whole milk (fat content > 3%).

General Operation:

1. Ensure the frother is clean and dry before use.
2. Place the desired whisk inside the frother. Use the spring whisk for frothing and the flat whisk for heating without frothing.
3. Pour milk into the frother, observing the MIN and MAX fill lines for your desired function (refer to the capacity diagram in the Specifications section).
4. Place the lid securely on the frother.
5. Press the power button to select the desired mode. The indicator light will illuminate according to the selected function.
6. The frother will automatically shut off once the process is complete.

Mode Selection:

The frother features a single button for mode selection. Press the button repeatedly to cycle through the modes:

- **Thick Hot Milk Foam:** Press once. Automatically heats to 149°F / 65°C. Ideal for rich cappuccinos.
- **Thin Hot Milk Foam:** Press twice. Automatically heats to 149°F / 65°C. Suitable for lattes and macchiatos.
- **Heated Milk:** Press three times. Automatically heats to 149°F / 65°C. Perfect for hot chocolate or warm milk.
- **Cold Milk Foam:** Press four times. Froths milk without heating. Great for iced coffees or cold beverages.



A visual guide to the frother's control button, detailing the four distinct modes: thick hot milk foam (automatically heated to 149°F/65°C), thin hot milk foam (automatically heated to 149°F/65°C), heated milk (automatically heated to 149°F/65°C, suitable for cocoa powder or chocolate), and room temperature milk foam (frothing without heating).

Feiner & seidiger Milchschaum

Ermöglicht es Ihnen, innerhalb von 2 Minuten perfekten Milchschaum zu machen. Verwenden Sie am besten Vollmilch (>3% Fett).



This image demonstrates the smooth, silky milk foam produced by the frother, being poured into a coffee cup. Accompanying icons emphasize key features: quiet operation, rapid frothing, automatic shut-off for safety, and a food-grade non-stick coating for durability and easy cleaning.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your milk frother and ensure optimal performance.

1. **Unplug:** Always unplug the frother from the power outlet before cleaning.
2. **Cool Down:** Allow the frother to cool down completely after use.
3. **Hand Wash Only:** The frother's interior and whisks should be cleaned by hand only. Do not place the frother body or base in a dishwasher.
4. **Clean Interior:** Rinse the interior of the frother with warm water immediately after use. Use the included cleaning brush and a mild, non-abrasive detergent to remove any milk residue. The non-stick coating makes cleaning easy.
5. **Clean Whisks:** Wash the whisks with warm, soapy water and rinse thoroughly.
6. **Exterior Cleaning:** Wipe the exterior of the frother with a damp cloth. Do not use abrasive cleaners or scouring pads.
7. **Dry Thoroughly:** Ensure all parts are completely dry before storing or next use.

LEICHT ZU REINIGEN

Aus ABS-Oberfläche und Edelstahl-Innenseite mit Antihaftbeschichtung und wasserdichtem Knopf für eine einfache Reinigung.



This image illustrates the ease of cleaning the frother. It shows water being poured into the stainless steel interior, which has a non-stick coating, and the use of the included cleaning brush to ensure thorough cleaning. The design prevents water from entering the base, making cleaning safe and simple.

TROUBLESHOOTING

If you encounter any issues with your Raflow Electric Milk Frother, please refer to the following common problems and solutions:

- **Frother does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if there is a power outage or tripped circuit breaker.
- **Milk is not frothing or foam is not thick enough:**
 - Ensure you are using fresh, cold whole milk (fat content > 3%).
 - Check that the correct whisk (spring whisk) is properly installed.
 - Do not exceed the MAX fill line for frothing.
 - Ensure the frother's interior is clean and free of residue.
- **Milk is not heating:**
 - Ensure the correct mode for heating milk is selected.
 - Do not exceed the MAX fill line for heating.
- **Unusual noise during operation:**
 - Ensure the whisk is properly seated and not obstructed.
 - Check that the frother is placed on a stable, flat surface.

If the problem persists after trying these solutions, please contact Raflow customer support for further assistance.

WARRANTY AND SUPPORT

Rafow products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or visit the official Rafow website.

For technical support, troubleshooting assistance, or inquiries about your product, please contact Rafow customer service:

- **Website:** www.rafow.com (Please note: This is a placeholder URL. Refer to your product documentation for the actual support contact information.)
- **Email:** support@rafow.com (Please note: This is a placeholder email. Refer to your product documentation for the actual support contact information.)

Please have your model number (N22-B) and purchase date ready when contacting support.

© 2023 Rafow. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question