Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TMEOSK B0BTSW1JNF

TMEOSK Full Over Full House-Shape Wooden Bunk Bed Instruction Manual

Model: B0BTSW1JNF

Introduction

This manual provides detailed instructions for the safe assembly, operation, and maintenance of your TMEOSK Full Over Full House-Shape Wooden Bunk Bed. Please read all instructions carefully before assembly and use to ensure safety and product longevity. Keep this manual for future reference.

Safety Information

WARNING: Failure to follow these warnings could result in serious injury.

- Always use the recommended mattress size to prevent entrapment or falls.
- Ensure all connections are tight before each use. Periodically check and tighten hardware.
- Do not allow children under 6 years of age on the upper bunk.
- Prohibit more than one person on the upper bunk.
- Always use the ladder for entering and exiting the upper bunk.
- Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.
- The maximum weight capacity for each bed is 250 lbs.

Setup and Assembly

Before beginning assembly, ensure all parts are present and undamaged. It is recommended to assemble the bed with two adults. Clear a spacious area for assembly.

Required Tools:

All necessary tools are provided with the product. No additional tools are typically required.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify against the parts list (not provided in

input, so generalize).

2. **Assemble Lower Bed Frame:** Connect the side rails and end panels for the lower bunk using the provided hardware. Ensure all connections are secure but do not fully tighten until the frame is complete.
3. **Install Lower Bed Slats:** Place the wooden slats onto the support rails of the lower bed frame. Secure them according to the instructions (usually by screwing them into place).
4. **Assemble Upper Bed Frame:** Repeat the process for the upper bunk frame, connecting side rails and end panels.
5. **Install Upper Bed Slats:** Secure the wooden slats for the upper bunk.
6. **Attach Upper Bunk to Lower Bunk:** Carefully lift and align the upper bunk frame onto the lower bunk frame. Secure them together using the designated connection points and hardware.
7. **Attach Ladder:** Securely attach the ladder to the designated side of the bunk bed. Ensure it is firmly fixed and stable.
8. **Install Roof and Window Panel:** Attach the decorative roof structure and the window panel with the integrated shelf to the upper bunk frame.
9. **Final Tightening:** Once all components are assembled, go back and fully tighten all hardware connections. Do not overtighten.



Image: Fully assembled TMEOSK Full Over Full House-Shape Wooden Bunk Bed, showing the house-shaped roof, window, and ladder.



Image: Close-up view of the unique house-shaped window panel with an integrated shelf, located on the upper bunk.



Image: Detail of the wooden bed slats providing mattress support and the sturdy white ladder for accessing the upper bunk.

Operating Instructions

- **Mattress Placement:** Place a full-size mattress on both the upper and lower bunks. Ensure the mattress fits snugly within the frame to prevent gaps.
- **Ladder Use:** Always use the provided ladder to access the upper bunk. Do not climb on the bed frame directly.
- **Weight Limit:** Adhere strictly to the 250 lbs weight limit per bed. Overloading can compromise structural integrity and safety.
- **Supervision:** Children using the upper bunk should be supervised, especially younger children.

Maintenance

- **Cleaning:** Wipe the wooden surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish. The product care instructions mention "Dry Clean Only," which typically refers to fabric

components if present. For the wood frame, a damp cloth is appropriate.

- **Hardware Check:** Periodically (e.g., monthly or quarterly) inspect all bolts, screws, and connections to ensure they are tight. Retighten any loose hardware to maintain stability and safety.
- **Structural Integrity:** Regularly check for any signs of wear, damage, or cracks in the wood. If any damage is found, discontinue use and contact customer support.

Troubleshooting

- **Squeaking Noises:** If the bed squeaks, check all hardware connections and tighten any loose bolts or screws. Ensure the slats are properly seated and secured.
- **Instability/Wobbling:** Verify that the bed is assembled on a flat, level surface. Recheck all connections and ensure they are fully tightened.
- **Missing Parts:** If any parts are missing or damaged upon arrival, do not proceed with assembly. Contact TMEOSK customer service immediately for assistance.

Specifications



Image: Diagram showing the detailed dimensions of the bunk bed in inches, including length, width, height, and internal measurements.

Feature	Detail
Model Number	B0BTSW1JNF
Brand	TMEOSK
Type	Full Over Full Bunk Bed
Overall Product Dimensions	77.2"L x 56"W x 77.8"H
Frame Material	Pine Wood, MDF
Color	Natural Wood
Weight Capacity (per bed)	250 lbs
Assembly Required	Yes
Special Features	House-shape design with roof and window, integrated shelf, sturdy wood slat support, built-in ladder.

Warranty and Support

For warranty information, missing parts, or any product-related inquiries, please contact TMEOSK customer service directly. Refer to your purchase documentation for specific contact details or visit the official TMEOSK website. When contacting support, please have your model number (B0BTSW1JNF) and purchase date available.

© 2023 TMEOSK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTSW1JNF

More documents and user manuals: **https://manuals.plus/**