

## TecTake 404740

# TecTake Ergonomic Gaming/Office Chair Model 404740 Instruction Manual

Model: 404740

## 1. INTRODUCTION

---

Thank you for choosing the TecTake Ergonomic Gaming/Office Chair, Model 404740. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.



Figure 1: TecTake Ergonomic Gaming/Office Chair (Model 404740)

## 2. SAFETY INFORMATION

- **Weight Limit:** Do not use the chair with a weight exceeding 120 kg to prevent stability issues.
- **Assembly:** Ensure all components are securely fastened before use. Follow assembly instructions precisely.
- **Stability:** Avoid standing on the chair or using it as a step stool. Do not lean excessively to one side.
- **Children:** Keep children away from the chair during assembly. Supervise children when they are near or using the chair.
- **Movement:** Exercise caution when moving the chair, especially on uneven surfaces.

## 3. PRODUCT OVERVIEW AND FEATURES

The TecTake Ergonomic Gaming/Office Chair is designed for versatile comfort and support during extended periods of use.

## Key Features:

- **Versatile Comfort:** Features adjustable seat height and a backrest reclinable up to 135° for optimal positioning.
- **Ergonomic Design:** Thick padding and an ergonomic shape provide exceptional comfort. Includes a lumbar cushion for back support.
- **Distinctive Style:** Bold lines and synthetic leather upholstery offer a refined aesthetic suitable for various environments.
- **Flexibility and Mobility:** A swivel cross base and double casters allow for easy movement.
- **Quality Construction:** Spacious seat with 8 cm padding and robust structure supporting up to 120 kg.



**tectake<sup>®</sup>**  
HOME

**CARATTERISTICHE**

-  **Cuscini confortevoli**  
per una comodissima  
esperienza di seduta
-  **Cuscino lombare extra**  
fornisce un supporto per  
la parte inferiore della  
colonna vertebrale
-  **Poggiapiedi pieghevole**  
per un piacevole sollievo  
delle gambe
-  **Braccioli premium**  
splendidamente curvati e  
comodamente imbottiti
-  **Altezza regolabile**  
grazie alla molla a gas  
stabile e sicura
-  **Schienale inclinabile**  
per rilassarsi o per  
giocare in modo rilassato
-  **Robusta base a stella**  
con 5 doppie ruote  
silenziose e protettive per  
il pavimento

**SGS**

**TESTATO PER  
120.000 CICLI  
DI UTILIZZO**

Figure 2: Key Features of the Chair



1. Imbottitura morbida e confortevole



2. Pratico poggiapiedi pieghevole



3. Schienale alto e confortevole



4. Altezza e inclinazione regolabili

Figure 3: Detailed Feature Views

## 4. SETUP AND ASSEMBLY

Assembly typically involves attaching the base, casters, gas lift, seat, and backrest. While specific steps may vary, the general process is as follows:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (not provided in this manual, refer to product packaging).
2. **Attach Casters to Base:** Insert the five casters into the holes on the star-shaped base until they click into place.
3. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the star-shaped base.
4. **Attach Mechanism to Seat:** Secure the seat mechanism to the underside of the seat cushion using the provided screws. Ensure the front of the mechanism aligns with the front of the seat.
5. **Connect Seat to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder.
6. **Attach Armrests:** Secure the armrests to both the seat and the backrest using the designated screws.
7. **Attach Backrest:** Connect the backrest to the seat assembly, typically via the armrests or a separate

bracket, and secure with screws.

8. **Install Lumbar Cushion and Headrest:** Position the lumbar cushion and headrest as desired.



Figure 4: Gas Lift Cylinder

---

## 5. OPERATING INSTRUCTIONS

---

Your TecTake chair offers several adjustment options for personalized comfort.

### Adjustments:

- **Seat Height Adjustment:** Locate the lever on the right side under the seat. Pull the lever upwards to raise the seat. To lower, remain seated and pull the lever upwards. Release the lever to lock the height.
- **Backrest Recline:** Use the lever on the left side under the seat to adjust the backrest angle. Pull the lever to recline the backrest up to 135°. Release the lever to lock the backrest in your desired position.
- **Foldable Footrest:** Pull the footrest out from under the seat and flip it up for leg support. Push it back under the seat when not in use.
- **Lumbar Cushion:** Adjust the position of the lumbar cushion along the backrest for optimal lower back support.



**ECCELLENTE  
PORTATA**

**APPOGGIATI  
COMODAMENTE**

**90°**

**135°**

**ANGOLO  
DI INCLINAZIONE  
REGOLABILE**

**REGOLAZIONE  
CONTINUA  
DELL'ALTEZZA**

**MANEGGEVOLE  
LEVA**

Figure 5: Recline and Height Adjustment



Figure 6: Chair with Extended Footrest

## 6. MAINTENANCE

Regular maintenance helps prolong the life and appearance of your chair.

- **Cleaning:** Wipe the synthetic leather upholstery with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Casters:** Keep casters free of hair and debris to ensure smooth movement.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the upholstery to fade or crack.

## 7. TROUBLESHOOTING

If you encounter issues with your chair, refer to the following common solutions:

- **Chair Sinks or Does Not Stay Up:** The gas lift may be faulty. Contact customer support for a replacement.
- **Chair Wobbles:** Check that all screws and bolts are securely tightened, especially those connecting the base, mechanism, and armrests. Ensure the casters are fully inserted.
- **Casters Not Rolling Smoothly:** Remove any hair or debris from the caster wheels. Lubricate with a silicone-based spray if needed.
- **Backrest Does Not Recline/Lock:** Check the recline lever and mechanism for obstructions. Ensure the lever is fully engaged or disengaged.
- **Squeaking Noises:** Apply a small amount of lubricant to moving parts or connection points where noise occurs.

## 8. SPECIFICATIONS

Brand	TecTake
Model	404740
Color	Black/Black
Material	Nylon, Synthetic Leather, Polypropylene, Polyurethane
Total Dimensions (W x D x H)	Approx. 70 cm x 69 cm x 117.5 - 127.5 cm
Seat Height	Approx. 47 - 56 cm
Backrest Dimensions (W x H)	Approx. 42 cm x 78 cm
Seat Dimensions (W x D)	Approx. 52 cm x 49 cm
Item Weight	19.2 kg

<b>Maximum Load Capacity</b>	120 kg
<b>Special Features</b>	Adjustable Height, Armrest, Lumbar Cushion, Ergonomic, Foldable Footrest, Adjustable Backrest

### MISURE



**Dimensioni totali**  
 Larghezza: ca. 70 cm  
 Profondità: ca. 69 cm  
 Altezza: ca. 117,5-127,5 cm

**Altezza di seduta**  
 ca. 47 - 56 cm

**Dimensioni dello schienale**  
 ca. 42 x 78 cm

**Dimensioni della seduta**  
 ca. 52 x 49 cm



**Portata massima:**  
 120 kg



Figure 7: Chair Dimensions

### 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact TecTake customer service directly. Details can typically be found on the manufacturer's website or through your point of purchase.



