

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Playmobil](#) /

› [Playmobil Special Plus Ballerina \(Model 71171\) Instruction Manual](#)

## Playmobil 71171

# Playmobil Special Plus Ballerina (Model 71171) Instruction Manual

### INTRODUCTION

---

Welcome to your Playmobil Special Plus Ballerina set. This instruction manual provides important information for the assembly, operation, and care of your new toy. This set allows children to engage in imaginative play with a ballerina figure and a ballet bar with mirrors.

### SAFETY INFORMATION

---

**WARNING: CHOKING HAZARD** - Small parts. Not for children under 3 years. Adult supervision is recommended during play to ensure safe handling of all components.

### PACKAGE CONTENTS

---

Your Playmobil Special Plus Ballerina set includes the following items:

- 1 Ballerina figure
- 1 Ballet bar with two mirror sections
- 1 Hairpiece for the ballerina figure



Image: The retail packaging for the Playmobil Special Plus Ballerina set, showing the ballerina figure and ballet bar inside.

## SETUP

### Assembling the Ballet Bar

1. Carefully unpack all components from the box.
2. Connect the two mirror sections to the central ballet bar. Ensure they click securely into place.
3. Attach the base supports to the bottom of the mirror sections to allow the bar assembly to stand freely and stably.

## Preparing the Ballerina Figure

1. Place the provided hairpiece onto the ballerina figure's head.
2. The ballerina figure is now ready for play.



*Image: The assembled Playmobil ballerina figure standing next to the ballet bar with mirrors.*

## OPERATING INSTRUCTIONS

---

The Playmobil Special Plus Ballerina set is designed for imaginative play. Follow these guidelines for optimal use:

- Position the ballerina figure at the ballet bar. The figure's hands are designed to grasp the bar, allowing for various ballet poses.
- Utilize the mirrors to enhance the play experience, enabling the ballerina to 'practice' her dance moves and observe her form.
- This set can be combined with other Playmobil sets to create expanded play scenarios and stories.



*Image: The Playmobil ballerina figure positioned at the ballet bar, demonstrating a typical play scenario.*

## MAINTENANCE

---

To ensure the longevity and cleanliness of your Playmobil set, please follow these maintenance guidelines:

- Clean figures and accessories with a damp cloth. Do not use harsh chemicals, abrasive cleaners, or solvents, as these may damage the plastic.
- Store the set in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping.
- Avoid submerging figures in water for extended periods.

## TROUBLESHOOTING

---

### Missing Parts

If any parts are missing upon opening the package, please contact Playmobil customer support directly for assistance.

### Figure Does Not Stand

Ensure the ballerina figure's feet are placed on a flat, stable surface. The figure is designed to stand independently or with support from the ballet bar. Check for any debris under the feet or on the standing surface.

## SPECIFICATIONS

---

Feature	Detail
Model Number	71171

Feature	Detail
Product Dimensions	4.72 x 3.54 x 1.57 inches
Item Weight	1.76 ounces
Recommended Age	3 years and up
Manufacturer	PLAYMOBIL

## WARRANTY AND SUPPORT

---

For warranty information or customer support regarding your Playmobil Special Plus Ballerina set, please refer to the official Playmobil website or contact their customer service department directly. It is advisable to keep your purchase receipt as proof of purchase.

Visit [www.playmobil.com](http://www.playmobil.com) for more information and contact details.