

[Manuals.plus](#) /

› [GreenPan](#) /

› GreenPan Elite 4-Square Waffle Maker: User Manual for Belgian & Classic Waffles

GreenPan CC010672-001

GreenPan Elite 4-Square Waffle Maker: User Manual

Model: CC010672-001

1. INTRODUCTION

The GreenPan Elite 4-Square Waffle Maker is designed to provide a versatile and convenient way to prepare both Belgian and classic style waffles. This appliance features Thermolon Volt ceramic nonstick coating, ensuring effortless food release and easy cleaning. With adjustable shade and crunch controls, you can customize your waffles to your preferred texture and browning level. The removable plates are dishwasher safe, simplifying post-meal cleanup. This manual provides essential information for the safe and effective use of your waffle maker.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. PRODUCT FEATURES

- **Thermolon Volt Ceramic Nonstick:** A revolutionary diamond-infused ceramic nonstick coating specifically designed for modern appliances, offering durability, easy cleaning, and PFAS-free cooking.
- **Toxin-Free:** The ceramic nonstick coating is free of PFAS, PFOA, lead, and cadmium for worry-free food preparation.
- **Removable Cast Plates:** Includes two sets of ultra-durable, removable plates for both classic American-style waffles and thicker Belgian waffles. These plates ensure optimal heat conduction and superior performance.
- **Adjustable Shade & Crunch Control:** Easily customize your waffles from light to golden brown, and from fluffy to crunchy, using the intuitive controls.
- **XL LCD Display:** Provides clear visibility for settings and cooking progress, offering total control over your waffle customization.
- **One-Touch Dial:** Integrated control for easy selection of desired presets.
- **Simple Storage:** Both Belgian and Classic Waffle Plates can be stored conveniently in the bottom of the unit for easy access and compact storage.
- **Extra-Large Moat:** Designed to prevent batter from leaking onto your countertop, the large moat frames the plates on all sides, simplifying cleanup.
- **Dishwasher Safe Plates:** The removable plates can be easily cleaned by placing them in the dishwasher.

4. SETUP

1. **Unpack:** Carefully remove the waffle maker and all accessories from its packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe down the exterior of the waffle maker with a damp cloth. Remove the waffle plates (see Section 6 for instructions) and wash them in warm, soapy water or place them in the dishwasher. Rinse thoroughly and dry completely.
3. **Placement:** Place the waffle maker on a stable, flat, heat-resistant surface, ensuring adequate ventilation around the unit.
4. **Plate Installation:** Ensure the desired waffle plates (Belgian or Classic) are securely installed in the unit.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet. The LCD display will illuminate.

5. OPERATING INSTRUCTIONS

1. **Power On:** Press the 'Start | Stop' button to turn on the waffle maker.
2. **Select Waffle Type:** Use the 'Settings' dial to select your desired waffle type (Belgian or Classic). The XL LCD display will show your selection.
3. **Adjust Shade/Crunch:** Use the 'Light | Dark' dial to set your preferred browning level (1-7). Use the 'Texture' button to toggle between 'Fluffy' and 'Crunchy' settings.
4. **Preheating:** The waffle maker will begin preheating automatically. The LCD display will show 'PREHEAT' and a progress bar. Wait until the unit beeps and the display indicates it is ready.
5. **Pour Batter:** Once preheated, open the lid. Carefully pour your waffle batter onto the center of each waffle plate. Ensure not to overfill; the extra-large moat will catch minor overflows.
6. **Close Lid:** Gently close the lid. The cooking timer will automatically begin counting down on the LCD display.
7. **Cooking Complete:** When the cooking cycle is complete, the waffle maker will beep and the display will show 'END'.
8. **Remove Waffles:** Open the lid and carefully remove the cooked waffles using a heat-resistant, non-metallic utensil.

to avoid damaging the nonstick coating.

9. **Continue Cooking:** If making more waffles, repeat steps 5-8. The unit will remain at temperature.

10. **Power Off:** When finished, press the 'Start | Stop' button to turn off the waffle maker and unplug it from the outlet.



Figure 5.1: Pouring batter into the preheated waffle plates.



THERMOLON™ VOLT

HEALTHY CERAMIC NONSTICK

Nonstick Reinvented

Healthy ceramic nonstick infused with diamonds and specially designed for kitchen electrics. Free of PFAS, PFOA, lead, and cadmium for worry-free cooking.



TOXIN-FREE

Our ceramic nonstick is free of PFAS, PFOA, Lead, and Cadmium



EXTRA TOUGH

Diamond-infused ceramic nonstick for power & performance



EASY TO CLEAN

Wipes clean & dishwasher safe

Figure 5.2: The XL LCD display and control dials for settings and shade/crunch adjustment.

6. PLATE INSTALLATION AND REMOVAL

The GreenPan Elite Waffle Maker comes with two sets of interchangeable plates: Belgian and Classic. These plates are designed for easy removal and installation.

1. **Ensure Cool:** Always ensure the waffle maker is unplugged and completely cool before attempting to remove or install plates.
2. **Remove Plates:** Locate the plate release buttons or levers, typically on the side or front of each plate. Press the release mechanism and gently lift the plate out of the unit. Repeat for the other plate.
3. **Install Plates:** Align the desired plate with the slots in the waffle maker base. Press down firmly until you hear a click, indicating the plate is securely locked into place. Repeat for the second plate.



Figure 6.1: Removable Belgian and Classic waffle plates.

7. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your GreenPan Elite Waffle Maker.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Plates:** Remove the waffle plates (see Section 6). The Thermolon Volt ceramic nonstick plates are dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge or cloth. Avoid metal scouring pads or harsh detergents.
3. **Clean Exterior:** Wipe the exterior of the waffle maker with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
4. **Clean Moat:** The extra-large moat helps contain spills. Any cooked batter in the moat can be easily removed once cooled. Wipe clean with a damp cloth.
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing the appliance.



Figure 7.1: Waffles are easily removed from the nonstick plates, simplifying cleanup.

8. STORAGE

For convenient and compact storage, the GreenPan Elite Waffle Maker is designed to store its extra set of plates directly within the unit.

- Ensure the appliance is clean and completely dry.
- Place the unused set of waffle plates into the designated storage area on the underside of the unit.
- The unit can be stored flat or upright to save counter or cabinet space.



Figure 8.1: The compact dimensions of the waffle maker for easy storage.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Waffles stick to plates	Plates not properly seasoned or cleaned; batter too thick/thin.	Ensure plates are clean and lightly oiled if necessary. Adjust batter consistency.
Waffles are not evenly cooked	Uneven batter distribution; incorrect temperature setting.	Distribute batter evenly. Adjust shade/crunch control. Allow full preheat.
Waffle maker not heating	Not plugged in; power switch off.	Check power cord connection. Ensure 'Start Stop' button is pressed.
Batter overflows	Too much batter poured.	Reduce the amount of batter. The moat will catch excess.

10. SPECIFICATIONS

- **Brand:** GreenPan
- **Model Number:** CC010672-001
- **Color:** Cream White
- **Material:** Healthy Ceramic Nonstick, PFAS-Free, Aluminum
- **Product Dimensions:** 17.13"D x 14.37"W x 9.96"H
- **Wattage:** 1400 watts
- **Voltage:** 220 Volts

- **Item Weight:** 17.96 pounds (8.17 Kilograms)
- **Special Feature:** Non Stick Coating, Removable Surface, Temperature Control
- **Included Components:** Electric Waffle Iron with 2 Sets of Removable Plates: Belgian and Classic
- **Number of Settings:** 3 (likely referring to main modes or presets)

11. WARRANTY AND SUPPORT

This GreenPan Elite 4-Square Waffle Maker comes with a Limited Warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or contact GreenPan customer support.

For technical assistance, troubleshooting, or to inquire about replacement parts, please visit the official GreenPan website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0BTTXC74K>

More documents and user manuals: <https://manuals.plus/>