Oraimo OPC-RS20

Oraimo SmartShaver 2 Electric Shaver User Manual

Model: OPC-RS20

Introduction

Thank you for choosing the Oraimo SmartShaver 2. This electric shaver is designed to provide a clean, comfortable, and efficient shaving experience. Please read this manual thoroughly before using the product to ensure proper operation, maintenance, and to maximize its lifespan. Keep this manual for future reference.

Important Safety Information

- Do not immerse the charging adapter in water or other liquids.
- Ensure the shaver is completely dry before connecting it to the charger.
- Keep the appliance out of reach of children.
- Do not use the shaver if the shaving head or pop-up trimmer is damaged, as this may cause injury.
- Only use the original charging cable provided with the shaver.
- This appliance is intended for shaving facial hair. Do not use it for other purposes.

Package Contents

Upon opening the package, please verify that all items listed below are present and in good condition:

- Oraimo SmartShaver 2 Electric Shaver
- USB Charging Cable
- Cleaning Brush
- User Manual



Image: The Oraimo SmartShaver 2, its charging cable, cleaning brush, and storage pouch, alongside its retail packaging.

Setup

Charging the Shaver

Before first use, fully charge the shaver. A full charge provides up to 60 minutes of cordless shaving. A quick 5-minute charge can provide enough power for one shave.

1. Ensure the shaver is dry.
2. Connect the USB charging cable to the shaver's charging port.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
4. The charging indicator light will illuminate. Once fully charged, the light will change or turn off depending on the model.



Image: The Oraimo SmartShaver 2 being charged via its USB cable, with indicators for 'Charge' and 'Full' battery status.

Operating the Shaver

Basic Shaving

The SmartShaver 2 can be used for both wet and dry shaving.

- **Dry Shaving:** For best results, shave before washing your face. Hold the shaver at a right angle to your skin and move it in circular motions.
- **Wet Shaving:** Apply shaving foam or gel to your face. Move the shaver in circular motions. Rinse the shaver head under water during shaving to prevent clogging.



Image: A detailed view of the shaver's dual ultra-thin razor net, designed for a clean and comfortable shave.



Image: The 3D floating razor heads of the Oraimo SmartShaver 2, designed to adapt to facial contours for smooth contact.

Using the Pop-Up Trimmer

The integrated pop-up trimmer is ideal for shaping sideburns, moustaches, and beards.

1. Locate the pop-up trimmer release button on the back of the shaver.
2. Press the button to activate the trimmer.
3. Use the trimmer to precisely shape and trim your facial hair.
4. Push the trimmer back into its housing when finished.




Image: A man using the Oraimo SmartShaver 2 for shaving, with an illustration demonstrating the pop-up trimmer in its extended position.

Maintenance

Cleaning the Shaver (IPX7 Water Resistance)

The SmartShaver 2 is IPX7 water-resistant, allowing for easy cleaning under running water.

1. After each use, switch off the shaver.
2. Open the shaving head by pressing the release button.
3. Rinse the shaving head and the hair chamber thoroughly under warm running water.
4. Use the provided cleaning brush to remove any stubborn hair particles.
5. Shake off excess water and allow the shaver head to air dry before closing or storing.



Image: The Oraimo SmartShaver 2 being cleaned under running water, highlighting its IPX7 water resistance for easy maintenance.

Blade Replacement

For optimal shaving performance, it is recommended to replace the shaving heads every 12 months, or sooner if you notice a decrease in shaving efficiency or increased irritation. Replacement heads can be purchased from authorized Oraimo retailers or their official website.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.

Problem	Possible Cause	Solution
Poor shaving performance / pulling hair.	Shaving heads are dirty or worn out.	Clean the shaving heads thoroughly. Consider replacing the shaving heads if they are old.
Shaver makes unusual noise.	Hair accumulation in the shaving head.	Clean the shaving head. If the noise persists, contact customer support.
Skin irritation after shaving.	Improper shaving technique or sensitive skin.	Ensure you are using circular motions. Try wet shaving with foam/gel. If irritation persists, consult a dermatologist.

Specifications

- **Model:** OPC-RS20
- **Power Source:** Battery Powered
- **Battery Type:** Lithium-ion
- **Battery Life:** Up to 60 minutes (cordless shaving)
- **Charging Time:** Approximately 1 hour (5-minute quick charge for one shave)
- **Water Resistance:** IPX7 (fully washable)
- **Blade Material:** Stainless Steel
- **Shaving System:** Dual Ultra-thin Razor Net, 3D Floating Razor Heads
- **Special Features:** Pop-up Trimmer, One-touch Open for cleaning
- **Dimensions (LxWxH):** Approximately 12 x 12 x 12 cm
- **Weight:** 200 g

Warranty and Support

Warranty Information

The Oraimo SmartShaver 2 comes with a **1-Year Replacement Warranty**. This warranty covers manufacturing defects and ensures that your product is free from defects in material and workmanship under normal use.
To claim your warranty, please visit the official Oraimo warranty claim portal:

Claim Warranty Here

Link: Click to access the Oraimo warranty claim form.



Image: Oraimo's warranty information, including a QR code for warranty claims and details about their global presence.

Customer Support

For any queries, assistance, or technical support, please contact Oraimo customer care:

- **Customer Care Number:** 1800 419 0525
- **Email:** service@whatnot.in (as per image text)

Please have your product model number (OPC-RS20) and purchase details ready when contacting support.

© 2024 Oraimo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question