Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- yoose /
- yoose Mini Shaver Instruction Manual

yoose MINI

yoose Mini Shaver Instruction Manual

Model: MINI | Brand: yoose

Introduction

Thank you for choosing the yoose Mini Shaver. This portable electric shaver is designed for convenience and a comfortable shaving experience, ideal for travel and daily use. Please read this manual thoroughly before using your new shaver to ensure proper operation and maintenance.



The yoose Mini Shaver, showcasing its compact and sleek design in alloy silver. A hand holding the shaver is visible in the bottom right corner, illustrating its small size.

WHAT'S INCLUDED

Your yoose Mini Shaver package includes the following items:

- yoose MINI Shaver 2.0
- Premium Leather Case
- USB-C Charging Cable
- Cleaning Brush
- Instruction Manual



MINI Shaver 2.0

Compact size for travel yoose




An overview of all items included in the yoose Mini Shaver package: the shaver, leather case, USB-C cable, cleaning brush, and instruction manual.

KEY FEATURES

 Travel Size & Portable: Designed for ultimate portability, this mini shaver fits easily in your bag, car, or travel kit. It includes a premium leather storage case and a TRAVEL LOCK function for secure carrying.



• Alloy Body Construction: Crafted from a one-piece molded alloy with an 18-plating process, the shaver boasts a mirror-like metal texture and a rounded shape for comfortable grip.



Detail shot emphasizing the alloy body and electroplating process of the shaver.

• **60 Minutes Cordless Shaving:** Equipped with USB-C quick charging, providing up to 60 minutes of cordless use per charge, suitable for weeks of regular shaving.



Visual representation of the shaver's USB-C charging capability and 60-minute battery life.

• IPX7 Waterproof & Washable: Fully washable design (IPX7 rated) with a magnetic head for effortless cleaning. Simply rinse under water after use.



The shaver partially submerged in water, demonstrating its IPX7 waterproof rating.

 Advanced Shaving System: Features a floating design with a stainless steel blade powered by a high-speed 8,000 RPM motor, ensuring a fast, comfortable shave without irritation.



yoose shavers come with an exclusive leather case. Convenient for your daily storage or for carrying the shaver when traveling. Moreover, it can protect the shaving head from damage.



An internal view highlighting the powerful motor and upgraded shaving blade for efficient performance.

SETUP

Before first use, fully charge your yoose Mini Shaver. Use the provided USB-C charging cable to connect the shaver to a compatible USB power source (e.g., wall adapter, computer USB port). The battery indicator will show charging status. A full charge provides approximately 60 minutes of cordless use.

OPERATING INSTRUCTIONS

Activating/Deactivating Travel Lock

The shaver is equipped with a travel lock function to prevent accidental activation during storage or transport. To activate or deactivate the travel lock, press and hold the power button for 2 seconds. The shaver will vibrate twice, and the indicator light will turn off after 1 second to confirm the lock is engaged.



A hand demonstrating how to activate the travel lock feature on the yoose Mini Shaver.

Shaving Tips

The yoose shaver is suitable for thin, short, soft, and new beards. For optimal results and to avoid pulling, it is recommended to trim longer hair before using the shaver. Once shaving has commenced, shave against the grain of the beard or facial hair for a closer shave.

Note: It is normal for the skin to experience mild irritation during the first few shaves. Regular use for approximately 3 weeks will help your skin accustom to the shaver.



Visual guide for shaving tips, showing recommended beard lengths for optimal use.

MAINTENANCE

Cleaning the Shaver

Thanks to its IPX7 waterproof rating, the yoose Mini Shaver is easy to clean. After each use, simply rinse the shaver head under running water to remove hair clippings. For a more thorough cleaning, detach the magnetic head and use the provided cleaning brush to clear any trapped debris. Ensure the shaver is dry before reattaching the head and storing.

The shaver being rinsed under water, demonstrating its full washability for easy cleaning.

SPECIFICATIONS

Feature	Detail
Model Name	MINI
Product Dimensions	2.42 x 2.08 x 1.02 inches
Weight	5.64 ounces
Power Source	Battery Powered (2 Lithium Ion batteries included)
Waterproof Rating	IPX7
Motor Speed	8,000 RPM
Battery Life	Up to 60 minutes cordless use
Charging Port	USB-C
Manufacturer	yoose
Country of Origin	China

TROUBLESHOOTING

If you encounter any issues with your yoose Mini Shaver, please refer to the following common solutions:

- Shaver not turning on: Ensure the travel lock is deactivated by pressing and holding the power button for 2 seconds. Check if the battery is charged.
- Poor shaving performance: Ensure the shaver head is clean and free of hair clippings. For longer beards, pre-trimming is recommended to prevent pulling and improve efficiency.
- **Skin irritation:** Mild irritation can occur during initial uses. Allow your skin to adapt over a few weeks of regular use. Ensure you are shaving against the grain for a closer, smoother result.
- Charging issues: Verify that the USB-C cable is securely connected to both the shaver and the power source. Try a different USB-C cable or power adapter if necessary.

For further assistance, please contact yoose customer support.

WARRANTY AND SUPPORT

The yoose Mini Shaver comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For product support, technical assistance, or warranty claims, please visit the official yoose website or contact their customer service department.

Online Resources:

- Visit the yoose Store on Amazon
- Download User Manual (PDF)

Related Documents - MINI

