

Manuals.plus /

- › Bosch /
- › Bosch UniversalLeafBlower 18V-130 Cordless Garden Blower User Manual

Bosch UniversalLeafBlower 18V-130

Bosch UniversalLeafBlower 18V-130 User Manual

Model: 06008A0601

1. INTRODUCTION

Thank you for choosing the Bosch UniversalLeafBlower 18V-130. This cordless garden blower is designed for quick and efficient removal of leaves, debris, and light garden waste from outdoor areas. Its lightweight design and powerful radial fan make garden clean-up effortless. Please read this manual carefully before operating the device to ensure safe and optimal performance.

2. SAFETY INFORMATION

Always observe basic safety precautions when using electrical tools to reduce the risk of fire, electric shock, and personal injury.

General Safety Warnings:

- Read all safety warnings, instructions, illustrations, and specifications provided with this power tool.
- Keep the work area clean and well-lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- Wear appropriate personal protective equipment, including eye protection, hearing protection, and sturdy footwear.
- Ensure the nozzle is securely attached before operation.
- Do not point the blower nozzle at people or animals.
- Use only Bosch 18V System batteries and chargers.

3. PRODUCT OVERVIEW

The Bosch UniversalLeafBlower 18V-130 is a compact and powerful tool for garden maintenance.



Figure 3.1: Bosch UniversalLeafBlower 18V-130 with its packaging, showcasing the main unit and detachable nozzle.

UniversalLeafBlower 18V-130

Ventilatore radiale potente

Il ventilatore radiale offre prestazioni di soffiaggio potenti per una rapida rimozione dei detriti



Attacco dell'ugello senza problemi

Con una semplice rotazione e clic dell'attacco dell'ugello robusto, i lavori di pulizia del giardino iniziano rapidamente

Tecnologia Syneon

Per una potenza ottimale e una massima durata a seconda delle necessità

Figure 3.2: Key features of the UniversalLeafBlower 18V-130, including the powerful radial fan, easy nozzle attachment, and Syneon Technology for optimized power and runtime.

Components:

- Blower Unit (main body with motor and handle)
- Blower Nozzle (detachable)
- Battery (*not included with this model*)
- Charger (*not included with this model*)

4. SETUP

4.1 Attaching the Blower Nozzle

1. Align the tabs on the blower nozzle with the slots on the blower unit's air outlet.
2. Insert the nozzle into the outlet.
3. Twist the nozzle clockwise until it clicks securely into place. Ensure it is firmly locked before use.



Figure 4.1: Attaching the blower nozzle by twisting it into place on the main unit.

4.2 Inserting/Removing the Battery

This tool is part of the Bosch 18V System and requires an 18V Lithium-Ion battery (sold separately).

- **Inserting:** Slide the charged battery into the battery slot on the blower unit until it clicks into place.
- **Removing:** Press the battery release button and slide the battery out of the slot.



Figure 4.2: The Bosch 18V battery system is compatible with a wide range of Bosch garden and power tools.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- To turn on the blower, press and hold the ON/OFF trigger switch located on the handle.
- To turn off the blower, release the ON/OFF trigger switch.

5.2 Speed Control

The UniversalLeafBlower 18V-130 features a 2-speed control to optimize power, noise, and runtime based on your needs.

- The blower offers two speed settings: a lower speed for lighter debris and longer runtime, and a higher speed for tougher tasks and faster cleaning.
- Adjust the speed by sliding the speed selector switch (if present) or by varying pressure on the trigger, depending on the model variant. Refer to the specific markings on your tool.

Regola la potenza con facilità

Da 185 km/h a 245 km/h a seconda del tipo di detriti, della distanza di pulizia e delle condizioni della superficie.



Figure 5.1: The speed control allows adjustment of airflow from 185 km/h to 245 km/h, depending on debris type and cleaning distance.

5.3 Operating Tips

- Start with the lower speed setting for general clean-up and switch to higher speed for stubborn debris.
- Work in sections, blowing debris into a manageable pile.
- Avoid blowing directly into flowerbeds or delicate areas.

Pulizia rapida delle aree esterne

Il ventilatore radiale integrato offre una potente prestazione di soffiaggio per una rapida rimozione dei detriti.



Figure 5.2: The UniversalLeafBlower 18V-130 in use, demonstrating its effectiveness for quick outdoor area cleaning.

6. MAINTENANCE

6.1 Cleaning

- Always remove the battery before cleaning.
- Wipe the exterior of the blower with a soft, damp cloth. Do not use harsh detergents or solvents.
- Clear any debris from the air intake and outlet vents to ensure proper airflow.

6.2 Storage

- Store the blower in a dry, secure place, out of reach of children.
- Detach the nozzle for more compact storage if desired.
- Store batteries in a cool, dry place, away from direct sunlight and extreme temperatures.



Figure 6.1: The compact design allows for convenient storage, such as hanging on a wall.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blower does not turn on.	Battery not inserted correctly or discharged.	Ensure battery is fully inserted and charged.
Low airflow or reduced power.	Air intake/outlet blocked; battery low; nozzle not fully attached.	Clear blockages; recharge battery; re-attach nozzle securely.
Unusual noise or vibration.	Loose components or internal damage.	Stop operation immediately. Do not attempt to repair. Contact Bosch service.

8. SPECIFICATIONS

Feature	Detail
Model Number	06008A0601
Product Dimensions	50 x 50 x 28 cm
Weight	1.3 kg
Voltage	18 Volt
Power Source	Battery powered
Sound Level	94 dB
Special Feature	Lightweight
Recommended Use	Debris removal
Components Included	UniversalLeafBlower 18V-130, cardboard packaging
Batteries Included?	No
Batteries Required?	Yes



Leggero e compatto

Pesa solo 1,6 kg e ha un'impugnatura ergonomica confortevole.



Figure 8.1: Dimensions of the UniversalLeafBlower 18V-130, highlighting its compact and lightweight design.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Bosch website. You can also contact Bosch customer service for assistance with product registration, technical support, or spare parts.

For more information on the Bosch 18V System, visit the Bosch Store on Amazon.