

SpeaKa SP-10461516

SpeaKa Professional SP-SHC-200 SCART to HDMI Converter User Manual

Model: SP-10461516

INTRODUCTION

The SpeaKa Professional SP-SHC-200 SCART to HDMI Converter allows you to connect older video sources with a SCART output to modern displays or televisions with an HDMI input. This device upscales the video signal to either 720p or 1080p, providing improved picture quality on high-definition screens. It supports NTSC/PAL/SECAM video standards and includes features like frame-based noise reduction and deinterlacing for a clearer image.

SETUP INSTRUCTIONS

Follow these steps to connect your SpeaKa Professional SP-SHC-200 converter:

1. **Connect the SCART Input:** Insert the SCART cable from your video source (e.g., DVD player, VCR, game console) into the "Scart Input" port on the converter.



Image: Rear view of the SpeaKa Professional SP-SHC-200 converter, showing the SCART input port labeled "Scart Input".

2. **Connect the HDMI Output:** Connect an HDMI cable from the "HDMI Output" port on the converter to an available

HDMI input on your television or monitor.

3. **Connect Audio Output (Optional):** If desired, connect a 3.5mm stereo audio cable from the "Stereo-Out" port on the converter to an audio receiver or speakers.



Image: Front view of the SpeakA Professional SP-SHC-200 converter, showing the HDMI Output, Stereo-Out, and DC/5V PWR ports, along with the 1080P/720P resolution switch.

4. **Connect Power:** Plug the included DC/5V power adapter into the "DC/5V PWR" port on the converter and then into a standard electrical outlet. The device will power on automatically.

OPERATING INSTRUCTIONS

Once all connections are made and the device is powered on, follow these steps to operate your converter:

1. **Select Input on Display:** Switch your television or monitor to the correct HDMI input channel where the converter is connected.
2. **Power On Source Device:** Turn on your SCART video source device (e.g., VCR, DVD player). The video signal should now appear on your HDMI display.
3. **Adjust Output Resolution:** The converter features a switch to select the output resolution between 720p and 1080p. Locate the switch labeled "1080P" and "720P" on the converter.



Image: Close-up of the SpeaKa Professional SP-SHC-200 showing the resolution switch between 1080P and 720P.

- Slide the switch to "1080P" for a Full HD resolution output.
- Slide the switch to "720P" for an HD resolution output.

Choose the resolution that best suits your display and content. It is recommended to try both settings to determine which provides the optimal viewing experience.

MAINTENANCE

To ensure the longevity and optimal performance of your SpeaKa Professional SP-SHC-200 converter, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or aerosols, as they may damage the unit.
- **Storage:** When not in use for extended periods, store the converter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping or subjecting the device to strong impacts. Handle all cables and connectors gently to prevent damage.
- **Ventilation:** Ensure the device has adequate ventilation and is not covered, to prevent overheating.

TROUBLESHOOTING

If you encounter issues with your SpeaKa Professional SP-SHC-200 converter, please refer to the following common problems and solutions:

- **No Picture on Display:**

- Ensure all cables (SCART, HDMI, power) are securely connected.
- Verify that your display is set to the correct HDMI input.
- Check if the SCART source device is powered on and outputting a signal.
- Try switching the resolution toggle (720p/1080p) on the converter.

- **No Audio:**

- Ensure the HDMI cable is properly connected, as HDMI carries both video and audio.
- If using the 3.5mm Stereo-Out, verify the cable is connected to an active audio input on your receiver/speakers.
- Check the audio settings on your source device.

- **Poor Picture Quality / Distorted Image:**

- Ensure the SCART cable is of good quality and fully inserted.
- Try switching the output resolution between 720p and 1080p. Some older SCART sources may look better at 720p.
- Verify that the source video standard (NTSC/PAL/SECAM) is compatible.

- **Device Not Powering On:**

- Check the power adapter and ensure it is correctly plugged into both the converter and a working power outlet.
- Try a different power outlet.

SPECIFICATIONS

Brand	SpeaKa Professional
Model Number	SP-10461516
Input	1 x SCART
Output	1 x HDMI, 1 x 3.5mm Stereo Audio
Supported Resolutions	720p, 1080p (switchable)
Supported Video Standards	NTSC, PAL, SECAM
Color	Grey
Dimensions (L x W x H)	7 x 6.3 x 2.4 cm
Weight	76 Grams
Power Supply	DC 5V

WARRANTY INFORMATION

This SpeaKa Professional product comes with a 1-year availability of spare parts. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact your retailer.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your SpeaKa Professional SP-SHC-200 converter, please contact your point of purchase or visit the official SpeaKa Professional website for support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question