

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar Eastand Pedestal Fan User Manual

Aigostar 330100A1D

Aigostar Eastand Pedestal Fan User Manual

Model: 330100A1D

Brand: Aigostar

INTRODUCTION

Thank you for choosing the Aigostar Eastand Pedestal Fan. This manual provides important information for the safe and efficient use of your fan. Please read it thoroughly before assembly and operation, and keep it for future reference.




Image: The Aigostar Eastand Pedestal Fan in a room, demonstrating its wide airflow.

Key Features

- **Wide Airflow:** Designed with 9 blades to produce a soft and wide airflow at a lower noise level compared to typical 3-blade fans.
- **3 Adjustable Speeds:** Offers low, medium, and high wind speeds to suit different situations and temperatures, ideal for various locations like offices and homes.
- **85-Degree Oscillation:** Provides wide coverage of air circulation with an 85° oscillation and an adjustable tilt head for flexible wind angle.
- **Adjustable Height:** The fan's height is fully adjustable to meet your needs. A heavy fan base ensures great stability during operation, preventing tipping.

MotorMotore Potente

RPM: 1200 r/min



Installazione
Facile



Pale di
alta qualità



Potenza
nominale di 60W




Image: Illustration of the fan's powerful motor, highlighting its efficient performance.

Low Noise

Quiet Fan For Bedroom,
Bring Cool And Comfy Feeling At Night



Image: Diagram illustrating the low noise level of the Aigostar Pedestal Fan (23dB), making it suitable for quiet environments like bedrooms.

SETUP AND ASSEMBLY

Follow these steps to assemble your Aigostar Eastand Pedestal Fan. Ensure all parts are present before beginning.



Image: Visual guide for fan assembly, showing the base, pole, motor, and fan head components.

1. **Step 1: Assemble the Base.** Insert the bottom pole into the heavy base and secure it firmly.
2. **Step 2: Secure the Pole.** Place the base cover and tighten the securing nut to ensure stability.
3. **Step 3: Adjust Height.** Loosen the height adjustment knob on the main pole, extend to desired height, and tighten the knob.
4. **Step 4: Attach Motor Unit.** Slide the motor unit onto the top of the adjustable pole and secure it.
5. **Step 5: Install Fan Blades and Grills.** Attach the rear grill, then the fan blades, securing them with the provided nuts. Finally, attach the front grill and secure it.

Ensure all connections are secure before plugging in the fan.

OPERATING INSTRUCTIONS

Familiarize yourself with the fan's controls for optimal performance.

Control Panel

Oscillazione Diffusa a 75°

Sentire la Brezza da ogni angolo della stanza




Image: Close-up of the fan's control panel, showing buttons for speed selection (0, 1, 2, 3).

The control panel is located on the main body of the fan. It features buttons for power and speed selection.

Speed Settings

- **0:** Off
- **1 (Low):** Gentle breeze, ideal for quiet environments like bedrooms.
- **2 (Medium):** Moderate airflow, suitable for general cooling.
- **3 (High):** Powerful airflow for maximum cooling.



Image: The fan oscillating horizontally, illustrating its 85-degree wide angle coverage.

Oscillation Function

To activate the oscillation, press down the knob located on top of the motor housing. To stop oscillation, pull the knob up.

Adjusting Fan Head Angle

The fan head can be tilted vertically to direct airflow. Gently push or pull the fan head to adjust its angle.

Adjusting Height




Image: Comparison of the fan at its minimum and maximum adjustable heights, illustrating the 20cm range.

To adjust the fan's height, loosen the height adjustment knob on the main pole, slide the pole to your desired height, and then firmly tighten the knob to secure it.

MAINTENANCE AND CARE

Regular cleaning and maintenance will ensure the longevity and efficient operation of your fan.

- **Always unplug the fan** from the power outlet before cleaning or performing any maintenance.
- **Cleaning the Exterior:** Wipe the exterior surfaces of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Cleaning the Grills and Blades:** Dust can accumulate on the fan blades and grills, reducing airflow. Periodically remove the front grill (refer to assembly instructions in reverse) and gently wipe the blades and inside of the grills with a soft, dry or slightly damp cloth. Ensure all parts are completely dry before reassembling and operating the fan.
- **Storage:** If storing the fan for an extended period, clean it thoroughly, then store it in a cool, dry place, preferably in its original packaging to protect it from dust and damage.

TROUBLESHOOTING

If you encounter any issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet not working; Fan switch is off.	Ensure the fan is securely plugged into a working electrical outlet. Check if the power switch is in the "On" position.
Weak airflow.	Fan blades or grills are dirty; Fan is on a low speed setting.	Clean the fan blades and grills as described in the Maintenance section. Increase the fan speed setting.
Fan is noisy.	Loose parts; Fan not on a stable surface; Dirt in motor.	Check for any loose screws or parts and tighten them. Place the fan on a flat, stable surface. If noise persists, contact customer support.
Oscillation not working.	Oscillation knob not engaged.	Ensure the oscillation knob on top of the motor housing is pressed down firmly.

If the problem persists after trying these solutions, please contact Aigostar customer support.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	Aigostar
Model Number	330100A1D
Product Dimensions (L x W x H)	28 x 42.5 x 123 cm
Item Weight	3.3 Kilograms
Power	45 Watts
Voltage	240 Volts
Number of Blades	9
Oscillation Angle	85 degrees
Adjustable Height Range	Approx. 103 cm to 123 cm

WARRANTY AND SUPPORT

Aigostar is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this manual, we encourage you to retain your proof of purchase for any warranty claims.

For any concerns, questions, or support needs regarding your Aigostar Eastand Pedestal Fan, please do not hesitate to contact Aigostar customer service. Your satisfaction is our pleasure, and we will address any issues with our products.

You can typically find contact information on the product packaging or the official Aigostar website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BV1JC4V8>

More documents and user manuals: **<https://manuals.plus/>**