Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok RC902V FMR4

Azwok RC902V FMR4 IR Remote Control User Manual

For TCL QLED TV Models: 65X925, 75X925, 50P725G, 55C728, 75C728

Introduction

This manual provides comprehensive instructions for the Azwok RC902V FMR4 Infrared (IR) Remote Control. This remote is designed as a direct replacement for specific TCL QLED TV models, offering essential functions without the need for complex programming. Please read this manual carefully to ensure proper setup and operation.

Setup

Battery Installation

The Azwok RC902V FMR4 remote control requires two AAA batteries (not included) for operation. No programming is required; the remote will function immediately upon correct battery installation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Rear view of the remote control with the battery cover removed, illustrating the correct placement for two AAA batteries.

Once batteries are installed, the remote is ready for use with compatible TCL QLED TV models.

Operating Instructions

The Azwok RC902V FMR4 is an Infrared (IR) remote control. Ensure there is a clear line of sight between the remote and your TV's IR receiver for optimal performance. This remote does not support voice control functions.





Image: Front view of the Azwok RC902V FMR4 remote control, displaying the layout of all buttons including power, navigation, volume, channel, and dedicated app buttons.

Key Functions

- **Power Button:** Turns the TV on or off.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select options.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Accesses the TV's main home screen.
- **Volume Up/Down:** Adjusts the TV's volume level.
- **Channel Up/Down:** Changes TV channels.
- **Mute Button:** Mutes or unmutes the TV's audio.
- **Settings Button:** Opens the TV's settings menu.
- **Dedicated App Buttons:** Provides quick access to popular streaming services like Netflix, Prime Video, YouTube, and TCL Channel.

Maintenance

Cleaning

To maintain the remote control's appearance and functionality, clean it regularly:

- Use a soft, dry cloth to wipe the surface of the remote.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

Storage

If the remote control will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage to the remote.

Troubleshooting

If you encounter issues with your Azwok RC902V FMR4 remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure batteries are correctly installed with the proper polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's IR receiver.
  - Confirm you are within the effective range of the TV's IR receiver.
- **Specific Buttons Not Working:**
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be interfering with button presses.
  - If only specific buttons are not working after cleaning and battery replacement, the remote may be defective.
- **TV Model Compatibility:**
  - This remote is specifically designed for TCL QLED TV models 65X925, 75X925, 50P725G, 55C728, and 75C728. If your TV model is not listed, the remote may not be compatible.
  - If you are unsure about compatibility, please contact customer support for assistance.

Specifications

Feature	Detail
Product Dimensions	8.27 x 1.57 x 0.51 inches
Item Weight	2.11 ounces
Model Number	RC902V FMR4
Batteries Required	2 AAA batteries (not included)
Special Feature	No Programming Required
Compatible Devices	Television (TCL QLED TV models: 65X925, 75X925, 50P725G, 55C728, 75C728)
Color	Black

Warranty and Support

Warranty Information

This Azwok RC902V FMR4 remote control comes with a**12-month replacement warranty**. If the product is found to be defective or incompatible with the specified models within this period, a replacement will be provided.

Customer Support

For any questions regarding product compatibility, setup, or troubleshooting that are not covered in this manual, please contact Azwok customer support. We are available to assist you in ensuring the correct remote control for your device.

© 2023 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BV2C8L2T

More documents and user manuals: **https://manuals.plus/**