

[manuals.plus](#) /

- › [Brook](#) /
- › [Brook Wingman XE 2 Converter Instruction Manual](#)

**Brook XE2**

## Brook Wingman XE 2 Converter Instruction Manual

Model: XE2

Brand: Brook

### 1. INTRODUCTION

The Brook Wingman XE 2 Converter is a versatile wireless controller adapter designed to bridge compatibility between various gaming controllers and consoles. It allows users to utilize their preferred controllers, including PS5, PS4, PS3, Switch Pro, Xbox Series X/S/One/Elite 2, and USB wired Xbox controllers, across PlayStation (PS4, PS3), Nintendo Switch, and PC (Direct-Input) platforms. This converter enhances the gaming experience by offering features such as adjustable turbo levels and button remapping, ensuring a lag-free connection.



Image: Brook Wingman XE 2 Converter and its retail packaging.

## 2. PACKAGE CONTENTS

- Brook Wingman XE 2 Converter x 1

## 3. SPECIFICATIONS

Feature	Detail
Product Dimensions	3.03 x 0.79 x 0.51 inches
Item Weight	0.5 ounces
Model Number	XE2

Compatible Devices	Nintendo Switch, PlayStation 4, PlayStation 3
Specific Uses For Product	PC, Video Game Console
Connector Type	USB Type A
Color	Blue
Manufacturer	Brook
Country of Origin	China

## 4. SETUP GUIDE

---

### 4.1 First-Time Setup and Firmware Update

Before initial use, it is crucial to ensure your Wingman XE 2 firmware is updated to the latest version. Visit the official Brook website for the most current firmware and update instructions. After updating, connect the converter to your gaming console via its USB port. The device will then be registered and ready for use.

### 4.2 Connecting to Consoles

The Wingman XE 2 supports connection to PlayStation 4, PlayStation 3, Nintendo Switch, and PC. Simply plug the converter into an available USB port on your desired console.

# **SUPPORT** **PS4 / PS3 / NS / NS2 / PC**

**Support cross-platform Just follow your bent**



Image: The Wingman XE 2 Converter connected to a console, demonstrating its compatibility.

## **4.3 Connecting Controllers**

The Wingman XE 2 supports a wide range of controllers, both wired and wireless. Each converter can pair with one device at a time.

### **Wired Connection:**

For wired controllers (e.g., Xbox Series X/S/One/Elite1&2 on PS4, PS3, Switch, PC), simply connect the controller's USB cable to the female USB port on the Wingman XE 2 converter. The constant blue indicator on the converter signifies a successful connection.

### **Wireless Connection:**

For wireless controllers (e.g., PS5/PS4/PS3, Switch Pro, XB Series X/S/One/Elite 2), connect the controller to the Wingman XE 2 via its USB cable initially. Once the blue indicator on the converter is constantly on, you can remove the USB cable from the controller. The controller is now wirelessly connected.



Image: Close-up of the Wingman XE 2 Converter showing its blue indicator lights.

Video: Detailed setup and connection guide for the Brook Wingman XE 2 Converter.

## 5. OPERATING INSTRUCTIONS

### 5.1 Adjustable Turbo Levels

The Wingman XE 2 allows you to set adjustable turbo levels for rapid button presses. There are 5 available turbo frequencies: 5, 10, 15, 20, and 25 clicks per second. This feature is useful for games requiring quick, repetitive inputs.

# SELF-DEFINE TURBO SPEED



Setting of turbo frequency with five levels.

The highest combo: 25 times per second, just with one button to make speed off the chart easily.



Image: Visual representation of the five adjustable turbo speed levels.

## 5.2 Remap Function

The remap function allows you to customize button assignments on your controller. This enables you to configure the buttons in a way that suits your personal gaming style, potentially simplifying complex maneuvers into single button presses.



## **SELF-DEFINED BUTTON LAYOUT**

**Take control of the button layout on your controller.  
Succeed in compound moves with one button.  
Create the exclusive gaming style of your own.**

Image: Illustration of the self-defined button layout feature.

Video: Overview of the Brook Wingman XE 2 features, including turbo and remap functions.

### **6. CONTROLLER COMPATIBILITY**

The Wingman XE 2 boasts extensive controller compatibility, supporting over 125 different wireless and wired controllers. This includes, but is not limited to, PS5, PS4, PS3, Switch Pro, Xbox Series X/S/One, and Xbox Elite 1 & 2 controllers.

# Fighting Stick & Controller



## PS4, PS3 NS, NS2 PC (Direct-Input)




Image: Detailed diagram illustrating various supported controllers and their connection types.

For a comprehensive list of all supported controllers, please visit the official Brook website.

## 7. TROUBLESHOOTING

- Connection Issues:** If the converter is not recognized or a controller frequently disconnects, ensure the Wingman XE 2 is securely plugged into the console's USB port. Try a different USB port if available.
- Controller Not Responding:** Verify that the controller is fully charged (if wireless) and properly paired with the converter. Re-pair the controller if necessary.
- Feature Malfunction (Turbo/Remap):** Ensure you are following the correct button combinations for setting up or canceling these features as outlined in the operating instructions.
- Performance Issues:** Ensure your Wingman XE 2 has the latest firmware installed. Firmware updates often include performance improvements and bug fixes.

## 8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the converter. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the converter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Handling:** Handle the converter with care to prevent physical damage to the USB connector or the device itself.

## 9. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official Brook website or the user guide provided with your product. You can also find additional resources and FAQs on their support pages.

A digital version of the user guide is available at: [User Guide \(PDF\)](#)

© 2023 Brook. All rights reserved.

### Related Documents - XE2

	<p><a href="#">Brook Wingman XE 2 Converter User Guide</a></p> <p>User guide for the Brook Wingman XE 2, a controller converter adapter compatible with PlayStation, Nintendo Switch, and PC. Learn about setup, firmware updates, Turbo, and Remap functions.</p>
	<p><a href="#">Brook Wingman FGC 2 User Guide</a></p> <p>Comprehensive user guide for the Brook Wingman FGC 2, covering firmware updates, product usage, software settings, and troubleshooting. Includes multi-language support.</p>
	<p><a href="#">Brook Wingman FGC 2 User Guide</a></p> <p>A comprehensive user guide for the Brook Wingman FGC 2, covering firmware updates, product usage, software settings, and manual configurations. Learn how to enhance your gaming experience with this versatile converter.</p>

	<p><a href="#"><u>Brook Wingman NS Lite Converter User Guide</u></a></p> <p>This guide provides instructions for using the Brook Wingman NS Lite Converter, a wireless controller adapter for Nintendo Switch, Switch OLED, Switch Lite, and PC. It details connection steps, LED indicators, wireless pairing, and advanced features like Turbo and Button Remap settings for various controllers including Xbox, PlayStation, and Switch Pro.</p>
	<p><a href="#"><u>Brook Wingman PS2 Converter User Manual</u></a></p> <p>Comprehensive user manual for the Brook Wingman PS2 Converter, detailing connection, LED display, button mapping, turbo function, remapping, and input mode switching for various game consoles and controllers.</p>
	<p><a href="#"><u>Brook Wingman FGC Firmware Update Guide</u></a></p> <p>Official guide for updating the firmware of the Brook Wingman FGC gaming converter. Includes step-by-step instructions, download links, and troubleshooting tips.</p>