

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fysic](#) /
- › [Fysic FX-6000 Cordless Phone User Manual](#)

## Fysic FX-6000

# Fysic FX-6000 Cordless Phone User Manual

Model: FX-6000

## 1. INTRODUCTION

Thank you for purchasing the Fysic FX-6000 Cordless Phone. This DECT phone is designed for ease of use, featuring large keys, a clear backlit display, and excellent sound quality, making it ideal for users with impaired vision or hearing. This manual provides essential information for setting up, operating, and maintaining your new phone.

## 2. SAFETY INFORMATION

- Use only the supplied power adapter and batteries.
- Do not expose the phone to water or moisture.
- Avoid placing the phone near heat sources or direct sunlight.
- Keep the phone away from strong electromagnetic fields.
- Do not attempt to open or repair the phone yourself. Contact qualified service personnel.
- Dispose of batteries responsibly according to local regulations.

## 3. PACKAGE CONTENTS

Please check that all items are present in your package:

- Fysic FX-6000 Handset
- Base Station
- Power Adapter
- Telephone Line Cord
- Rechargeable Batteries (NiMH)
- User Manual (this document)

## 4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Fysic FX-6000 phone.



**Image 4.1:** Fysic FX-6000 Cordless Phone Handset and Base Station. The handset features a large display and keypad, resting in a sleek black base station.



**Image 4.2:** Diagram illustrating the components of the Fysic FX-6000 handset. Key features include the handset speaker, indicator light, display, direct memory keys (M1, M2, M3), phone function keys, keypad, handset microphone, and charging contacts at the bottom.

## Handset Features:

- **Handset Speaker:** For listening during calls.
- **Indicator Light:** Flashes for incoming calls, lights up constantly when the BOOST function is active.
- **Display:** Large, backlit screen for clear information display.
- **Direct Memory Keys (M1, M2, M3):** For quick dialing of frequently used numbers.
- **Navigation Buttons (Up/Down):** For menu navigation and volume adjustment.
- **Phone Function Keys:** Including Call, End Call, Phonebook, and other operational buttons.
- **Keypad:** Large, clear numeric keys for dialing.
- **Handset Microphone:** For speaking during calls.
- **Charging Contacts:** Located at the bottom of the handset for charging when placed in the base station.

## 5. SETUP

### 5.1. Installing the Batteries

1. Open the battery compartment cover on the back of the handset.
2. Insert the supplied rechargeable NiMH batteries, observing the correct polarity (+/-).
3. Close the battery compartment cover securely.

### 5.2. Connecting the Base Station

1. Connect one end of the telephone line cord to the LINE port on the base station.
2. Connect the other end of the telephone line cord to your telephone wall socket.
3. Connect the power adapter to the DC IN port on the base station.
4. Plug the power adapter into a standard electrical outlet.

### 5.3. Initial Charging

Place the handset on the base station. The handset will begin charging. For optimal battery performance, allow the handset to charge for at least 12-15 hours before its first use, even if the display indicates a full charge earlier.

## 6. OPERATING INSTRUCTIONS

### 6.1. Making a Call

1. Pick up the handset or press the **Call** button (green receiver icon).
2. Dial the desired phone number using the keypad.
3. Press the **Call** button again if you picked up the handset first, or wait for the call to connect.

## 6.2. Answering a Call

When the phone rings, press the **Call** button (green receiver icon) to answer the call.

## 6.3. Ending a Call

Press the **End Call** button (red receiver icon) or place the handset back on the base station.

## 6.4. Adjusting Ringer and Call Volume

The ringer and call volume can be set to a very loud level. Use the **Up** and **Down** navigation buttons during a call or while in standby mode to adjust the volume.

## 6.5. Using Direct Memory Keys (M1, M2, M3)

1. To store a number: Refer to the phone's menu for instructions on assigning numbers to M1, M2, and M3.
2. To dial a stored number: Press the desired memory key (M1, M2, or M3) and then press the **Call** button.

## 6.6. Phonebook

The phonebook can store up to 50 contacts. Refer to the on-screen menu for instructions on adding, editing, and deleting contacts.

## 6.7. Flashing Indicator Light

The indicator light on the handset will flash when there is an incoming call, providing a visual alert in addition to the ringer. It will light up constantly when the BOOST function is active.

# 7. MAINTENANCE

- Clean the phone with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure the charging contacts on both the handset and base station are clean to ensure proper charging.
- If the phone will not be used for an extended period, remove the batteries from the handset.

# 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No dial tone	Telephone line cord not connected or faulty.	Check the telephone line cord connection. Try another phone line if available.
Handset not charging	Handset not correctly placed on base; dirty charging contacts; faulty batteries.	Ensure handset is properly seated. Clean charging contacts. Replace batteries if old.

Problem	Possible Cause	Solution
Poor sound quality	Out of range; interference; low battery.	Move closer to the base station. Avoid other electronic devices. Charge handset.
Display is blank	Low battery; handset not powered on.	Place handset on base to charge. Press and hold the power/end call button to turn on.
Cannot make/receive calls	No line connection; handset not registered to base.	Check line connection. Refer to the full manual for handset registration instructions.

## 9. SPECIFICATIONS

- **Model:** Fysic FX-6000
- **Type:** DECT Cordless Phone
- **Color:** Black
- **Display:** Large, backlit
- **Phonebook Capacity:** Up to 50 contacts
- **Indoor Range:** Up to 50 meters
- **Outdoor Range:** Up to 300 meters
- **Standby Time:** >100 hours
- **Talk Time:** Up to 10 hours
- **Hearing Aid Compatible:** Yes
- **Caller ID:** Yes
- **Manufacturer:** Lenco GmbH
- **Date First Available:** February 7, 2023

## 10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your purchase or visit the official Fysic website. Keep your proof of purchase for warranty claims.

**Spare parts availability:** Information unavailable

**Software updates guaranteed until:** Information unavailable

