

[Manuals.plus](#) /

› [Lomiluskr](#) /

› Lomiluskr Cute Bunny Wireless Mouse (Model B0BV389T3M) Instruction Manual

Lomiluskr B0BV389T3M

Lomiluskr Cute Bunny Wireless Mouse Instruction Manual

MODEL: B0BV389T3M

Introduction

Thank you for choosing the Lomiluskr Cute Bunny Wireless Mouse. This lightweight, soundless, 2.4G wireless optical mouse is designed for comfortable and efficient use with various computer systems. Its unique bunny-inspired design adds a touch of charm to your workspace. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new mouse.



Image: The Lomilusk Cute Bunny Wireless Mouse in pink, showcasing its design.

Setup

1. Battery Installation

1. Gently slide open the battery compartment cover located on the underside of the mouse.
2. Insert one (1) AA battery, ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

2. USB Receiver Connection

1. Locate the USB receiver, which is typically stored inside the battery compartment for safekeeping.
2. Plug the USB receiver into an available USB port on your PC or laptop.
3. The mouse will automatically connect to your device. No additional drivers are required for most operating systems.



Image: The underside of the mouse showing the battery compartment and the USB receiver.

Setup Demonstration Video

Your browser does not support the video tag.

Video: A demonstration of the Cute Bunny 2.4G Wireless Mouse, including its lightweight design and candy colors. This video provides a visual guide to the product's features and handling.

Operating Instructions

Basic Functions

- **Left Click:** Use the left button for selecting items, opening applications, and confirming actions.
- **Right Click:** Use the right button to access context menus and additional options.
- **Scroll Wheel:** Roll the wheel up or down to navigate through documents and web pages. The scroll wheel also functions as a middle click button.



Image: A hand demonstrating the use of the Lomilusk Cute Bunny Wireless Mouse on a desk surface.

DPI (Dots Per Inch)

The mouse operates at 1200 DPI, which is suitable for general office and daily use. If you need to adjust the pointer movement speed, please do so through your computer's operating system settings.

Standby Mode

The mouse is designed to enter standby mode after 3-5 minutes of inactivity to conserve battery life. To wake it up, simply click any of the buttons.

Maintenance

Battery Replacement

When the mouse's performance decreases or it stops responding, it may be time to replace the AA battery. Follow the battery installation steps in the Setup section to replace the battery.

Cleaning

To clean the mouse, use a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the surface.

Troubleshooting

If the Mouse is Not Responding:

1. Insert the USB receiver into a USB port of your PC and wait for the driver to be installed automatically. (Skip this step if the driver is already installed).
2. Remove the USB receiver and take out the battery from the mouse.
3. Plug the receiver back into the same USB port, then install the battery within 10 seconds. Ensure the distance between the mouse and receiver is less than 20cm during this process.
4. After the pairing is completed automatically, the mouse can be used within a 10m range.
5. Ensure the battery has sufficient charge. Replace with a new AA battery if necessary.

Specifications

Connection Method	2.4Ghz Wireless
Product Dimensions	3.7 x 2.44 x 1.42 inches
Item Weight	3.17 ounces
Number of Buttons	3 buttons
DPI	1200
Compatible With	Windows, Mac
Batteries	1 AA battery required (included)
Special Features	Lightweight, Soundless, Wireless
Movement Detection Technology	Optical

Warranty and Support

Product Guarantee

All Lomilusk products undergo quality inspection before shipping. If any quality issues arise with the product within one year of purchase, we offer a refund or a free replacement.

Contact Support

If you have any questions or require further assistance, please feel free to contact Lomilusk customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BV389T3M>

More documents and user manuals: **<https://manuals.plus/>**