

## SPLATRBALL SRB370

# SPLATRBALL SRB370 Water Bead Blaster Kit Instruction Manual

Model: SRB370

## 1. INTRODUCTION

The SPLATRBALL SRB370 Full Auto Water Bead Blaster is designed for outdoor recreational use, firing 7.5mm Splat-R-Ball water bead ammunition. This blaster features a 375-round internal reservoir and can shoot up to 7 rounds per second at a velocity of up to 135 feet per second. The water balls are soft, non-staining, and require virtually no cleanup, as they disintegrate on impact. This manual provides essential information for the safe and effective operation of your blaster.

**Important Safety Note: Do not aim for eyes.**

## 2. WHAT'S INCLUDED

Your SPLATRBALL SRB370 Blaster Kit includes the following components:

- One Water Ball Blaster with 375-round internal reservoir
- Sling Clip
- 2,500 rounds of certified SplatRBall water ball beads
- Rechargeable 7.4V 500 mAh battery
- USB charging cable
- Foldable water ball loading funnel
- Safety Glasses

## 3. SETUP

### 1. Prepare Water Beads:

Place the 2,500 SplatRBall water beads in a container with plenty of water. Allow them to soak for at least 4 hours, or until they expand to 7.5mm in diameter. Ensure they are fully hydrated for optimal performance and to prevent jamming.

### 2. Charge the Battery:

Locate the USB charging port on the blaster. Connect the provided USB charging cable to the blaster and to a compatible USB power source (e.g., wall adapter, computer USB port). The battery is a rechargeable 7.4V 500 mAh unit. Allow sufficient time for a full charge before first use.

**3. Load Water Beads:**

Unscrew the cap from the internal reservoir on top of the blaster. Use the foldable water ball loading funnel to carefully pour the hydrated water beads into the reservoir. Ensure the reservoir is securely closed after loading.

**4. Attach Sling Clip (Optional):**

If desired, attach the sling clip to the designated attachment points on the blaster for easier carrying during play.

**5. Wear Safety Glasses:**

Always wear the provided safety glasses before operating the blaster to protect your eyes from stray water beads.



Figure 1: Close-up view of the ammo loading port on the SplatRBall SRB370 Blaster. The green tab indicates the opening for pouring water beads into the internal reservoir.



Figure 2: The rechargeable 7.4V 500mAh battery and its accompanying USB charging cable, essential for powering the blaster.



Figure 3: The safety glasses provided in the kit, crucial for eye protection during blaster operation.

## 4. OPERATING INSTRUCTIONS

---

### 1. Power On/Off:

Locate the power switch on the blaster. Slide the switch to the 'ON' position to activate the blaster.

### 2. Select Firing Mode:

The blaster features a two-position selector switch: 'Safe' and 'Full Auto'. Move the switch to 'Full Auto' for continuous firing. Ensure the switch is in 'Safe' mode when not in use.

### 3. Firing:

Once powered on and in 'Full Auto' mode, press the trigger to fire water beads. The blaster will shoot approximately 7 water balls per second.



Figure 4: The selector switch on the side of the blaster, allowing users to choose between 'Safe' and 'Full Auto' firing modes.

## 5. MAINTENANCE

- **Cleaning:** The water balls are non-staining and designed for virtually no cleanup. Any residue can typically be rinsed with water.
- **Storage:** Store the blaster in a cool, dry place away from direct sunlight. Ensure the battery is fully charged before long-term storage.
- **Battery Care:** Do not overcharge or completely drain the battery. Follow charging instructions carefully.

## 6. TROUBLESHOOTING

- **Blaster Not Firing:**
  - Check if the battery is charged.

- Ensure the power switch is in the 'ON' position.
  - Verify the firing mode selector is set to 'Full Auto'.
  - Confirm there are sufficient water beads in the reservoir.
- **Gel Beads Jamming:**
    - Ensure water beads are fully hydrated to the correct 7.5mm size.
    - Only use certified SplatRBall water ball beads.
    - Clear any obstructions from the loading port or barrel.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	950007
Ammunition Type	7.5mm SplatRBall Water Beads
Reservoir Capacity	375 Rounds (Internal)
Rate of Fire	Up to 7 rounds per second
Velocity	Up to 135 feet per second
Battery	Rechargeable 7.4V 500 mAh Lithium Ion
Charging	USB Charging Cable (Included)
Operation Mode	Full Automatic
Material	Plastic
Color	White
Item Weight	2 Pounds
Item Dimensions (L x W x H)	16"L x 2.63"W x 8.5"H

## 8. SAFETY WARNINGS

- **Eye Protection:** Always wear safety glasses when operating or near the blaster.
- **Target Safely:** Do not aim at eyes or face.
- **Age Recommendation:** Recommended for users aged 14 years and older.
- **Ammunition:** Use only certified SplatRBall water ball beads. Other gel beads may damage the blaster or not meet safety standards.
- **Water Exposure:** Do not put water directly into the blaster's hopper or internal mechanisms, as this can cause permanent damage to electronics.
- **Supervision:** Adult supervision is recommended for younger users.

## 9. WARRANTY & SUPPORT

For warranty information, product support, or to purchase additional accessories and water beads, please visit the official SPLATRBALL website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

SPLATRBALL Official Store: [Visit the SPLATRBALL Store](#)