

- › [MASTER & DYNAMIC](#) /
- › [MASTER & DYNAMIC MC300 Wireless Charge Pad and Headset Stand User Manual](#)

## MASTER & DYNAMIC MC300

# MASTER & DYNAMIC MC300 Wireless Charge Pad and Headset Stand User Manual

## INTRODUCTION

---

The MASTER & DYNAMIC MC300 is a 2-in-1 device designed to provide both a stable display for your headphones and a convenient wireless charging solution for compatible devices. It features a premium aluminum stand and a machined aluminum charge pad for efficient power delivery and heat dissipation. The unit also includes an additional USB-C port for wired charging of other compatible devices.



Image: The MC300 Wireless Charge Pad and Headset Stand, showcasing its sleek design.

## WHAT'S IN THE BOX

---

Carefully unpack the contents and ensure all items are present:

- Wireless Charge Pad
- 1m USB-C to USB-C Power Cable
- 20cm USB-C to USB-C Charging Cable
- Headphone Stand Attachment
- Magnetic Cable Holder



Image: The individual components of the MC300, including the base, stand, and cables.

## SETUP INSTRUCTIONS

---

### 1. Assembly of the Headphone Stand

1. Locate the headphone stand attachment and the wireless charge pad base.
2. Gently push down the collar located at the center of the charge pad base.
3. Insert the bottom end of the headphone stand attachment into the opening in the charge pad base.
4. Release the collar to secure the stand firmly in place. Ensure the stand is stable before proceeding.



Image: The underside of the MC300 base, showing the textured surface and connection points for the stand.

## 2. Power Connection

1. Connect the 1m USB-C to USB-C power cable to the designated power input port on the MC300 charge pad.
2. Connect the other end of the power cable to a suitable USB power adapter (not included) and plug it into a wall outlet.
3. The MC300 is now ready for use.



Image: The MC300 stand with the USB-C power cable connected to the base.

## OPERATING INSTRUCTIONS

---

### 1. Headphone Stand Use

The MC300 provides a dedicated space to store and display your headphones.

- Carefully place your headphones over the top curved arm of the stand.
- Ensure the headphones are balanced and securely resting on the stand.



Image: A pair of headphones neatly displayed on the MC300 Headset Stand.

## 2. Wireless Charging

The charge pad supports wireless charging for compatible devices.

- Place your wireless charging compatible device (e.g., smartphone, earbuds case) onto the center of the charge pad.
- For MagSafe compatible devices, the charge pad offers an easy magnetic connection.

- Ensure the device is properly aligned for optimal charging. A charging indicator on your device should confirm charging has begun.



Image: Headphones on the stand, with a wireless earbud case charging on the base pad.

### 3. Additional Wired Charging

The MC300 includes a second USB-C port for wired charging.

- Connect the provided 20cm USB-C to USB-C charging cable to the secondary USB-C port on the MC300.
- Connect the other end of this cable to your headphones or other compatible devices that require wired charging.

Video: A short demonstration of the MC300 in a minimalist setup, showing its aesthetic integration and function as a base station for headphones and other items.

## COMPATIBILITY

---

The MC300 Wireless Charge Pad and Headset Stand is compatible with:

- Master & Dynamic headphones.
- Other compatible headphones that fit the stand's dimensions.
- Wireless charging compatible devices, including iPhone 8 and newer mobile digital devices.
- MagSafe compatible devices for magnetic wireless charging.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your MC300, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the aluminum surfaces and the coated canvas threading. Avoid abrasive cleaners or solvents that may damage the finish.
- **Storage:** When not in use for extended periods, store the MC300 in a cool, dry place.
- **Handling:** Handle the stand with care to prevent scratches or damage to the aluminum components.

## TROUBLESHOOTING

---

If you encounter issues with your MC300, refer to the following common problems and solutions:

Problem	Solution
Device not wirelessly charging.	<ul style="list-style-type: none"><li>• Ensure the MC300 is properly connected to power.</li><li>• Verify your device is wireless charging compatible.</li><li>• Reposition the device on the center of the charge pad.</li><li>• Remove any thick cases from your device that may interfere with charging.</li></ul>
Headphone stand is unstable.	<ul style="list-style-type: none"><li>• Ensure the stand attachment is fully inserted and the collar is released to secure it.</li><li>• Place the MC300 on a flat, stable surface.</li></ul>
Wired charging not working.	<ul style="list-style-type: none"><li>• Check that the 20cm USB-C cable is securely connected to both the MC300 and your device.</li><li>• Ensure the MC300 is receiving power.</li><li>• Test with a different USB-C cable if available.</li></ul>

## SPECIFICATIONS

---

Feature	Detail
Product Dimensions	5.51 x 5.51 x 11.18 inches
Item Weight	15.9 ounces
Model Number	MC300
Brand	MASTER & DYNAMIC
Color	Black (Gunmetal/Black Canvas variant)
Compatible Devices	Headphones, iPhone 8 and newer, MagSafe compatible devices

## IMPORTANT SAFETY INFORMATION

---

Please read and follow these safety guidelines to prevent damage to the product or injury to yourself:

- Do not expose the device to water or excessive moisture.
- Avoid extreme temperatures.
- Do not attempt to disassemble or modify the device. This will void the warranty.
- Keep out of reach of children.
- Use only the provided cables or certified compatible cables for power and charging.

## WARRANTY AND SUPPORT

---

MASTER & DYNAMIC products are designed for durability and performance. For specific warranty details, please refer to the warranty card included with your product or visit the official MASTER & DYNAMIC website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact MASTER & DYNAMIC customer service through their official website or the contact information provided in your product packaging.

**Online Support:** [www.masterdynamic.com/support](http://www.masterdynamic.com/support)