LAUSAINT HOME BSSGPCT010C1

LAUSAINT HOME 10x10ft Heavy Duty Patio Gazebo Instruction Manual

Model: BSSGPCT010C1

Introduction

Thank you for choosing the LAUSAINT HOME 10x10ft Heavy Duty Patio Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This gazebo features a thickened galvanized steel frame for enhanced stability, a 1500MM water-resistant canopy with UPF 50+ UV protection, a ventilated double-tier roof with mesh for improved airflow and insect protection, and includes privacy curtains and mosquito nettings. It is designed for outdoor use in various settings such as patios, decks, gardens, and lawns.



Image: Fully assembled LAUSAINT HOME 10x10ft gazebo with curtains tied back, providing shade and an inviting outdoor space.

Safety Information

- **Assembly:** Always assemble the gazebo with at least two adults. Ensure all parts are correctly aligned and securely fastened.
- **Anchoring:** For maximum stability and long-term outdoor use, always secure the gazebo with the provided ground stakes or expansion bolts. Failure to do so may result in damage or injury.
- **Weather Conditions:** This gazebo is designed for general outdoor use. During extreme weather conditions such as strong winds (above Level 6), heavy rain, storms, or snow, remove the canopy, curtains, and netting to prevent damage and extend product lifespan.
- **Fire Safety:** Keep all flame and heat sources away from the gazebo fabric. The fabric is not fireproof.
- **Maintenance:** Regularly inspect the frame and fabric for any signs of wear or damage. Replace worn parts

immediately.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Galvanized Steel Frame Components (various poles, connectors, and base plates)
- Main Canopy Fabric (1500MM water-resistant, UV 50+ protection)
- Double-Tier Roof Vent Fabric
- Mosquito Netting (with zippers)
- Privacy Curtains (with zippers and velcro straps)
- Expansion Bolts (12 pcs for concrete/deck installation)
- Ground Stakes (12 pcs for lawn/soil installation)
- Wind-Resistant Ropes (4 pcs)
- Assembly Hardware (screws, washers, nuts, Allen key)

Setup and Assembly

Assembly typically requires two people. Follow the numbered steps in your included assembly guide for detailed diagrams. Ensure you have adequate space and all tools before starting.

1. **Frame Assembly:** Connect the main support poles and crossbeams according to the diagrams. Ensure all connections are secure.
2. **Roof Frame Assembly:** Assemble the upper roof frame structure.
3. **Canopy Installation:** Carefully drape the main canopy fabric over the assembled roof frame. Ensure the double-tier vent is properly positioned.
4. **Securing the Canopy:** Zip up the top cover of the gazebo. This video demonstrates the process:

   Video: Demonstration of zipping up the top cover of the gazebo canopy.

5. **Attaching Netting and Curtains:** Attach the mosquito netting and privacy curtains to the frame tracks. Ensure zippers are functional.
6. **Anchoring the Gazebo:** Secure the gazebo to the ground using the appropriate hardware for your surface.

   Image: Close-up view of the gazebo's base plate, showing the pre-drilled holes and included expansion bolts for secure ground attachment.

   - For concrete or wooden decks, use the provided expansion bolts.
   - For lawns or soil, use the provided ground stakes.
   - Utilize the wind-resistant ropes for additional stability, especially in areas prone to wind.




Image: The gazebo with wind-resistant ropes extended and secured, demonstrating an additional measure for stability.

Operating Instructions

Mosquito Netting and Privacy Curtains

- The gazebo includes both mosquito netting and privacy curtains, which can be operated independently on separate tracks.
- Use the integrated zippers to fully close the netting or curtains for complete enclosure.
- When not in use, the curtains and netting can be tied back to the gazebo legs using the attached velcro straps for an open feel.




Image: Close-up of the premium track design, allowing curtains and nettings to be operated separately for versatile use.




Image: Detail of the durable zippers on both the privacy curtains and mosquito nettings, ensuring a secure closure.

Ventilation and Airflow

The double-tier roof design promotes air circulation, reducing heat buildup and enhancing wind resistance. The mesh between the roof tiers helps keep insects out while maintaining airflow.



Image: Diagram illustrating the airflow through the vented double roof, highlighting its role in heat reduction and insect deterrence.

Ceiling Hook and Corner Rings

- A central ceiling hook is provided for hanging a fan or pendant light (maximum weight capacity: 44 lbs).
- Four built-in D-rings are located at the corners for attaching decorative items such as string lights or wind chimes.



Image: Close-up of the corner rings, designed for hanging decorative lights or other accessories.

Maintenance

- **Cleaning:** Clean the canopy and curtains with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as this may damage the fabric's water-resistant and UV-protective coatings. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Wipe the galvanized steel frame with a damp cloth to remove dirt and debris. Periodically check all bolts and connections to ensure they remain tight.
- **Seasonal Storage:** For prolonged periods of non-use or during severe weather, it is recommended to remove the canopy, curtains, and netting. Store them in a dry, protected area to prevent mildew and extend their lifespan.
- **Drainage:** The canopy is designed with drainage holes to prevent water buildup. Ensure these holes remain clear of debris.



Image: Close-up view of the upgraded, thickened fabric used for the gazebo canopy and curtains, designed for durability and anti-fading properties.

Troubleshooting

- **Gazebo Instability:** Ensure all frame connections are tightened. Verify that the gazebo is properly anchored to the ground using either expansion bolts or ground stakes, and that wind-resistant ropes are deployed if necessary.
- **Water Pooling on Canopy:** Check that the canopy is installed correctly and taut. Ensure drainage holes are clear of debris. If pooling persists, adjust the canopy tension.
- **Difficulty with Zippers/Curtains:** Ensure tracks are clear of obstructions. Apply a silicone-based lubricant to zippers if they are stiff.
- **Fabric Tears/Wear:** Inspect for sharp edges on the frame that might be rubbing against the fabric. Ensure the canopy is removed during extreme weather to prevent stress.

Specifications

Feature	Detail
Brand	LAUSAINT HOME
Model Number	BSSGPCT010C1
Dimensions	10'x10' (100 square feet floor area)
Frame Material	Galvanized Iron
Canopy Material	Polyester
Water Resistance Level	1500MM Water Resistant
UV Protection	UV 50+
Roof Type	Double-Tier, Vented with Mesh
Included Accessories	Mosquito Netting, Privacy Curtains, Expansion Bolts, Ground Stakes, Wind Ropes
Ceiling Hook Capacity	44 lbs

Warranty and Support

LAUSAINT HOME stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official LAUSAINT HOME website. If you encounter any issues during assembly or use, or if you require replacement parts, please contact LAUSAINT HOME customer support directly. Have your model number (BSSGPCT010C1) and purchase information ready when contacting support.

Visit the LAUSAINT HOME Store for more information

© 2026 LAUSAINT HOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question