

[Manuals.plus](#) /

› [TUSY](#) /

› TUSY 7-Drawer Organizer Instruction Manual

TUSY TUSY

TUSY 7-Drawer Organizer Instruction Manual

Model: TUSY

Brand: TUSY

1. INTRODUCTION

Thank you for choosing the TUSY 7-Drawer Organizer. This tall chest of drawers is designed to provide ample and versatile storage for your home office, living room, studio, kitchen, or closet. Its minimalist design and practical features make it a valuable addition to any space. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your product.





Figure 1: Front view of the TUSY 7-Drawer Organizer.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** Do not exceed the total weight capacity of 160 lbs. Distribute weight evenly across drawers.
- **Anti-Tipping:** For enhanced safety, especially in households with children, utilize the included anti-dumping design to secure the unit to a wall.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use.
- **Children Safety:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the unit.
- **Stability:** Ensure the unit is placed on a flat, stable surface. If using caster wheels, ensure the lockable wheels are engaged when the unit needs to remain stationary.



Figure 2: Key features including anti-dumping design and locking casters.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Side Panels (2)
- Top Panel (1)
- Bottom Panel (1)
- Drawer Fronts (7)
- Drawer Side Panels (14)
- Drawer Back Panels (7)
- Drawer Bottom Panels (7)

- Drawer Slides (14 pairs)
- Caster Wheels (4, 2 lockable)
- Assembly Hardware (screws, dowels, cam locks, anti-tipping kit)
- Illustrated Instruction Manual (1)

4. SETUP AND ASSEMBLY

The TUSY 7-Drawer Organizer is designed for easy assembly. Follow the detailed illustrated instructions provided in your package. It is recommended to have a Phillips head screwdriver and a hammer for assembly. Assembly typically takes approximately 1-2 hours for one person.

Assembly Steps Overview:

1. Attach drawer slides to the side panels of the main cabinet.
2. Assemble the main cabinet frame using the top, bottom, and side panels.
3. Install the caster wheels onto the bottom panel of the cabinet.
4. Assemble each of the seven drawers individually.
5. Insert the assembled drawers into the cabinet.
6. Secure the anti-tipping device to the wall and the cabinet.



Figure 3: Product dimensions for planning placement.

Assembly Video:

Video 1: Official Installation Video for the TUSY 7-Drawer Chest. This video provides a visual guide for the assembly process, demonstrating each step in detail.

5. OPERATING INSTRUCTIONS

The TUSY 7-Drawer Organizer is designed for simple and efficient use.

- **Drawer Operation:** Each drawer features a user-friendly concave handle for easy opening and closing. The smooth runners ensure effortless gliding.
- **Mobility:** The chest is equipped with four universal wheels for easy movement. Two of these casters are lockable, allowing you to secure the unit in place when needed. To move, unlock the wheels and gently push or pull the unit. To secure, engage the locks on the two front casters.
- **Storage:** Utilize the seven spacious drawers to organize various items such as office supplies, documents, craft

materials, cosmetics, or small apparel. The vertical design maximizes storage in compact spaces.



Figure 4: Example of ample storage capacity with drawers open.

6. MAINTENANCE

To maintain the appearance and functionality of your TUSY 7-Drawer Organizer, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Promptly clean any spills to prevent staining or damage to the particle board.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Environment:** Avoid prolonged exposure to direct sunlight or extreme humidity, which can affect the material's integrity.

7. TROUBLESHOOTING

If you encounter any issues with your TUSY 7-Drawer Organizer, refer to the common problems and solutions below:

- **Drawers are difficult to open/close:**
 - Check if the drawer slides are correctly installed and aligned.
 - Ensure no items are obstructing the drawer's path or are overloaded.
 - Verify that all assembly screws for the drawers and cabinet frame are tightened.
- **Unit feels wobbly or unstable:**
 - Confirm that the unit is placed on a flat and level surface.
 - Retighten all assembly screws on the main cabinet frame.
 - Ensure the anti-tipping device is properly installed and secured to the wall.
- **Caster wheels are not rolling smoothly or locking:**
 - Check for any debris or hair caught in the wheels.
 - Ensure the wheels are securely attached to the bottom panel.
 - Verify that the locking mechanism is fully engaged or disengaged.

If the issue persists, please contact TUSY customer support for further assistance.

8. SPECIFICATIONS

Brand	TUSY
Product Dimensions	14"D x 15.8"W x 34.3"H
Color	White
Mounting Type	Free Standing
Room Type	Home Office, Study Room, Living Room, Kitchen, Closet
Special Feature	4 universal wheels (2 lockable), Anti-dumping design
Furniture Finish	Engineered Wood
Drawer Type	Side Mount
Product Care Instructions	Wipe with Dry Cloth
Assembly Required	Yes
Item Weight	49 Pounds
Number of Pieces	1

Date First Available

February 8, 2023

9. WARRANTY AND SUPPORT

The TUSY 7-Drawer Organizer comes with a **Limited Warranty**. Please refer to the warranty information included in your product packaging for specific terms and conditions.

For any questions about the product, missing parts, assembly assistance, or warranty claims, please contact TUSY customer service. Our professional service team is dedicated to ensuring your satisfaction.

Contact Information:

Please refer to the contact details provided on the product packaging or the official TUSY website.

© 2024 TUSY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question