**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**JVC LT-32VAF5355**

# JVC LT-32VAF5355 32 Inch Android TV User Manual

Your guide to setting up, operating, and maintaining your JVC Smart TV.

## 1. Introduction

Thank you for purchasing the JVC LT-32VAF5355 32 Inch Full HD Android TV. This manual provides essential information to help you set up, operate, and troubleshoot your new television. Please read this manual thoroughly before using the product and keep it for future reference.

The JVC LT-32VAF5355 offers impressive Full HD resolution, HDR 10 support, a versatile triple tuner, and the extensive features of Android TV, including Google Assistant and Chromecast built-in.

## 2. What's in the Box

Carefully unpack your television and check that all the following items are included:

- JVC LT-32VAF5355 32 Inch Android TV
- Remote control
- 2 x AAA batteries (for remote control)

## 3. Setup

### 3.1 Initial Placement and Connections

Place the TV on a stable, flat surface or mount it on a wall using a compatible VESA mount (75x75mm). Ensure adequate ventilation around the TV.




Image: Rear view of the JVC TV showing available connection ports including HDMI, USB, CI+ Slot, Ethernet, VGA, Headphone Output, Optical Audio Output, and Antenna (RF/F).

Connect the power cable to the TV and then to a wall outlet. Insert the supplied AAA batteries into the remote control, observing the polarity markings.

## 3.2 Antenna/Cable/Satellite Connection

The integrated triple tuner allows reception via antenna (DVB-T2), cable (DVB-C), or satellite (DVB-S2). Connect your antenna, cable, or satellite dish to the corresponding input on the TV.

## 3.3 First-Time Setup Wizard

Upon first power-on, the TV will guide you through the initial setup process. This includes:

- Language selection
- Network connection (Wi-Fi or Ethernet)
- Google account sign-in (recommended for full Android TV features)
- Channel scanning (DVB-T2/C/S2)
- Privacy settings





Image: The JVC Android TV home screen, showing popular streaming applications like Netflix, YouTube, and Prime Video.

# 4. Operating Your TV

## 4.1 Basic TV Functions

- **Power On/Off:** Press the power button on the remote control or on the TV.
- **Channel Selection:** Use the P+/P- buttons or number buttons on the remote.
- **Volume Control:** Use the V+/V- buttons.
- **Input Source:** Press the 'Source' button to switch between HDMI, TV, USB, etc.

## 4.2 Smart TV Features (Android TV)

Your JVC TV runs on Android TV, providing access to a vast array of entertainment and smart features.




Image: The remote control for the JVC TV, featuring quick access buttons for Netflix, YouTube, and Prime Video.

- **Google Play Store:** Download and install your favorite apps, games, and streaming services directly on your TV.
- **Streaming Services:** Access popular platforms like Netflix, Prime Video, Disney+, YouTube, DAZN, and more.




Image: A visual representation of the Google Play ecosystem, highlighting various supported streaming applications available on the TV.

### 4.3 Google Assistant

Control your TV and smart home devices using your voice with Google Assistant. Simply say "Ok Google" or press the Google Assistant button on your remote to activate it.

- Change channels, adjust volume, open apps.
- Search for movies, shows, or information.
- Control compatible smart home devices.




Image: The 'Works with Ok Google' logo, indicating voice control functionality with the TV.

### 4.4 Google Chromecast Built-in

Easily cast content from your smartphone, tablet, or computer directly to your TV using Chromecast built-in. Look for the Cast icon in compatible apps.

## 5. Features

### 5.1 Picture Quality

Experience content in modern Full HD resolution. The TV supports HDR 10 including HLG, as well as Super Resolution & Micro Dimming, delivering high-contrast images with natural colors and impressive detail sharpness.




Image: Logos for HDR10, Super Resolution, and Micro Dimming, illustrating the advanced picture technologies.


## 5.2 Connectivity

The TV offers numerous connection options:

- 3 x HDMI (CEC + ARC) for connecting game consoles, Blu-ray players, soundbars.
- 2 x USB with media player for playing content from USB drives.
- WLAN (Wi-Fi) for wireless internet connection.
- Bluetooth for connecting external sound devices or headphones.

## 5.3 Optimal Viewing Distance

For the best viewing experience, consider the recommended seating distance based on your TV's size and resolution.




| Größe | Empfohlener Sitzabstand bei | | |
|---|---|---|---|
| | 4K | Full HD | HD |
| 24" | | | ca. 150 cm |
| 32" | | ca. 160 cm | ca. 200 cm |
| 40" | | ca. 204 cm | |
| 43" | ca. 162 cm | ca. 216 cm | |
| 50" | ca. 189 cm | | |
| 55" | ca. 209 cm | | |
| 65" | ca. 246 cm | | |
| 70" | ca. 266 cm | | |

Image: A chart detailing optimal viewing distances for different TV sizes (24", 32", 40", 43", 50", 55", 65", 70") across 4K, Full HD, and HD resolutions.

## 6. Maintenance

### 6.1 Cleaning

Always unplug the TV before cleaning. Use a soft, dry cloth to wipe the screen and cabinet. For stubborn marks, a slightly damp cloth with a mild, non-abrasive cleaner can be used, but never spray liquid directly onto the screen.

### 6.2 Software Updates

Your Android TV may receive software updates periodically to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates. You can check for updates manually in the TV's settings menu.

## 7. Troubleshooting

If you encounter issues with your TV, try the following common troubleshooting steps:

- **No Power:** Check if the power cable is securely connected and the wall outlet is working.
- **No Picture/Sound:** Verify the correct input source is selected. Check cable connections to external devices.
- **Remote Not Responding:** Ensure batteries are correctly inserted and not depleted. Point the remote directly at the TV's IR sensor.
- **Slow Performance/App Issues:** Restart the TV by unplugging it from the power outlet for a few minutes. Clear app caches in the settings. If issues persist, a factory reset may be necessary (note: this will erase all personal settings and downloaded apps).
- **No Satellite Signal:** Ensure your satellite dish is correctly aligned and the cable is securely connected.

## 8. Specifications

Detailed technical specifications for the JVC LT-32VAF5355:

| Feature | Specification |
|---|---|
| Model Number | LT-32VAF5355 |
| Screen Size | 32 Inches (82 cm) |
| Resolution | 1080p (Full HD) |
| Display Technology | LED |
| Refresh Rate | 50 Hz |
| Special Features | Chromecast, Google Play Store, HDR10, HLG, Super Resolution, Micro Dimming |
| Connectivity | Bluetooth, USB (2x), HDMI (3x, CEC+ARC), WLAN (Wi-Fi) |
| Supported Internet Services | Netflix, Disney Plus, Prime Video, YouTube, DAZN, etc. |
| Product Dimensions (W x H x D) | 72.6 x 48 x 17.4 cm (with stand) |
| Weight | 4.35 kg |
| Batteries | 2 AAA batteries (included) |
| Manufacturer | JVC |

### 8.1 Energy Efficiency

The JVC LT-32VAF5355 has an energy efficiency rating of E (based on new EU energy label standards).



JVC LT-32VAF5355





**26** kWh/1000h

ABCDEF**G**

HDR

**45** kWh/1000h




2019/2(




Image: The EU Energy Label for the JVC LT-32VAF5355, indicating its energy efficiency class and annual energy consumption.

For more details, refer to the official EU Product Data Sheet: EPREL Database Link

## 9. Warranty and Support

Your JVC LT-32VAF5355 television comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical support, service, or warranty claims, please contact JVC customer support through their official website or the contact information provided in your product documentation.

© 2023 JVC. All rights reserved. Information in this manual is subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0BV78242C**

More documents and user manuals: **https://manuals.plus/**