

[Manuals.plus](#) /

› [Cybex](#) /

› Cybex Gazelle S All-in-One Toddler and Baby Stroller Instruction Manual

Cybex 522004813

Cybex Gazelle S All-in-One Toddler and Baby Stroller

INSTRUCTION MANUAL

Model: 522004813

Introduction

The Cybex Gazelle S is a versatile all-in-one stroller designed to adapt to your growing family's needs. It offers over 20 modular configurations, allowing it to function as a single stroller, a double stroller for siblings or twins, or even accommodate three children with an additional ride-on board (sold separately). Featuring ergonomic near-flat recline seats, a large shopper basket, and a compact fold, the Gazelle S provides comfort and convenience for daily use.

This manual provides essential information for the safe and proper assembly, operation, and maintenance of your Cybex Gazelle S stroller. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Cybex Gazelle S stroller in Moon Black, showcasing its sleek design and robust frame.

What's in the Box

Upon unboxing your Cybex Gazelle S stroller, please ensure all components are present and undamaged. The standard package includes:

- Stroller Frame
- Seat Pack (main seat)
- Bumper Bar
- Shopping Basket
- Gazelle Car Seat Adapters
- Cup Holder
- Gazelle Rain Cover

WHAT'S IN THE BOX?

GAZELLE S



Car Seat Adapters



Cup Holder



Rain Cover

Image: A visual representation of the Cybex Gazelle S components, including the stroller frame, seat pack, shopping basket, bumper bar, car seat adapters, cup holder, and rain cover.

Setup

The Cybex Gazelle S is designed for intuitive assembly. Follow these general steps for initial setup:

1. **Unfold the Frame:** Release the folding latch and extend the stroller frame until it locks securely into place. Ensure all locking mechanisms are engaged.
2. **Attach the Wheels:** Insert the front and rear wheels into their respective slots until they click. Verify they are firmly attached by pulling on them.
3. **Install the Seat Unit:** Align the seat unit with the frame connectors and push down until it clicks into place. The seat can be installed facing forward or rearward.
4. **Attach Accessories:** Secure the bumper bar, cup holder, and shopping basket as indicated in the detailed assembly guide (refer to the included printed manual for specific diagrams).

For detailed visual instructions on setting up various configurations, including double stroller setups, please refer to the official video below:

Video: Official Cybex demonstration of the Gazelle S 2 Double Stroller setup and various configurations. This video provides a comprehensive guide to assembling and transforming your stroller.



Image: The Cybex Gazelle S stroller configured for single use, demonstrating its readiness for initial setup.

Operating

The Cybex Gazelle S offers a range of functionalities for ease of use:

- **Folding the Stroller:** The Gazelle S features a compact fold, even with one or two seats attached. To fold, ensure the handlebar is at its lowest position, then locate the folding mechanisms (typically levers or buttons on the handlebar or frame) and activate them while pushing the handlebar forward and down. The stroller will collapse into a compact unit.
- **Reclining the Seat:** The seat offers an ergonomic near-flat recline position. Locate the recline lever on the back of

the seat and adjust to your desired angle.

- **Adjusting the Harness:** The one-pull harness system allows for quick and secure fastening. Pull the strap to tighten the harness around your child. To release, press the button on the buckle.
- **Adjusting the Handlebar:** The handlebar height can be adjusted to suit different users. Press the buttons on either side of the handlebar and move it up or down to the desired height.
- **Using the Brakes:** The foot brake is located near the rear wheels. Press down to engage the brake and lift up to release. Always engage the brake when the stroller is stationary.



Image: The Cybex Gazelle S showcasing its reversible and reclining seat functionality, providing comfort for the child.



*COT S LUX, INFANT CAR SEAT AND SECOND SEAT SOLD SEPARATELY

Image: A diagram illustrating the over 20 modular configurations possible with the Cybex Gazelle S, highlighting its adaptability.

Video: An in-depth official Cybex video demonstrating various operational aspects of the Gazelle S stroller, including folding, adjusting, and configuring.

Maintenance

Proper maintenance ensures the longevity and safety of your Cybex Gazelle S stroller:

- **Fabric Care:** Wash fabric components separately. Use a gentle action wash with warm water. Do not bleach, tumble dry, iron, or dry clean. Refer to the care label on each fabric part for specific instructions.
- **Frame Cleaning:** Wipe the frame and plastic parts with a damp cloth and mild detergent. Dry thoroughly.
- **Wheel Maintenance:** Regularly check the wheels for debris and clean as needed. Ensure wheels spin freely.
- **Lubrication:** Periodically lubricate moving parts, such as wheel axles and folding mechanisms, with a silicone-based lubricant to ensure smooth operation.
- **Storage:** Store the stroller in a dry place, away from direct sunlight and extreme temperatures, to prevent material

degradation.

Troubleshooting

If you encounter issues with your Cybex Gazelle S stroller, consider the following common solutions:

- **Stroller Not Folding/Unfolding Smoothly:** Ensure all locking mechanisms are disengaged. Check for any obstructions in the folding mechanism. Lubricate moving parts if resistance persists. If the recline lever is not working, it may prevent proper folding; ensure it is functioning correctly.
- **Wheels Not Turning Freely:** Check for debris (e.g., dirt, hair) wrapped around the axles. Clean the wheels and lubricate if necessary.
- **Harness Not Securing:** Ensure the harness straps are not twisted and the buckle components are clean and free of obstructions. Verify the one-pull adjustment mechanism is functioning correctly.
- **Seat Not Reclining:** Check the recline lever for any obstructions or damage. Ensure the seat is correctly installed on the frame.

If problems persist after attempting these solutions, please contact Cybex customer support for further assistance.

Specifications

Feature	Detail
Brand	Cybex
Model Number	522004813
Color	Moon Black
Material	Aluminum, Mesh
Fabric Type	Mesh
Frame Material	Metal
Age Range Description	Toddler (From birth with infant car seat or Gazelle S Cot, sold separately, to approx. 4 years)
Included Components	Gazelle Car Seat Adapters, Cup Holder and Gazelle Rain Cover
Item Height	42.7 inches
Item Weight	28.4 Pounds
Folded Size (L x W x H)	32.9" L x 25.4" W x 12.2" H
Maximum Weight Recommendation	50 Pounds (per seat)
Basket Weight Capacity Maximum	25 Pounds (lower basket) + 25 Pounds (shopper basket) = 50 lbs total
Harness Type	5 Point, One-Pull
Stroller Type	Modular Stroller

Seating Capacity	Up to 3 (with ride-on board, sold separately)
Care Instructions	Wash separately. Gentle action wash warm water, do not bleach, do not tumble dry, do not iron, do not dry clean
Certifications	ASTM, JPMA



Image: A diagram showing the key dimensions of the Cybex Gazelle S stroller (length, width, height).

Warranty & Support

The Cybex Gazelle S stroller comes with a **2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship when the product is used under normal conditions and in accordance with the instruction manual.

For warranty claims, technical support, or any questions regarding your stroller, please contact Cybex customer service through their official website or the retailer from whom you purchased the product. Please have your model number and proof of purchase readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question