



Manuals.plus /

› Liebherr /

› Liebherr CNbdd 5733 Refrigerator-Freezer Instruction Manual

Liebherr CNbdd 5733

Liebherr CNbdd 5733 Refrigerator-Freezer Instruction Manual

Model: CNbdd 5733 | Brand: Liebherr

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Liebherr CNbdd 5733 refrigerator-freezer. Please read it thoroughly before using the appliance and keep it for future reference.

The Liebherr CNbdd 5733 is a combi refrigerator-freezer unit, featuring a refrigerator compartment above and a freezer compartment below, designed for household use. It comes in an Inox Graphite finish.

2. SAFETY INSTRUCTIONS

Always observe the following safety precautions to prevent personal injury or damage to the appliance.

2.1 General Safety

- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments.
- Keep ventilation openings clear of obstruction.
- Unplug the appliance before cleaning or maintenance.

2.2 Installation Safety

- Place the appliance on a firm, level surface.
- Ensure adequate ventilation around the appliance.
- Do not install near heat sources or in direct sunlight.
- Allow sufficient space for door opening.

3. SETUP AND INSTALLATION

Follow these steps for proper setup and installation of your Liebherr CNbdd 5733.

3.1 Unpacking

Carefully remove all packaging materials. Inspect the appliance for any transport damage. Report any damage immediately to your supplier.

3.2 Positioning

Place the appliance in a suitable location, away from direct sunlight and heat sources. Ensure there is sufficient space for air circulation around the back and sides of the unit. The product dimensions are approximately 50 x 50 x 28 cm.



Figure 3.2.1: The Liebherr CNbdd 5733 refrigerator-freezer positioned in a kitchen, showing its overall size and appearance with the door open.



Figure 3.2.2: A wider view of the Liebherr CNbdd 5733 refrigerator-freezer in a kitchen environment, illustrating its design and how it fits into a modern living space.

3.3 Electrical Connection

Connect the appliance to a properly installed and grounded power outlet. The voltage and frequency must match the specifications on the rating plate.

3.4 Initial Start-up

After connecting, allow the appliance to stand for at least 4 hours before switching it on. This allows the refrigerant to settle. Once switched on, allow it to cool for several hours before loading with food.

4. OPERATING INSTRUCTIONS

This section details how to operate your Liebherr CNbdd 5733 refrigerator-freezer.

4.1 Temperature Control

The appliance features separate temperature controls for the refrigerator and freezer compartments. Use the digital display on the door to adjust settings. The recommended refrigerator temperature is 5°C, and the freezer temperature is -18°C.



Figure 4.1.1: The Liebherr CNbdd 5733 refrigerator-freezer with its door closed, highlighting the integrated digital display for temperature control and settings.

4.2 Interior Features

The refrigerator compartment includes adjustable glass shelves, door bins, and a BioFresh compartment for optimal storage of fruits and vegetables. The freezer compartment has multiple drawers for organized storage.



Figure 4.2.1: An interior view of the Liebherr CNbdd 5733 refrigerator-freezer, showcasing its various shelves, drawers, and door compartments filled with food items.



Figure 4.2.2: A clear interior view of the Liebherr CNbdd 5733 refrigerator-freezer, showing the empty shelves, drawers, and door storage, highlighting the internal layout.

4.3 SmartDevice Functionality (if applicable)

If your model is equipped with SmartDevice, you can connect it to the Liebherr SmartDevice app for remote control and monitoring. Refer to the separate SmartDevice manual for detailed instructions.

5. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and longevity of your appliance.

5.1 Cleaning the Interior

Before cleaning, unplug the appliance. Clean the interior with a soft cloth and a mild, non-abrasive cleaning solution. Rinse with clean water and dry thoroughly. Do not use abrasive cleaners or sharp objects.

5.2 Defrosting

The freezer compartment features a hot gas defrost system, minimizing the need for manual defrosting. However, if ice buildup occurs, manually defrost by unplugging the unit and allowing ice to melt naturally. Do not use sharp objects to remove ice.

5.3 Cleaning the Exterior

Clean the exterior surfaces, especially the Inox Graphite finish, with a soft, damp cloth. For stainless steel parts, use a specialized stainless steel cleaner. Avoid harsh chemicals.



Figure 5.3.1: The Liebherr CNbdd 5733 refrigerator-freezer with its door slightly open, providing a closer look at the Inox Graphite exterior finish.



Figure 5.3.2: A side view of the Liebherr CNbddd 5733 refrigerator-freezer, illustrating the depth and design of the appliance from an angle.

6. TROUBLESHOOTING

Before contacting customer service, consult this table for common issues and their solutions.

Problem	Possible Cause	Solution
Appliance not cooling	No power; temperature setting too high; door not closed properly.	Check power supply; adjust temperature; ensure door is sealed.
Excessive noise	Appliance not level; objects vibrating against the unit.	Adjust leveling feet; remove vibrating objects.
Water on floor	Drain hole blocked; excessive humidity.	Clear drain hole; ensure proper ventilation.

7. TECHNICAL SPECIFICATIONS

Key technical data for the Liebherr CNbdd 5733.

Model: CNbdd 5733

Brand: Liebherr

Configuration: Freezer-on-Bottom

Colour: Silver (Inox Graphite)

Installation Type: Freestanding

Number of Doors: 2

Defrost System: Hot gas defrost

Finish Type: Stainless steel

Product Dimensions: 50 x 50 x 28 cm (approximate)

Item Weight: 190 g (Note: This weight seems unusually low for a refrigerator-freezer and might be a data entry error in the source. Please refer to the product's official specifications for accurate weight.)

Manufacturer: LIEBHERR

8. WARRANTY AND SUPPORT

Your Liebherr CNbdd 5733 appliance comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty period and coverage.

For technical support, spare parts, or service requests, please contact Liebherr customer service or your authorized dealer. Have your model number (CNbdd 5733) and serial number ready when contacting support.

You can find more information and contact details on the official Liebherr website:home.liebherr.com

