Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EUHOMY IM-06S-HM

EUHOMY Countertop Ice Maker Machine

User Manual

Product Overview

The EUHOMY Countertop Ice Maker Machine (Model: IM-06S-HM) is a portable and efficient appliance designed to provide fresh bullet ice quickly. With a daily ice production capacity of up to 26 lbs and a rapid ice-making cycle of 6 minutes for 9 ice cubes, it's ideal for home, kitchen, camping, RVs, and parties. Its compact design, handle, and self-cleaning function make it user-friendly and convenient.



Image: EUHOMY Countertop Ice Maker Machine in Light Grey, with ice cubes and a glass of iced drink.

Important Safety Information

WARNING: Risk of Fire or Explosion. Flammable Refrigerant Used.

- Do not use mechanical devices to defrost the ice maker.
- Do not puncture refrigerant tubing.
- This unit should be properly grounded for your safety. It is equipped with a three-prong plug which mates with standard wall outlets to minimize the possibility of electric shock.
- Plug your appliance into an exclusive, properly installed, grounded wall outlet. Do not under any circumstances, cut

or remove the third (ground) prong from the power cord. If you have questions concerning power and/or grounding, consult a qualified electrician.

- This appliance requires a standard 110-120 V, 60 Hz electrical outlet with a three-prong grounded connection.
- Before using the ice maker for the first time, please leave it standing upright for at least 24 hours before plugging it in. This is an important prerequisite for a good ice-making effect.

What's in the Box

- EUHOMY Ice Maker Machine
- Ice Basket
- Ice Scoop
- User Manual



Image: Diagram showing the ice maker, removable ice basket, and ice scoop, along with product specifications.

Setup and First Use

1. **Unpack and Position:** Carefully remove the ice maker from its packaging. Place it upright on a stable, level surface away from direct sunlight and heat sources. Ensure proper ventilation around the unit.
2. **Allow to Settle:** Before plugging in, let the ice maker stand upright for at least 24 hours. This allows the refrigerant to settle, which is crucial for optimal performance.
3. **Clean Before Use:** It is recommended to run the self-cleaning cycle at least once before first use. (See Maintenance section for details).
4. **Add Water:** Open the top cover and remove the ice basket. Pour potable water into the water reservoir up to the "MAX" fill line. The reservoir has a 1.2L capacity.

5. **Plug In:** Connect the ice maker to a grounded 110-120V, 60Hz electrical outlet.



Image: Visual guide showing the three simple steps to operate the ice maker: adding water, pressing the power button, and scooping ice.

Operating Instructions

1. **Start Ice Making:** After adding water and plugging in, press the "ON/OFF" button on the control panel. The "POWER" indicator light will turn green.
2. **Ice Production:** The ice maker will begin producing bullet-shaped ice cubes. The first batch of 9 ice cubes will be ready in approximately 6 minutes. The machine can produce up to 26 lbs of ice per day.
3. **Smart Indicators:**
    - The "ICE FULL" indicator will flash when the ice basket is full, signaling you to remove the ice to prevent overflowing. The machine will pause ice production.
    - The "ADD WATER" indicator will flash when the water reservoir is low, reminding you to add more water. The

machine will pause until water is refilled.

4. **Collecting Ice:** Use the provided ice scoop to remove ice from the basket. The bullet-shaped ice cubes are smooth and less likely to stick together.



Image: Close-up of the easy-to-use control panel with indicator lights for "ADD WATER", "ICE FULL", and "POWER", along with the "ON/OFF" button.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and operation of the Euhomy Countertop Ice Maker, including its handle, ice production, and smart indicators.

Maintenance

Automatic Self-Cleaning

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the "ON/OFF" button for 5 seconds.
3. The ice maker will enter automatic cleaning mode, which runs for approximately 30 minutes. The "ADD WATER" and "ICE FULL" indicators may flash alternately during this cycle.
4. Once the cleaning cycle is complete, drain the water from the machine by opening the drain plug located at the bottom.
5. Wipe the interior dry with a soft cloth.



Image: Diagram illustrating the automatic self-cleaning process, showing water circulation within the machine.

Regular Cleaning

- Regularly clean the ice basket and scoop with mild detergent and warm water. Rinse thoroughly.
- Wipe the exterior of the machine with a soft, damp cloth.

- For prolonged storage, ensure the unit is completely drained and dry before storing in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
"ADD WATER" indicator flashing	Water reservoir is empty or low.	Add potable water to the reservoir up to the MAX line.
"ICE FULL" indicator flashing	Ice basket is full.	Remove ice from the basket.
Ice maker not producing ice	Not plugged in, insufficient water, or unit not settled.	Ensure unit is plugged in, add water, and allow 24 hours to settle before first use.
Ice melts quickly in basket	The ice maker is not a freezer and does not keep ice frozen.	Transfer ice to a freezer for long-term storage.

Specifications

Feature	Detail
Brand	EUHOMY
Model Name	ice maker
Model Number	IM-06S-HM (HZB-12H)
Product Dimensions	11.42"D x 8.74"W x 11.57"H
Weight	12.9 pounds
Ice Production per Day	26 Pounds
Water Tank Capacity	1.2L
Ice Basket Capacity	1.3 lbs
Wattage	170 watts
Voltage	115 Volts
Refrigerant	R600a
Material	Stainless Steel

Feature	Detail
Color	Light Grey

Warranty and Support

EUHOMY offers 12-month after-sales service from the original purchase date and technical service support. If you have any questions about using your Ice Maker, please contact customer support for assistance.
For further assistance, you may refer to the official User Manual (PDF) available at:
https://manuals.plus/m/395a3f16efaf343d4febdac9d7c1d1ac7e8fd2c4d290eb8948b7fb92ded6f80e

© 2025 EUHOMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BV9Z8ZFV

More documents and user manuals: **https://manuals.plus/**