Dyberg Larsen 8223

Dyberg Larsen Morph D21 Black Table Lamp User Manual

Model: 8223

1. Introduction

Thank you for purchasing the Dyberg Larsen Morph D21 Black Table Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before installation and operation, and retain them for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the lamp is unplugged before cleaning or changing the bulb.
- Do not operate the lamp with a damaged cord or plug.
- Do not expose the lamp to water or excessive moisture.
- Use only the specified bulb type and wattage. Refer to the lamp's label for details.
- Keep the lamp away from flammable materials.
- This lamp is designed for indoor use only.

3. Package Contents

Carefully unpack your lamp and check that all items are present and undamaged. If any parts are missing or damaged, please contact your retailer.

- Dyberg Larsen Morph D21 Black Table Lamp (Main Unit)
- User Manual (this document)



Figure 3.1: The Dyberg Larsen Morph D21 Black Table Lamp, featuring its distinctive multi-layered black shade and chrome-finished base and stem.

4. Setup and Installation

Follow these steps to set up your Dyberg Larsen Morph D21 Table Lamp:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble (if necessary):** The Morph D21 lamp typically comes pre-assembled. If any assembly is required,

such as attaching the shade, ensure all parts are securely fastened.

3. **Insert Bulb:** Screw the appropriate bulb (not included) into the lamp socket. Ensure the bulb wattage and type match the lamp's specifications.
4. **Position Lamp:** Place the lamp on a stable, flat surface.
5. **Connect Power:** Plug the power cord into a standard electrical outlet.



Figure 4.1: The Dyberg Larsen Morph D21 Table Lamp illuminated, showcasing the warm glow emitted from beneath its layered shade design.

5. Operating Instructions

Operating the Dyberg Larsen Morph D21 Table Lamp is straightforward:

- **Turning On/Off:** Locate the inline switch on the power cord. Flip the switch to the 'ON' position to turn the lamp on, and to the 'OFF' position to turn it off.
- **Bulb Replacement:** Before replacing the bulb, ensure the lamp is unplugged and the bulb has cooled down. Unscrew the old bulb and screw in a new one of the correct type and wattage.

6. Maintenance and Care

To ensure the longevity and appearance of your lamp, follow these maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power supply before cleaning. Use a soft, dry cloth to wipe down the lamp shade and base. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Type:** Always use the bulb type and wattage specified on the lamp's socket or label. Using an incorrect bulb can lead to overheating or damage.
- **Storage:** If storing the lamp for an extended period, unplug it and store it in a dry, cool place, preferably in its original packaging to protect it from dust and damage.



Figure 6.1: The Dyberg Larsen Morph D21 Table Lamp positioned on a wooden cabinet, demonstrating its aesthetic integration into a living space alongside decorative items.

7. Troubleshooting

If you encounter issues with your lamp, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet. Bulb is loose or burnt out. Switch is faulty.	Check if the outlet is working by plugging in another device. Tighten or replace the bulb. Contact customer support if the switch is suspected to be faulty.
Light flickers.	Loose bulb. Incorrect bulb type. Unstable power supply.	Tighten the bulb. Ensure the correct bulb type and wattage are used. Check the power outlet.

Problem	Possible Cause	Solution
Lamp gets too hot.	Incorrect bulb wattage.	Ensure the bulb wattage does not exceed the lamp's maximum rating.



Figure 7.1: The Dyberg Larsen Morph D21 Table Lamp as part of a styled interior, illustrating its design and how it complements modern decor.

8. Specifications

Feature	Detail
Model Number	8223
Product Dimensions	10 x 5 x 1.27 cm (approximate)
Weight	1 kg (approximate)

Feature	Detail
ASIN	B0BVBX2MRC
Brand	Dyberg Larsen
Color	Black

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Dyberg Larsen is committed to providing quality products and customer satisfaction.
For further assistance, please visit the official Dyberg Larsen website or contact their customer service department.

© 2023 Dyberg Larsen. All rights reserved.