

[Manuals.plus](#) /

› [BaBylissPRO](#) /

› BaBylissPRO LithiumFX Hair Trimmers User Manual

BaBylissPRO FX773N

BaBylissPRO LithiumFX Hair Trimmers User Manual

Model: FX773N

Brand: BaBylissPRO

PRODUCT OVERVIEW

The BaBylissPRO LithiumFX Cord/Cordless Lithium Ergonomic Hair Trimmers (Model FX773N) are engineered for precision and performance. Featuring a gold titanium T-blade, a powerful 6,800 RPM motor, and over 4 hours of cordless runtime, these trimmers are designed for professional-grade results.

Key Benefits:

- **Gold Titanium T-Blade:** Provides precision for clean, sharp lines and detailed styling.
- **Extended Runtime:** Lithium-ion battery offers over 4 hours of cordless operation.
- **Ergonomic Design:** Ensures comfortable handling and superior control, reducing hand fatigue.
- **Versatile Use:** Functions effectively both corded and cordless for maximum flexibility.

Suggested Use:

These trimmers are ideal for close trims, edge-ups, outlining, and detailing on all hair types. Their design supports both professional salon use and personal grooming at home.



Figure 1: Front view of the BaBylissPRO LithiumFX Trimmer.

SETUP

1. Package Contents:

Before first use, ensure all items are present in the package:

- BaBylissPRO LithiumFX Trimmer (Model FX773N)
- Charging Adapter (FXCORD compatible)
- Blade Guard
- Cleaning Brush
- Lubricating Oil
- Zero-Gap Tool (for blade adjustment)
- User Manual



Figure 2: All components included in the BaBylissPRO LithiumFX Trimmer package.

2. Initial Charging:

For optimal performance, fully charge the trimmer before its first use. Connect the charging adapter to the trimmer's FXCORD charging port and plug it into a suitable power outlet. The LED indicator will show charging status. A full charge provides over 4 hours of cordless runtime.

3. Blade Adjustment (Zero-Gap):

The LithiumFX Trimmer features zero-gap adjustability for extremely close cuts. Use the included zero-gap tool to align the blades precisely. Refer to the detailed instructions in the user manual for proper adjustment to avoid skin irritation.

BaBylissPRO

**Extended Cordless
Runtime**

Lithium-Ion Battery ————— ■
Over 4 hours of runtime

FXCORD Charging Port ————— ■
for Cord/Cordless use



Figure 3: Detail of the Gold Titanium T-blade, highlighting its zero-gap adjustability.

OPERATING INSTRUCTIONS

1. Powering On/Off:

Locate the redesigned on/off switch on the side of the trimmer. Slide the switch to the 'ON' position to activate the trimmer. Slide it back to the 'OFF' position to turn it off.

2. Corded vs. Cordless Use:

The trimmer can be used corded for continuous power or cordless once fully charged. For corded operation, simply plug the charging adapter into the trimmer and a power outlet. The trimmer will operate while charging.

3. Trimming Techniques:

- **Outlining and Edging:** Hold the trimmer with the blade flat against the skin and use light pressure to create sharp lines around the hairline, beard, or mustache.

- **Detailing:** For intricate designs or small areas, use the exposed T-blade for enhanced visibility and maneuverability.
- **Close Trimming:** The zero-gapped blade allows for extremely close cuts, ideal for bald fades or smooth finishes.



Figure 4: Demonstrating the precision of the BaBylissPRO LithiumFX Trimmer for detailing.

MAINTENANCE

1. Cleaning the Blades:

Regular cleaning ensures optimal performance and longevity. After each use, turn off the trimmer and use the included cleaning brush to remove any loose hair from the blades. The blades can be easily detached for thorough cleaning. Ensure the blades are dry before reattaching.

2. Lubricating the Blades:

Apply a few drops of the provided lubricating oil to the blades after every few uses, or as needed. Turn the trimmer on for a few seconds to allow the oil to distribute evenly. This helps maintain blade sharpness and smooth operation.

3. Storage:

Store the trimmer in a cool, dry place, away from moisture and direct sunlight. Always attach the blade guard when storing to protect the blades from damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Low battery; not properly charged.	Ensure trimmer is fully charged. Try operating corded.
Poor cutting performance.	Blades are dull, dirty, or not properly aligned.	Clean and oil blades. Check blade alignment and adjust if necessary. Consider blade replacement if dull.
Trimmer gets hot during use.	Excessive friction due to lack of lubrication or prolonged use.	Apply lubricating oil to blades. Allow trimmer to cool down between uses.
Excessive vibration or noise.	Loose blades or internal component issue.	Check that blades are securely fastened. If issue persists, contact customer support.

SPECIFICATIONS

Model Number: FX773N

Blade Type: Gold Titanium T-Blade

Motor Speed: 6,800 RPM

Battery Type: Lithium-Ion (1 included)

Runtime: Over 4 hours (cordless)

Charging Port: FXCORD Compatible

UPC: 074108466815

Manufacturer: BaBylissPRO

Country of Origin: China

WARRANTY AND SUPPORT

The BaBylissPRO LithiumFX Trimmer comes with a **2-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any inquiries regarding your product, please contact BaBylissPRO customer service. Keep your proof of purchase for warranty validation.

For more information, visit the official BaBylissPRO website or refer to the contact details provided in your product packaging.