

[Manuals.plus](#) /

› [SNARK](#) /

› SNARK Super SNARK 3 Clip-On Tuner Instruction Manual

SNARK SS-3

SNARK Super SNARK 3 Clip-On Tuner Instruction Manual

INTRODUCTION

The SNARK Super SNARK 3 Clip-On Tuner (Model SS-3) is designed to provide highly accurate tuning for a variety of stringed instruments. Its durable construction, long battery life, and precise tuning capabilities make it an essential accessory for musicians. This manual will guide you through the proper setup, operation, and maintenance of your Super SNARK 3 tuner.

SETUP

Battery Installation

The Super SNARK 3 tuner operates on a CR2032 coin cell battery. To install or replace the battery:

1. Locate the battery compartment on the back of the tuner's display unit.
2. Use a small coin or screwdriver to gently open the compartment cover.
3. Insert the CR2032 battery with the positive (+) side facing up.
4. Securely close the battery compartment cover.

Attaching the Tuner to Your Instrument

The clip-on design allows for easy attachment to the headstock of your instrument. The tuner uses vibration sensing for accurate tuning.



Image: Side view of the SNARK Super SNARK 3 Clip-On Tuner, illustrating its robust clip and flexible neck for optimal positioning on an instrument's headstock.

1. Gently open the tuner's clip.
2. Attach the clip firmly to the headstock of your guitar, bass, or other stringed instrument. Ensure it is securely fastened but not overtightened to avoid damage.
3. Adjust the flexible neck and rotating display to achieve the best viewing angle.

OPERATION

Power On/Off

To power on the tuner, press and hold the power button located on the front of the display unit. To power off, press and hold the same button again.



Image: Front view of the SNARK Super SNARK 3 Clip-On Tuner, highlighting its clear digital display and the easily accessible power button.

Tuning Your Instrument

The Super SNARK 3 tuner uses vibration to detect the pitch of your instrument's strings.

1. Ensure the tuner is securely clipped to the headstock and powered on.
2. Pluck a single string on your instrument.
3. Observe the display:
 - The display will show the note being played.
 - Adjust the tuning peg of the string until the display indicates the correct note and the indicator light turns green, signifying it is in tune.
 - If the indicator is to the left, the note is flat; if to the right, it is sharp.
4. Repeat this process for all strings until your instrument is accurately tuned.

Instrument Modes

The Super SNARK 3 is designed to tune various instruments including guitars, electric guitars, bass guitars, and other stringed instruments. The tuner automatically detects the pitch, simplifying the tuning process across different instrument types.

MAINTENANCE

Battery Replacement

When the display dims or the tuner becomes unresponsive, it's time to replace the CR2032 battery. Follow the battery installation steps outlined in the Setup section.

Cleaning

To clean your tuner, wipe it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the display or casing.

TROUBLESHOOTING

- **Tuner not turning on:** Check if the CR2032 battery is correctly installed and has sufficient charge. Replace the battery if necessary.
- **Inaccurate readings:** Ensure the tuner is securely clipped to the instrument's headstock. Loose connections can affect vibration sensing. Make sure there is no excessive background noise interfering with the vibrations.
- **Display is dim or flickering:** This usually indicates a low battery. Replace the CR2032 battery.
- **Tuner not detecting notes:** Verify that the instrument's strings are vibrating sufficiently. Pluck strings clearly and individually.

SPECIFICATIONS

Model Number	SS-3
Item Weight	1.6 ounces
Package Dimensions	3.58 x 2.76 x 1.81 inches
Color	Black
Material Type	Rubber
Battery Type	CR2032 (included)

WARRANTY AND SUPPORT

The SNARK Super SNARK 3 Clip-On Tuner is backed by a manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included with your product or visit the official SNARK website. Keep your purchase receipt as proof of purchase.