

[Manuals.plus](#) /

> [DANGZW](#) /

> DANGZW WD-996 2-in-1 Electric Fly Swatter User Manual

DANGZW WD-996

DANGZW WD-996 2-in-1 Electric Fly Swatter User Manual

Model: WD-996 | Brand: DANGZW

1. INTRODUCTION

Thank you for choosing the DANGZW WD-996 2-in-1 Electric Fly Swatter. This device is designed to effectively eliminate mosquitoes, flies, and other flying insects using a high-voltage grid and a built-in UV light. It offers both manual swatter mode and an automatic insect trap mode with a charging base. Please read this manual carefully before use to ensure safe and optimal operation.



Image 1: The DANGZW WD-996 Electric Fly Swatter showcasing its key features including 3000V physical mosquito control, 1200mAh battery, 3 layers of net protection, built-in purple LED light, double switch protection, USB charging base, portable and detachable design, and ABS material.

2. SAFETY INSTRUCTIONS

To prevent injury or damage to the device, always follow these safety precautions:

- Keep the device out of reach of children and pets.
- Do not touch the high-voltage grid with bare hands or metal objects, even when the device is off, as residual current may remain for a short period.
- Do not use the device near flammable liquids or gases.
- Do not use the device in wet environments or expose it to rain.
- Avoid using the device while charging in manual mode.
- Do not wash the device with water. Clean with a dry brush or cloth.
- If the device is damaged, do not attempt to repair it yourself. Contact customer support.
- Ensure the power switch is in the "OFF" position when not in use or when cleaning.

SAFE TO TOUCH

3 layers safety mesh design to avoid accidental electric shock





Image 2: A close-up view demonstrating the 3-layer safety mesh design, which includes outer safety nets to prevent accidental contact with the high-voltage grid, ensuring the device is safe to touch.

3. PACKAGE CONTENTS

Verify that all components are present in your package:

- 1 x DANGZW Electric Fly Swatter (Model WD-996)
- 1 x USB Charging Cable
- 1 x Charging Base
- 1 x User Manual

PORTABLE DESIGN



Image 3: An exploded view diagram highlighting the different parts of the electric fly swatter, such as the three layers of mesh, ABS material, USB charging port, double switch (ON1/ON2/OFF), detachable handle, and indicator lights for working and charging status.

4. PRODUCT FEATURES

- **2-in-1 Design:** Functions as a handheld electric fly swatter and an automatic insect trap with UV light.
- **High Voltage:** Up to 3000V output for effective insect elimination.
- **Triple-Layer Safety Mesh:** Outer safety nets protect against accidental contact with the high-voltage grid.
- **Built-in UV LED Light:** Attracts mosquitoes and other flying insects for automatic trapping.
- **USB Rechargeable:** Equipped with a 1200 mAh lithium-polymer battery and a convenient USB charging base.
- **Portable & Detachable Handle:** Easy to carry and store, suitable for various indoor and outdoor settings.
- **Durable Material:** Made from environmentally friendly ABS plastic.

5. SETUP

The DANGZW WD-996 features a detachable handle for portability and storage. To set up the device:

1. **Assemble the Handle (if detached):** Align the handle with the main swatter body and twist clockwise until securely locked.
2. **Initial Charge:** Before first use, fully charge the device. Refer to the "Charging" section for detailed instructions.



Image 4: This image illustrates the simple process of attaching the detachable handle to the main swatter unit. Below, it shows the versatility of the device in various portable settings such as outdoor gatherings, gardens, and camping trips.

6. OPERATING INSTRUCTIONS

The DANGZW WD-996 offers two operating modes:

6.1. Manual Zap Mode (Handheld Swatter)

1. Slide the power switch on the handle to the "ON1" position.
2. Press and hold the large circular work button on the handle. The red working indicator light will illuminate.

3. Swing the swatter towards flying insects to make contact with the electrified grid. A "zap" sound indicates successful elimination.
4. Release the work button to deactivate the grid.

6.2. Automatic Trap Mode (with UV Light)

1. Slide the power switch on the handle to the "ON2" position. The built-in purple UV LED light will turn on.
2. Place the swatter into its charging base. The device will now stand upright and attract insects using its UV light.
3. Insects attracted to the UV light will fly into the electrified grid and be eliminated.
4. For continuous operation in automatic mode, it is recommended to keep the power cord connected to the charging base to avoid insufficient power.

2 IN 1 DESIGN




Image 5: This image demonstrates the dual functionality of the device. The top panel shows the swatter in 'Auto ZAP Mode' while placed in its base, attracting insects with its UV light. The bottom panel shows the 'Manual ZAP Mode' where the device is used as a traditional handheld swatter.



BUILT-IN PURPLE LED LIGHTS

The built-in purple LED light not only attracts mosquitoes in the dark, but also allows you to quickly find and eliminate them. Slide the power switch of the electric mosquito swatter to the ON2 position, then place it in the charging base to act as a mosquito repellent light. (It is recommended to keep the power cord connected to avoid insufficient power.)



LARGE MESH AREA

The mesh area is 22 * 16 cm, and the three mesh layers are staggered and cut. The mesh size is about 15 mm. The size of flies and mosquitoes is about 3-10 mm, so mosquitoes have nowhere to escape after touching the grid area.



PREVENT ACCIDENTAL TOUCHING

When the switch is released, there is no residual current on the surface of the mosquito swatter. Even if a finger accidentally touches the inner grille, it will not cause electric shock or injury. When switching on, it is forbidden to enter the internal network of the electric mosquito swatter.

Image 6: A visual guide detailing the operational steps for both manual (ON1) and automatic (ON2) modes. It shows how to activate the swatter for manual use and how to set it up in the charging base for automatic insect trapping with the UV light.



Image 7: This image highlights the key features for effective and safe operation: the built-in purple LED lights for attracting insects, the large mesh area (22x16 cm) with staggered layers for efficient trapping, and the safety mechanism that prevents accidental electric shock by eliminating residual current quickly.

7. CHARGING

The DANGZW WD-996 is equipped with a 1200 mAh rechargeable lithium-polymer battery.

1. Connect the provided USB charging cable to the USB charging port on the swatter handle or the charging base.
2. Connect the other end of the USB cable to a compatible USB power source (e.g., PC, power bank, USB adapter).
3. The charging indicator light will show the charging status. It typically glows red while charging and turns green or off when fully charged (refer to product specific indicator behavior).
4. A full charge typically takes 3-4 hours.

USB CHARGING



Image 8: This image displays the electric fly swatter on its charging base, connected via USB. It also provides the product dimensions (53cm height, 22cm width, 370g weight) and shows various compatible USB charging sources like a PC, power bank, or adapter.

8. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and effectiveness of your electric fly swatter.

- **Cleaning the Grid:** After use, ensure the device is switched to "OFF" and any residual charge has dissipated (wait a few seconds). Use a soft, dry brush or cloth to gently remove dead insects from the grid. Do not use water or wet cloths.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and moisture.
- **Battery Care:** If not used for an extended period, charge the battery at least once every three months to maintain its lifespan.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Swatter not zapping/no power.	Battery is low or depleted. Power switch is OFF or in wrong position. Work button not pressed (manual mode).	Charge the device fully. Ensure switch is ON1 (manual) or ON2 (auto). Press and hold the work button.
UV light not turning on.	Power switch not in ON2 position. Battery is low.	Slide switch to ON2. Charge the device.
Insects not being attracted in auto mode.	UV light is off. Device placed in a brightly lit area.	Ensure switch is ON2 and UV light is active. Place the device in a darker area for better attraction.
Charging indicator not working.	USB cable or adapter is faulty. Device is already fully charged.	Try a different USB cable or adapter. This is normal if the battery is full.

10. SPECIFICATIONS

Feature	Specification
Model Number	WD-996
Brand	DANGZW
Output Voltage	Up to 3000V
Battery Type	1200 mAh Lithium-polymer (included)
Charging Method	USB (with charging base)
Material	ABS
Dimensions (approx.)	53 cm (Height) x 22 cm (Width)
Weight (approx.)	560 grams
Included Components	Electric Fly Swatter, USB Cable, User Manual, Charging Station

11. WARRANTY AND SUPPORT

DANGZW products are manufactured to high-quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official DANGZW website. Keep your purchase receipt as proof of purchase.

